PLACEMENT OF SERIAL NUMBER MODEL: XAV-AX5500//Q(UC)

Type Approval mark and Serial number is to be printed are on the same plate label affixed to bottom of main unit

