


XPERIA 10 III

SONY

1 SIM




XQ-BT52


SIM1

SIM2

microSD



2 PWR ON



Startup guide

Ръководство „Бърз старт“
Úvodní příručka
Kurzanleitung
Installationsvejledning
Alustusjuhend
Guia de início
Aloitusopas
Guide de démarrage
Οδηγός εκκίνησης
Priručnik
Használatbavételi útmutató
Ræsihandbók
Guida introduttiva
Palesties vadovas
Sākšanas ceļvedis
Opstartgids
Oppstartsveiviser
Instrukcja obsługi
Manual de Iniciação
Ghid de pornire
Starthandbok
Vodič za začetek uporabe
Úvodná príručka
Руководство по запуску
Бастапқы нұсқаулық
คู่มือเริ่มต้นการใช้งาน
用戶指南



XQ-BT52



Printed in XXX (Printers logotype)





Xperia Transfer 2



OR



https://rd1.sony.net/help/mobile/xperia-10m3/h_zz/



USB Type-C



Google Assistant key

