

# 80g铜版纸 黑白单色 双面印刷 风琴折

注: 正反双面印刷, 请保持正反面内容是同一方向,方便阅读。 成品尺寸: 62.5\*100mm

风琴折( - - - - - 虚线为折痕标识, 不用印刷; ———

# 一 实线为刀模,不用印刷)





### Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including

interference that may cause undesired operation. FCC Warning Statement:
This equipment has been tested and found to comply with the

limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help.

### NOTE:

1. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

2. Equipment system maintenance is simple, please refer to the manual.

 The user can take simple measures to correct the interference.
 Such as staying away from interference sources, turning off interference sources, etc.

### Safety Instruction

Avoid water, heat, fire, penetration of the battery, and severe drops at all times
Do not insert other objects into the USB ports other than the USB connectors.
Once the product is fully charged, your power pack automatically shuts off to save power.

save power.

During charge & recharge, battery may feel sightly warm.

Do not clean the battery with water or other cleaning products, clean the with a lightly wested dofn or nagare.

Normally the battery performance will decline after 2 years.

A stream of an an physical domage to the battery will not be under the varieties of the contract of the product of the contract of the product of the contract of the product of the

erature is between -10°C~+60°C , operating temperature

5°C. ge the battery before first use to maximize the battery life.



## PowerSafe Management

Guarantees against short circuit and over-charging for your power bank and



Customer Service
For any question about the product, please contact us at







Dispose the battery properly, seek for local disposal facility for advice. Do not dispose, dissemble, damage, or incinerate the battery at all time

UM 2 QM5004 EN 1.1

6.25 cm 6.25 cm 6.25 cm 6.25 cm

