


WHAT'S INCLUDED

Component Checklist



(1) RC Vehicle



(2) Transmitter




(3) AA Batteries

TRANSMITTER

Battery Installation

1. To open battery compartment cover on transmitter, slide in the direction indicated by the arrow.
2. Insert 3 "AA" size batteries. Make sure the positive (+) and negative (-) markings on the batteries match up to the ones inside the Battery Compartment.
3. Replace the Battery Compartment Cover making certain that the Compartment tab has "snapped" into the locked position.



After inserting batteries, please check the following items:
 - The battery cover is closed properly.
 - The battery cover is locked properly.
 - The battery cover is not damaged.

Syncing

This transmitter is equipped with 2.4GHz technology which allows up to 8 vehicles to be used at the same time.

To sync transmitter and vehicle, follow these steps:

1. Install batteries in Transmitter.
2. Turn on Vehicle.

Once the batteries are installed and the vehicle is turned on, the Transmitter will sync automatically with the vehicle.

Sound

Touch the wheel to hear Laughing sounds.

TRANSMITTER

Functions

Left Hand Control



Right Hand Control

Note:
Vehicle has working lights. When vehicle is powered ON, eyes will glow. When vehicle is in motion, eye color will change.

How to Drive

FORWARD AND REVERSE DRIVING



FORWARD DRIVING
Push LEFT joystick forward for forward driving.



REVERSE DRIVING
Push RIGHT joystick backward for reverse driving.

TURNING



RIGHT TURNING
Push LEFT joystick forward to turn right while driving forward. Push LEFT joystick back to turn right in reverse.



LEFT TURNING
Push RIGHT joystick forward to turn left while driving forward. Push RIGHT joystick back to turn left in reverse.

SPINS




180° SPIN - Clockwise
Push joystick to turn for Clockwise Spinning.



360° SPIN - Counter-Clockwise
Push joystick to turn for Counter-Clockwise Spinning.

VEHICLE

Functions



Charging

This vehicle is equipped with an internal Lithium-Ion battery that is recharged via USB. **ON/OFF Switch must be in the OFF position prior to charging.**

1. Locate the Charging Cord Compartment Cover on the underside of vehicle.
2. Use a screwdriver to remove the small screw keeping the cover in place.
3. Remove USB cable from the Storage Compartment. Use care when extending cord as it is attached to inside internal battery. Cord can be plugged into any computer or USB outlet (not included).
4. Insert the USB connector into a computer or other USB power source.
5. While charging, the Charging Status Light under the vehicle will be on. Once fully charged the light will turn off. Charging is completed in approximately 2 hours (when charging from a 1.0A A/C).
6. After charging is complete, place the USB cord in the Charging Cord Compartment. Pop out the Compartment cover and remove the USB cord.