


1. 尺寸单位: MM

					FOLLRIVER	
					FOLLRIVER	
					FOLLRIVER	
0000	01	02	03	04	FOLLRIVER	
05	06	07	08	09	FOLLRIVER	
10	11	12	13	14	FOLLRIVER	
15	16	17	18	19	FOLLRIVER	
20	21	22	23	24	FOLLRIVER	
25	26	27	28	29	FOLLRIVER	
30	31	32	33	34	FOLLRIVER	
35	36	37	38	39	FOLLRIVER	
40	41	42	43	44	FOLLRIVER	
45	46	47	48	49	FOLLRIVER	
50	51	52	53	54	FOLLRIVER	
55	56	57	58	59	FOLLRIVER	
60	61	62	63	64	FOLLRIVER	
65	66	67	68	69	FOLLRIVER	
70	71	72	73	74	FOLLRIVER	
75	76	77	78	79	FOLLRIVER	
80	81	82	83	84	FOLLRIVER	
85	86	87	88	89	FOLLRIVER	
90	91	92	93	94	FOLLRIVER	
95	96	97	98	99	FOLLRIVER	



Label Location