

UTX-P40 Internal Structure <1>



Detached the Case.




Detached the PWB CPU-472.

UTX-P40 Internal Structure <2>




Detached PWB RF-178.

UTX-P40 Internal Structure <3>



Side A of Board CPU-472.

UTX-P40 Internal Structure <4>



Side B of Board CPU-472.