

BIC BIC RASTAR

01.04.47600.01200

01.04.47600.01100



OPERATION GUIDE

 The fixing piece for chassis can be used to twist the lock of the battery cover, please see the picture on the right.
 Please open the lid and put 5 pieces of "AA" batteries into the car according to its polarity, then close the lid and twist the chassis piece to lock the battery cover. 3.Put the antenna into the controller socket. Open the lid and put the 2 pieces of "AA" batteries into the controller according

to its polarity, then close the lid. 4.Switch to "ON" position on the car to begin playing.

5.Adjust the direction adjustment switch to control the car running in a straight line.

CAUTION

1.Different types of batteries or new and used batteries are not to be mixed. Exhausted batteries are to be removed from 2.Batteries should be replaced by an adult. Batteries are to be inserted with the correct polarity. The supply terminals are not

to be short-circuited. 3.Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the toy before being charged. Batteries are to be charged by an adult or children at least 8 years old, leaked or broken batteries are not to be charged.

4.Rechargeable batteries are only to be charged under adult supervision.
5.Only batteries of the same or equivalent type is recommended to be used.
6.The antenna, wire, USB wire or battery plug are not to be inserted into output socket.
7.Never put the batteries near fire or any source of heat, water or direct sunlight.
8.Skin or clothing is to be washed immediately if you make contact with leaked liquid from the battery.
9.Regularly examine the toy for any damage to its wires, plug, enclosure and other parts, and they must not be used until the

damage has been repaired. 10. For better preservation of rechargeable batteries, please regularly recharge it. Only a charger of the same or equivalent type is recommended to be used. 11.Plastic bag is not for playing, as it may cause suffocation. Please keep away from small children. 12.Dispose of battery responsibly. Do not dispose of in fire.

<u>Ferrar</u>i

Produced under license of Ferrari S.p.A. The name FERRARI, the PRANCING HORSE device, all associated logos and distinctive designs are property of Ferrari S.p.A. The body designs of the Ferrari cars are protected as Ferrari S.p.A. property under design, trademark and trade dress regulations.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Licensee: RASTAR (HK) INDUSTRIAL COMPANY LIMITED Manufacturer:RASTAR GROUP Add:Xinghui Industrial Park, Xiadao Road, Shanghua, Chenghai, Shantou, Guangdong, China. Http://www.rastar.com MADE IN CHINA



Not for children under 3 years.





DIRECTION ADJUSTMENT

CHASSIS

BATTERY

ON-OFF SWITCH

5"AA"BATTERIES

(NOT INCLUDED)



The packaging has to be kept since it contains important information.

REVERSE

BATTERY

2 "AA" BATTERIES

(NOT INCLUDED)

Full Function Radio Control: Forward, Reverse, Turn Left, Turn Right, Headlight and Rear Light.



RIGHT

______ C M Y K 485C 50100 1/14法拉利 LaFerrari 常规英文彩盒