

Search for available Bluetooth Wireless devices and you would find "LINSAY SLP-500CL" – Pair it with this device.

If required, enter the password "0000" to pair with the device. Once paired successfully, another indication tone would be heard.

You can now stream wireless music on your speaker through your source device.

Listening to Music Connecting Bluetooth

Please ensure that your device (Mobile Phone, Tablet or other devices) is paired with the Wireless Speaker to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Increase Volume	Playing music	Press and hold the + button to increase the volume
Decrease Volume	Playing music	Press and hold the - button to decrease the volume
Pause	Playing music	Short press the Play /Pause button will pause the music
Play	Pausing	Short press the Play /Pause button will resume the music
Previous track	Playing music	Short press the — button will return you to the previous track
Next track	Playing music	Short press the + button will take you to the next track

(Note: The above functions only can be used in Wireless mode only. An indication tone will alert you when the volume is adjusted to either minimum or maximum level.)

Talking using the Bluetooth Speaker

Please ensure that you are paired with the Bluetooth Wireless Speaker to use the below functions.

Function	Operation	Button
Answer Incoming Call	Incoming Call	Press the Phone once to answer an incoming call.
Reject incoming call	Incoming Call	Press and hold the Phone button for 2 second
End Call	Incoming Call	After your phone conversation, short press the Phone button
Increase Volume	During a Call	Press and hold the + button to increase the volume
Decrease Volume	During a Call	Press and hold the - button to decrease the volume
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

1+1 Connection

To enrich your listening experience please you can build your own party by wirelessly connecting 2 speakers.

1. Turn ON the Speaker
2. Long press the light button and you will hear "dingdong" sound and means 2 speakers are connected successfully.
3. Activate the Bluetooth Wireless function on your source device (Mobile

Phone, Tablet or other devices). Please refer to manufacturer's instructions for instructions on enabling wireless connection on your device.

4. Search for available Wireless devices and you would find LINSAY SLP-500CL – Pair it with this device.
5. Enjoy your connecting music time.

Listening to FM Radio

Insert the Micro USB end of the included USB rechargeable cable into the charging port, and leave the other end of the cable open. USB rechargeable cable serves as FM Antenna while in FM Radio mode.

Long Press the ON/OFF switch to open the power, you would hear an indication tone then short press button then the speaker is in FM mode.

To AUTO SCAN the station, Press Power button once.

It will take few minutes to search all the stations. Once all the stations are scanned, they get registered in memory, automatically.

Press + or – to skip selected station.

Long press + to increase the volume or press - to decrease the volume.

Play Music through “Auxiliary” Mode

Turn ON the speaker.

Insert one end of the Auxiliary cable (included) into the Auxiliary port,

Plug the other end to the audio device (such as phone / MP3 Player / computer /

tabletetc). Select your favourite song at the source device to play.

Long press + to increase the volume or press - to decrease the volume.

The LED Light Settings

Short Press the button to change the LED Light you like or turn off the light.

Stream music from Micro SD (TF) Card or USB Flash Drive

Turn ON the speaker.

Insert the Micro SD (TF) Card or USB Drive preloaded with songs, into the

Micro SD (TF) Card Slot or USB Card Slot of the speaker correspondingly.

Speaker would automatically start playing songs from the Micro SD (TF)

Card or USB Drive.

Troubleshooting

Problem	Possible Cause	Solution
Low sound level	Source (Tablet, Mobile Phone, Laptop, etc.) volume too low.	Adjust source volume.
	Battery dead	Charge Battery.
Sound distorted	Battery nearly dead	Charge Battery.
No sound at all	Source (Tablet, Mobile Phone, Laptop) turned off.	Turn the source on.
	Speaker turned off.	Turn the speaker on.
	Volume turned down source.	Adjust volume source.
	Media paused on source.	Play media from source.
Wireless BT cannot connect	There are short functional obstacles in the product The product has been connected with other devices	Restart the speaker Disable Wireless BT of other source devices and search for Wireless BT again

SPECIFICATIONS

Wireless Streaming Range Distance	up to 10 Metres
Output Power	5 Watts
FM Frequency Range	87.5-108MHz
Unit Size	L86 x H184 x D86mm
Unit Weight	497g approx.
Power Input	DC 5V
Charging Time	2-3 hours
Play time	up to 2 hours (max. volume)
Built-In Rechargeable Battery	3.7V / 2000mAh
Micro SD (TF) Card/USB Drive	Support up to 32GB

(Note: Battery life & charging time may vary based on usage, types of devices connected & wireless distance).

SAFETY INSTRUCTIONS

- Keep the speaker away from heat sources, direct sunlight, humidity, water and any liquids.
- Do not operate the speaker if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and / or injury to yourself and damage to speaker.
- Do not use the speaker if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the speaker with wet hands.
- Do not put objects into any of the openings.
- Keep the speaker free from dust, lint etc.
- Do not use this speaker for anything other than its intended use.
- Keep the speaker out of reach of children.
- This appliance is not a toy.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operation the equipment.

TOLL FREE-1-855-LINSAY-HELP

Warranty Policy

(1) ONE YEAR Limited Warranty on Parts and Labor

LINSAY provides (1) One YEAR of limited WARRANTY against manufacturing defects in materials and workmanship to the original purchaser of a new LINSAY purchased from an authorized LINSAY U.S., which begins on the date of purchase by the customer. Customer is responsible for maintaining proof of date of purchase and must make the registration of the product into of 30 days of the purchase on <http://www.linsaydigital.com/registration.php> to validate the warranty

LINSAY's Responsibility

LINSAY purchased new from an authorized LINSAY U.S. reseller and that are used in the fifty (50) United States or Puerto Rico are warranted to be free from manufacturing defects in materials and workmanship for (3) three months from the date of the original retail purchase. LINSAY 's limited warranty covers only those defects which arise as a result of normal use of the product, and do not apply to any improper or inadequate maintenance or modification; software, interfacing, media, parts, or supplies not provided or supported by LINSAY; or operation outside the product's specifications.

If LINSAY receives, during the applicable warranty period, notice of a defect in any hardware product, which is covered by LINSAY's warranty, LINSAY shall either repair or replace the defective product at LINSAY's option.

If LINSAY is unable to repair or replace, as applicable, a defective product which is covered by LINSAY's warranty, LINSAY shall within a reasonable time after being notified of the defect, refund the purchase price for the product.

LINSAY shall have no obligation to repair, replace or refund until the customer returns the defective product to LINSAY.

Units sent to LINSAY for repair will be repair or replaced with new or like-new product (s) of the same model with the same functionality as the original unit.

Original unit (s) will be returned only at LINSAY's discretion. LINSAY is not responsible for any content on the original unit.

LINSAY's limited warranty is only valid in the country of purchase.

LINSAY will not validate purchases made via trade or barter. This pertains to trade or barter between individuals on sites such as E-Bay where trade or barter transactions are facilitated.

LINSAY does not warrant damage incurred to the shell case on any unit sold. Any manufacturer's defect is at the sole discretion and discernment of LINSAY repair technicians as the unit will need to be in possession of the return authorization number RAN technicians for a full and accurate evaluation to be made.

How to Obtain Warranty Service

To obtain warranty service, contact LINSAY Technical Support via email at

TechnicalSupport@linsaydigital.com. You must provide the model, serial number, and date of purchase. LINSAY Technical Support is available from 10:00AM to 5:00PM EAST Time, Monday through Friday. Please note that holiday hours may vary. For up to date information, please visit www.LINSAYdigital.com.

LINSAY reserves the right to assess all warranty claims and to determine if defects or damages are covered by this limited warranty. In case of a claim that is not covered by this warranty, you will be contacted to determine whether LINSAY

should repair the damage for a fee or whether the product should be returned to you as received by the service technician or service center.

Parts and service labor that are LINSAY's responsibility under this limited warranty will be provided without charge. All other service is at the customer's expense.

LINSAY reserves the right to charge the customer for any service call for anything not covered by this limited warranty. Before you ask for warranty service, please review your User Manual. You may avoid a service call and a service charge.

Please refer to the reverse side of this page for additional information regarding how to obtain warranty service.

PLEASE DO NOT RETURN YOUR UNIT TO LINSAY WITHOUT PRIOR AUTHORIZATION.

Not Covered

This limited warranty does not cover the following: cosmetic defects; damage, malfunctions or failures resulting from shipping or transit, improper or faulty installation, abuse, operation contrary to furnished instructions, operation on incorrect power supplies, products not supplied by LINSAY, modification, alteration, improper servicing or tampering; damage from fire, water, lightning, power surges, abnormal environmental conditions or other acts of nature; normal wear and tear; unsatisfactory audio performance not caused by a manufacturing defect; or unreadable serial number.

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE LISTED OR DESCRIBED ABOVE. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE PERIOD OF TIME SET FORTH ABOVE. LINSAY'S TOTAL LIABILITY FOR ANY AND ALL LOSSES AND DAMAGES RESULTING FROM ANY CAUSE WHATSOEVER, INCLUDING LINSAY'S NEGLIGENCE, ALLEGED DAMAGE, OR DEFECTIVE GOODS, WHETHER SUCH DEFECTS ARE DISCOVERABLE OR LATENT, SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE PRODUCT.

LINSAY SHALL NOT BE RESPONSIBLE FOR LOSS OF USE, COMMERCIAL LOSS, LOST REVENUE OR LOST PROFITS, OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. This is the only warranty applicable; no one is authorized to extend or modify it or to grant any other warranty on LINSAY's behalf.

Owner's Responsibility

To ensure warranty service, keep the dated bill or sales receipt as evidence of the purchase date and location. This limited warranty applies only to original purchaser and is non-transferable.

Warranty service conditions are subject to change. For the latest Warranty Terms and Conditions and additional information regarding LINSAY's Limited Product Warranty, please see complete details online at:

www.LINSAYdigital.com

