尺寸:110x70mm

产品说明书

——Product description—



YYK-Q80 夹耳式蓝牙耳机

蓝牙版本:V5.3

通话时间:约6小时

音乐播放:约6小时

待机时间:80小时

通信距离:≥10m

耳机充电时间:约1小时

频率特性:2.40GHz-2.48GHz

支持协议:A2DP1.3/HFP1.6 HSP1.2/AVRCP1.6/D11.3







暂停/播放:双击MFB键

上一曲:长按1秒L边MFB键

下一曲:长按1秒R边MFB键

音量加:三击L边

音量减:三击R边

接听电话:双击MFB键

挂断电话:双击MFB键

来电拒接:长按MFB键2秒

取消通话:双击MFB键

呼叫Siri:不播放歌状态下 三击左或右MFB键

取消Siri:双击左或者右边MFB键

开机关机

1.初次开始使用的情况下,当耳机从充电仓里取出 耳机就会自动开机。 放回充电仓耳机就会开始充电并自动关机。

2.当耳机不使用时,放回充电仓自动关机。

如何重置

耳机在配对状态下,双击MFB键后长按3秒。将耳机放入 充电仓,耳机会自动关机并开始充电。取出耳机后,耳机 会自动开机,重置就完成。

如何配对

1.从充电仓拿出开机 2.耳机自动配对

3.打开手机/平板的设置---蓝牙---打开蓝牙---搜索---YYK-Q80---配对/连接--播放音乐。

电脑/手提电脑配对的方法

打开电脑设置-设备-蓝牙和其他设备-开启蓝牙--添加蓝牙 或其他设备-搜索蓝牙设备YYK-Q80-配对/连接-播放音乐。 注意:如果电脑没有蓝牙,请插入蓝牙适配器,下载蓝牙驱动

如何给耳机充电

1.把耳机放入充电仓内,耳机就会自动关机然后开始充电, 充电仓显示灯亮起,说明充电仓正在给耳机充电。 2.耳机充电时红灯常亮,充满蓝灯常亮充电仓灭灯

给充电仓充电

请使用手机适配器给充电仓充电,可以使用电脑Type-c线 或者其他Type-c接口的充电器进行充电。

高质量的耳机,为了延长使用寿命,请参考以下说明:

- 1.请本品远离高温、高湿、腐蚀环境。 2.请防止本品被撞击,跌落,弯曲,浸泡等。
- 2.请不要让本品一直过度充电,这样降低本品的使用寿命。 4.请不要让本品一直过度充电,这样降低本品的使用寿命。
- 4. 请小委儿本的一直过度元也,这种特征本的的政府对印。 5. 如果它引作何不适感或者疼痛,请停止使用本品。 6. 使用由受监管的制造商认证的DC SV-1A适配器。 反复充电和放电耳机会导致电池性能随时间降低,这对所有可充电

产品包装内有

2.充电座1个 3.Type-c充电线1条 4.说明书1本

User Manual

——Product description—



YYK-Q80 Clip on Bluetooth headset

Bluetooth version: V5.3

Talk time: about 6 hours

Music playing: about 6 hours

Standby time: 80 hours

Communication distance: ≥10m

Charging time of headset: about 1 hour

Frequency characteristic: 2.40GHz-2.48GHz

Support agreement:A2DP1.3/HFP1.6 HSP1.2/AVRCP1.6/D11.3



L side MFR key

Pause/play: Double click MFB

Last song: Long press the Lear MFB key for 1 second

Next song: Long press the R ear MFB key for 1 second

Sound plus: three strikes on L ear

Sound reduction: three strikes on Rear

Answer the call: Double click MFB

Hang up the phone: double click the MFB key

Call rejection: Long press MFB key for 2 seconds

Cancel call: double click MFB key

Call Siri: in the state of not playing songs Three click left or right MFB

Cancel Siri: Double click the left or right MFB key

Power on/of

1. When the headset is taken out of the charging cham ber for the first timeThe headset will turn on automati

Put the headset back in the charging chamber and it will start charging and automatically shut down. 2. When the headset is not in use, put it back into the charging chamber and turn it off automatically.

How to reset

When the headset is paired, double click the MFB key and hold it for 3 seconds. Put the headset in In the ch arging chamber, the headset will automatically shut down and start charging. After removing the headset It will start automatically, and the reset is completed.

How to pair

- 1. Take out the charging chamber to start the machine 2. Automatic headset pairing
- 3. Open the settings of mobile phone/tablet --- Bluetooth --- Open Bluetooth --- Search---

YYK-Q80 --- pairing/connecting --- playing music.

Computer/laptop pairing method

Turn on PC settings - Devices - Bluetooth and other devices - Turn on Bluetooth - Add BluetoothOr other devices - search Bluetooth device YYK-Q80 - pair/connect - play music. Note: If the computer does not have Bluetooth, please insert the Bluetooth adapter and download the Bluetooth driverThen it can be used normally

1. Put the headset into the charging compartment, and the headset will automatically shut down and start char ging. The display lamp of the charging compartment lights up, indicating that the charging compartment is charging the headset.

The red light is always on when charging the headset, and the blue light is always on when charging the headset. The charging chamber is off.

Please use the mobile phone adapter to charge the charging chamber. You can use the computer Type-c cableOr other chargers with Type-c interface.

prolong the service life: .. Please keep away from high temperature, high humidity and corros

P. Please prevent the product from being hit, dropped, bent, soaked, etc.

Please do not remove the headset or charging stand

4. Please do not allow the product to be overcharged all the time, so as to reduce the service life of the product.

5. If it causes any discomfort or pain, please stop using this product.

6. Use a DC 5V-1A adapter certified by a regulated manufacturer. Repeated charging and discharging of the headset will cause the battery performance to decrease over time, which will affect all rechargeable

There are

1. Two Bluetooth headsets One charging base
 One Type-c charging line

FCC Warning

15.19 Labeling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)
This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

the equipment.
15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device,

pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the

equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
FCC RF Radiation Exposure Statement:
1.This Transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.
2.This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
This equipment should be installed and operated with minimum distance 5mm

between the radiator and your body

FCC ID: 2AOZMYYK-Q80