


## <Photographs of EUT>

Refer to the EUT external photographs.

## <Antenna Location>



The separation distance for antenna to edge:

| Antenna | To Front Side (mm) | To Rear Side (mm) | To Left Side (mm) | To Right Side (mm) | To Top Side (mm) | To Bottom Side (mm) |
|---------|--------------------|-------------------|-------------------|--------------------|------------------|---------------------|
| BT      | < 5mm              | 6.0               | 14.6              | < 5mm              | 20.4             | 11.6                |

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China  
 Tel: +86-755-28230888 Fax: +86-755-28230886 E-mail: [info@uttlab.com](mailto:info@uttlab.com) <http://www.uttlab.com>  
 UTTR-SAR-IEEE Std 1528-2013-V1.1\_Appendix D

## <Photographs of SAR Setup>



## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China  
 Tel: +86-755-28230888 Fax: +86-755-28230886 E-mail: [info@uttlab.com](mailto:info@uttlab.com) <http://www.uttlab.com>  
 UTTR-SAR-IEEE Std 1528-2013-V1.1\_Appendix D