



Internal Photos


OPEN VIEW OF EUT




VIEW OF BATTERY




INTERNAL VIEW OF EUT-1




INTERNAL VIEW OF EUT-2




INTERNAL VIEW OF EUT-3




Charging Dock
VIEW OF EUT (PORT)




Series Model
BH099B
OPEN VIEW OF EUT




VIEW OF BATTERY




INTERNAL VIEW OF EUT-1




INTERNAL VIEW OF EUT-2




INTERNAL VIEW OF EUT-3




BH067A
OPEN VIEW OF EUT




VIEW OF BATTERY




INTERNAL VIEW OF EUT-1




INTERNAL VIEW OF EUT-2




INTERNAL VIEW OF EUT-3




BH131A
OPEN VIEW OF EUT




VIEW OF BATTERY




INTERNAL VIEW OF EUT-1




INTERNAL VIEW OF EUT-2




INTERNAL VIEW OF EUT-3




BH191A
OPEN VIEW OF EUT




VIEW OF BATTERY



INTERNAL VIEW OF EUT-1



INTERNAL VIEW OF EUT-2



INTERNAL VIEW OF EUT-3

