

USER MANUAL



Specifications

Battery Capacity	10000mAh 37Wh
Type-C Input	5V \sim 3A, 9V \sim 2A, 12V \sim 1.5A
Type-C Output	5V \sim 3A, 9V \sim 2.22A, 12V \sim 1.67A
USB Output	5V \sim 4.5A, 9V \sim 2A, 12V \sim 1.5A
Wireless Output	15W/10W/7.5W/5W
Dimensions	126.7 x 71.6 x 18mm

Package Contents



Power Bank x1




Charging Cable x1



User Manual x1

Product Features



1. Wireless Charging Indicator
2. 4-Level Power Indicators
3. Power Button
4. USB Output
5. Type-C Input & Output
6. Folding Phone Stand
7. Wireless Charging Area and Magnetic Adsorption Ring

Operating Instructions

1. Charging the power bank



1). Connect the Type-C cable (included) between power bank and the wall charger or power adapter (not included), It will start charging automatically. It's recommend to use the PD22.5W wall charger or power adapter to match the fast charging.

2). During charging, the power Indicators will flash. Each LED light indicates about 25% of the available battery capacity. When fully charged, all power Indicators will always be on.

Note: Fully charge the power bank before using the power bank for the first time. Recharge the power bank once every three months when not in use or seldom used.

2. Charging the device



1). Wired Charging

Press the power button, the power indicators are on. Connect the charging cable between the USB or Type-C port of power

bank and the device to start charging. During charging the device, the power indicators are on.

2). Wireless charging

Place the device in the center of the wireless charging area. If your device supports MagSafe technology, The power bank will automatically hold it thanks to strong magnets.

Press the power button, the wireless charging indicator is on, which means wireless charging is in progress.

Note: Make sure your device is fit for Qi standard receiving equipment.

Troubleshooting

1. Press the power button, if the first power indicator is flashing, It means the battery is running out soon, please recharge.
2. This power bank can automatically identify equipment that need to charge, If no device is being charged, the power bank will be turned off after 30 seconds.
3. For wireless charging, your device must be equipped with a Qi wireless receiver. The device can automatically identify a Qi-compatible device placed on it. If the center point of the receiving terminal is deflected over 8-10mm from the center point of transmitting terminal, the power bank will turn off automatically.
4. If wired charging is not working properly, please use another charging cable, since the connector may become loose .
5. During charging, the device may become warm due to high

currents and resistance, especially during wireless charging. To reduce temperature, avoid running intensive applications or using GPS on your mobile device when charging.

Cautions

1. The power bank will generate heat when charging. Always charge in a well-ventilated and open-air area.
2. Do not charge under pillows, blankets, clothing or on flammable surfaces. Keep the power bank away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
3. Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into the power bank.
4. Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy objects on the power bank.
5. Do not short-circuit the power bank or store it in a receptacle where it may be short-circuited by other metallic or conductive objects.
6. Do not operate the power bank if it has been wet or damaged, to prevent against electric shock, explosion and/or injury.
7. Keep the power bank dry to avoid short circuits or other damage to electronic components.
8. Keep the power bank away from high heat and flammable liquids and gasses. Avoid using in environment temperature above 45°C or below 0°C.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.