



USER GUIDE

Push Active Series



Skullcandy.com/support/usa/active

Auto Pair Mode



Pairing Mode



Auto Power - On




Power - On




Auto Power - Off




Power - Off




Charge Earbuds



Charge Case





Pairing Mode



Play/Pause




Track Forward



Track Back




Power - On



Power - Off





Play/Pause




Track Forward



Track Back




Volume Up



Volume Down




Answer/End



Activate Voice Assistant



Clear Paired Device



Questions Visit

Skullcandy.com/support/usa/active

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker

EN Speaker