


SAR Test Setup Photographs

EUT Side Definition(System2 Full)		
Mode	Side	
1	Back	
2	Side1	
3	Side2	
4	Side3	
5	Side4	
		

Phantom Position : Flat	EUT side : Back
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side1
Spacing to phantom : 0mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side2
Spacing to phantom : 0mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side3
Spacing to phantom : 0mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side4
Spacing to phantom : 0mm	Accessory : N/A
	