


物料名称：用户手册

物料编号:

材质：70g书写纸，双面单墨印刷



尺寸：531×146mm 成品尺寸：59×73mm



Running Status	LED Indicator Description
Parking	Red LED and blue LED both dimmed
Turn On	LED indicator is red, LED indicator is blue when turning on
Standby Mode / TT Card Mode	LED light is solid green
TF Card Music Play	Green LED is on while playing
Charging	Green LED will flash 4 times, LED light goes off while it's charged

Operation Guidance

Turn On	Toggle switch to turn on position, Red LED will be on for 2 seconds and then headphones turn on
Turn Off	Toggle switch to turn off position, red LED will be on for 2 seconds and then headphones turn off
Bluetooth Connection (1)	After entering the headphones enter in pairing, you need to set the "BT" on your phone and connect with Blue



TCF Card Music Play	
I	When inserting TCF card during shutdown, the driver will automatically start playing music.
Mode Switch Long press the music button for 6 seconds to switch between TCF card and phone.	
Auto off and Long-Station Recorrect	
When	Auto off happens automatically, if it's still off after 6 minutes for saving energy cost.
The headphones	After 6 minutes of disconnection, it will turn off the playback function and then auto correct your phone. (Disconnected for over 6min will auto off)
Factory Reset	
When	Bluetooth in connection, long press "OK" + "Up" + "Down" at the same time for 5 seconds, it will enter the factory reset mode, and then it will clear all the data and LED words display. It restores the factory default setting after reset. (volume default to grade 14/16, and won't remember the previous volume setting)
NOTE!	NOTE! To delete the data on your phone, please connect to the power supply or the previously connected power.
Languages Switch	
Double click	in playing status for changing language.
Line-in Mode	
Turn	Turn SONY STEREO in the audio cable, the music will be played from the line-in port. The volume can be turned on, on/off to the music.
NOTE!	To prevent damage to the songs in the music, it is recommended to turn off the volume before turning on the line-in mode.
Double click	in playing status for changing language.
Charging Mode	
Headphones	With headphones off power and adapter connected to the power supply, turn on the headphones with USB charging data. The headphones will start charging during USB connection. The headphones will automatically turn off when the power is off.
Power Status	
Check	Check the headphones connected to the current power status of the headphones through the indicator of the device.

language settings.

Parameters Information	
Profile Supported	BT/HFP / SPP / HSP / HFP
Access Range	8-100m
Speaker Resistance	3.5Ω ± 0.2Ω
Frequency Response	20Hz ~ 20K Hz
Frequency Range	20Hz ~ 20K Hz
Packing List	
1	Bluetooth headphones
1	USB Charging Cable
2	User Manual
4	Certification
Charging cable	5ft
Working range	30 - 40m
Charging contact	UA
Charging port	3.1
Warm Tips	
1. If you can't connect the headphones after 10-15 seconds, try a longer time to charge the headphones.	
2. When the headphones have not been used for more than 3 months, there may be a short delay when connecting.	
3. If the headphones do not work well, please turn off the headphones and turn them back on again.	
4. If there was not a long time, we suggest you change every 3 months to ensure the headphones work well.	
5. We suggest you fully charged the headphones for the first use.	

Attention:

- 1. Please keep or use the Headphone in normal direct sunlight.
- 2. Please do not leave the Headphone away from fire or heat.
- 3. Please keep the headphone away from smoky or smelly environment.
- 4. Please don't try to use other method for charge battery.
- 5. Please do not use headphones in water.
- 6. Please don't disassemble, heat or modify.
- 6. Please pay attention to excessive usage if you feel uncomfortable, please stop using it immediately and seek medical help.
- 7. If the headphone produces an abnormal and normal temperature, color or shape changes about the earcup, please stop using it and contact us via our customer service and turn to us for help via our website, your warranty will be void.

⚠ Warning

- 1. Please do not use headphones when you walk or drive the bicycle.
- 2. It is recommended to be aware of the same type of headphones or similar products may have different performance characteristics due to the construction such as weight, volume, frequency response, etc.
- 3. Please do not use headphones when you are driving a vehicle, riding a bicycle, walking, cycling, riding a motorcycle, etc.
- 4. Please do not use headphones when you are swimming, diving, or any activity that may need to be accompanied by them.
- 5. Using headphones at high volume for long periods of time may damage to your hearing.