

Changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to

This equipment has been tested and found to comply with the

protection against harmful interference in a residential

radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

guarantee that interference will not occur in a particular

the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

that to which the receiver is connected

installation. This equipment generates uses and can radiate

interference to radio communications. However, there is no

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

the equipment off and on, the user is encouraged to try to correct

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from

- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is

limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

operate the equipment.

Wireless Charging Status	Wireless Charging Indicator Status	Display Instruction
Wireless charging the phone	•	Blue light stays on
After removing the phone from wireless charging	•	Blue light will turn off within 3 seconds
When there is a Foreign Object Detection (FOD) in wireless charging	*	Blue light flashes quickly for 10 seconds
oreign object (FOD)	less charging output i is detected, the blue Il continue to flash 10 er it is removed.	light of the wireless
Attentions		

chargers.

slower the charging speed will be.

on the wireless charge

Safety Significant Matters

When using this product, basic precautions should always be followed, including the following:

01. Please store this product in a cool and dry place.

02. You cannot wirelessly charge your device in the following situations: a. using a case with a magnetic / iron plate; b. using a case with a foldable handle and bracket; c. using an ultra-thick (> 2.5 mm) protective phone case.

0°C-35°C /32°F-95°F

USB-C Ladekabel x 1, Benutzerhandbuch x1

n. Das Foto ist für referenz, b

Powerbank × 1,

ter stammen aus dem Labor von TORRAS. Der eter würde sich aufgrund von Produkten und

33

Lieferumfang

Die obigen Param tatsächliche Paran

Sie sich auf das pro

05. Do not disassemble the product. Take it to a qualified 04. Do not use an adapter with an output of 5V=1A (5W) or service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons. 05. Wireless chargers make charging more convenient than 06. For safety reasons, please do not drop the product. Do not wired chargers, but due to current wireless technology limitations, the charging speed is slower than wired use this product in high temperature or humid environments to prevent short circuits. 07. During charging, this product may generate heat. This is normal, please do not worry. If overheating occurs, please stop using it temporarily. 06. High temperatures can reduce charging speed and limit power, which is a common issue with all wireless chargers. It is recommended to charge your device in environments with temperatures below 25°C / 77°F. 08. After fully charging, please unplug the charger plug in a timely manner to avoid damaging the battery due to 07. The phone case and the position of your device on the prolonged charging. wireless charger will affect the charging speed. The further the device is from the center of the wireless charger, the 09. In normal conditions, the battery performance will decline over several years. 08. For optimal charging performance, align your smartphone with the coil in the center of the wireless charger. If the charging icon does not appear on your smartphone, adjust its placement. Ensure the smartphone is always centered 10. Do not place the product in high temperatures or fire. Avoid

exposing the product to environments with temperatures exceeding 40°C, as this may result in overheating, fire, or If the power bank emits any unusual smell, overheats, changes color, or deforms, please stop using it immediately.

5%-1%

Hinweis: Beim Aufladen von Geräten im Wireless-Ladeanzeige erlischt

35

0% • • • • Alle fünf Lichter aus

die blaue LED der drahtlosen Ladeanzeige (Erste blaue LED)

erlöschen.

Erste blaue LED erlöschen, zweite,

Erste blaue LED erlöschen, zweite, dritte, vierte und fünfte weiße LEDs leuchtet konstant.

34

dritte und vierte weiße LEDs leuchtet konstant, und fünfte weiße LED blinkt.

-99% **●** ○ ○ ○ ☆

100%

12. Do not use harmful chemicals or detergents to clean this

13. Misuse, dropping, or excessive abrasion may cause product 14. Do not damage or puncture the casing of the power bank. This may cause overheating, fire, or explosion.

Caution

This product is equipped with a built-in lithium battery, and please pay attention to the followings: 01. Please charge the product in time when the battery is low. If the product is not used for long periods of time, charge and discharge it once every three months to prevent battery

damage. 02. Do not disassemble, hit, squeeze, or throw into fire, If severe swelling occurs, stop using it. Do not place it in high temperature environments. If the battery life significantly shortens, stop using it and seek professional maintenance 03. If the wrong type of battery is used, there is a risk of explosion, fire, etc.

04. The battery (battery pack or assembled battery) should not be exposed to high temperatures such as direct sunlight or

05. Products containing built-in batteries should be separated from household waste when discarded. Take this product to an appropriate waste collection center for recycling and do not discard it casually.

06. When disposing of used batteries, keep batteries of different electrochemical systems separate from each other.

07. Note that a discharged battery may cause fire or smoke. Insulate the terminals with tape.

All products bearing this symbol are waste electrical and

electronic equipment which should not be mixed with unsorted household waste. Instead, you should protect human health and

the environment by handing over your waste equipment to a

and electronic equipment, appointed by the government or la authorities. Correct disposal and recycling will help prevent

human health. Please contact the installer or local authorities

for more information about the location as well as terms and conditions of such collection points.

operating in conjunction with any other antenna or

potential negative consequences to the environment and

FCC RF Radiation Exposure Statement: 1. This Transmitter must not be co-located or

2. This equipment complies with RF radiation

exposure limits set forth for an uncontrolled

transmitter

designated collection point for the recycling of waste electrical

ment or local

JP 製品概要 1....1 12 3 (4) 0000- ワイヤレス充電のインジ (2)バッテリー残量インジ ケーターライト (白) ケーターライト (青) ④ USB-Cポート ③電源ボタン ⑥ 隠しリングスタンド ⑤ワイヤレス充電エリア

自由な充電体験


本製品は、持ち運びやすい、隠しリングスタンド付き、ワイヤレス充 電にも可能な小型のモバイル電源です。充電方式は三つある。そ れぞれは、磁気吸着ワイヤレス充電(iPhone12以上のモデル)、一 般的なワイヤレス充電(その他のワイヤレス充電対応のスマートフ ォン)と有線充電の3つの充電モードです。お好みの充電モードが 自由に選択できる以外、デスクトップスタンドとしても使用できる。 快適且つ自由な充電体験をお楽しみ。

① スタンドが折りたたみ式を ② 畳んでいるスタンドを出 採用して、通常のワイヤレス すと、スタンド式充電器と 充電対応できます。 して利用できます。



① 回転角度は120°となるスタンドは本体をしっかり支えて、お客さ

まの両手を解放します。



07. Beachten Sie, dass entladene Batterien Feuer oder Rauch

39

entsorgen.

16. Verwenden Sie Original- oder zertifizierte Datenkabel.

Wenn das Ladegerät angeschlossen ist, verwenden Sie ein zertifiziertes und den Standards entsprechendes Ladegerät.

38

verursachen können. Isolieren Sie die Pole mit Klebeband.



Email: support@torraslife.com

物料编码	3: YTPI01225A	物料名称: 图拉斯1 支点Q	系列移动电源(10000mAh)	说明书		
	材 质:银禾祥合100克	本白双胶纸	单 位: mm		印刷颜色: K	LOFFAN DESIGN
	成型尺寸: 60*90mm		刀 线: ———		表面工艺:双面印刷,单黑;啤;骑马钉(单钉,44P)	
结 构	结构设计:黄从峰		压 线:	 面	平面设计:莫淞下	
部分	结构修改:		针刀线:	 分	平面修改:	
	日 期: 2023.8.16		刀线相交:		日 期: 2024.07.30	
	备 注:		坑 纹:		备 注:	

b. eine Hülle mit klappbarem Griff und Ständer verwendet wird

C eine extern diese (z.2.min) na vyriate termende mit.
03. Legen Ste bitte keine Fremklörper auf die Oberfläche des Geräts und des kabellosen Ladegeräts, einschließlich Metalkissen auf dem Armaturenbreit, Kreditkarten, Türschlüssel, Münzen, metallische Gegenstände der NFC-Karten, da dies zu einem Ausfall oder Überhitzung des kabellosen Ladegeräts führen kann.

04. Verwenden Sie keinen Adapter mit einer Ausgangsleistung von 5V----1A (5W) oder weniger.

36

c. eine extrem dicke (>2,5mm) Handyhülle verwendet wird.

02. Bewahren Sie das Produkt nicht an Orten mit hohen Temperaturen

03. Verwenden Sie das powerbank nicht nachdem es nass geworden ist.

04. Der Einsatz von nicht vom Hersteller empfohlenen oder verkauften

Stromquellen oder Ladegeräten kann zu Brandgefahr oder Verletzungsrisiken führen.

05. Öffnen Sie das Produkt nicht. Wenn das Produkt gewartet oder

repariert werden muss, übergeben Sie es bitte an Fachpersonal. Falsche Montage kann zu Brandgefahr oder Personenschäden führer

37

oder hoher Luftfeuchtigkeit auf.