




| ERAZER Invested by Lenovo | Specification of Product | Welcome to ERAZER Wireless Earbud | How to wear headphones correctly | Product Description | Touch Operation | Indicator Light Description | Once Press | Long Press | Triple Press | Clear Bluetooth pairing history |
|--|--|---|---|---|---|--|--|--|---|--|
|  <p>ERAZER Wireless Earbud XT62PRO Product Manual</p> | <p>Item list</p> <ul style="list-style-type: none"> Headphones x 2 Charging case x 1 USB cable x 1 Charging cable x 1 | <p>Take out and pair it</p> <p>When using for the first time, take out the left and right headphones from the charging case. The blue light of the earphones flash alternately, indicating that the earphones have started pairing mode.</p> | <p>1</p>  <p>2</p>  | <p>Bluetooth LED</p> <p>Half function key touch sensor</p> <p>Charging Case</p> <p>Charging Indicator</p> <p>Type Battery</p> | <p>Connect with Bluetooth device</p> <p>Open the Bluetooth settings of the Bluetooth device to be paired, select the device name of the headphones, and then the connection is successful. When the connection is successful, the headphones will be in the charging case.</p> | <p>Power On</p> <p>When the headphones are taken out of the charging case, the headphones will be powered on. When the headphones are taken out of the charging case, the headphones will be powered on. When the headphones are taken out of the charging case, the headphones will be powered on.</p> | <p>Music mode</p> <p>Phone mode</p> <p>Double Press</p> <p>Music mode</p> <p>Phone mode</p> | <p>Wake up voice assistant</p> <p>When using both sides, press and hold the left ear microphone button for 3 seconds to activate the voice assistant. When using both sides, press and hold the left ear microphone button for 3 seconds to activate the voice assistant.</p> | <p>Game mode</p> <p>Music mode</p> <p>Press and hold the left ear microphone button for 2 seconds to activate the game mode. Press and hold the left ear microphone button for 2 seconds to activate the game mode.</p> | <p>Wireless pairing mode</p> <p>When both sides are taken out of the charging case, the headphones will be in the pairing mode. When both sides are taken out of the charging case, the headphones will be in the pairing mode.</p> |

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.