



Quick Start Guide



tracker
+ Safe & Found

Thank you for purchasing Tracker + Safe & Found! Please follow these simple but important instructions for optimal use of your new tracker.

1. Getting to Know Your Tracker



Power button:	Press and hold for 5 secs to turn the device on. Press and hold for 20-23 secs to reset factory defaults. Quickly press 3 times to activate the Alert button.
Speaker:	Alerts the user with a beep sound when the light sensor detects changes, or when the Find My Device feature is enabled.
Light sensor:	Ability to detect changes in light.
Magnetic charging terminals:	Charge your device via the included USB cable and travel adapter.
LED indicator:	Display the current status.
● Solid yellow:	Battery charging
● Solid green:	Battery fully charged
(●) Blinking red:	Low battery or alert
(●) Blinking green:	Pairing mode
(●) Solid green for 2s:	Paired
● Solid red:	Received Find My Device command
● No light:	Standby

2. Charging the Battery

- Align the magnetic charging terminals of the USB cable with the magnetic charging terminals on the back of the device. They will be automatically aligned.
- Once those are aligned, connect the USB end to the travel adapter.
- Connect the travel adapter to an electrical outlet to fully charge the device.
- The LED indicator will light up when charging.



Power Tracker On & Off


To turn the device on, press and hold the **Power button** (5 secs) until the LED indicator blinks red, yellow, green, then release the button. A beep will indicate device is powered on.

Wait until the LED indicator blinks green (could be up to 5-10 mins). You are now ready to pair your device using the Safe & Found app.

To turn the device off, press and hold the **Power button** (5-15 secs) until the LED indicator blinks red, yellow, green.

3. Installing the Safe & Found App and Creating A Tracker Account

If you already have the Telus Safe & Found app, skip to step 4. If you don't have the Telus Safe & Found app yet, visit Google Play or App Store to download and install Safe & Found.



Note: Once Safe & Found is installed, follow the instructions on screen to set up your Safe & Found account.

4. Connecting Your Tracker to Your Safe & Found Account

Once in the app, you can add one or more Trackers to your Safe & Found account by following the simple steps outlined within the app.



5. More Information

- For more information on device features, how to access advanced app services and personalize your overall experience, visit www.telus.com/tracker or www.telus.com/tracker-faq. Additional information may also be found at www.coolpad.us.
- For coverage maps check www.coverage.telus.com.

Trademarks and Copyrights

©2019 Coolpad Technologies Inc. Coolpad and the Coolpad logo are registered trademarks of Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd. All rights reserved. Other trademarks and trade names are the property of their respective owners. Screenshots and product images are simulated; they may differ from the actual product and are subject to change. Reproduction, transfer, distribution of the contents herein in any manner without the prior written permission of Coolpad Technologies, Inc. is prohibited. Coolpad Technologies, Inc. reserves the right to add, modify or delete, any of the contents herein or withdraw this documents at any time without prior notice and without assigning any reasons thereof.

©2019 Telus. All rights reserved. Telus and the logo are trademarks of Telus.