



Operating Instructions for Smart Watch Product



A: First of all, please be sure to connect our smart watch through the "FitCloudPro" APP.





B: Perform the following steps to enable the answer/call function.




If you don't need to use the call function, you can turn off the answer/call function so that the battery can last longer.

◆ Appearance Description



◆ Introduction to Watch Function



Exercise: Click on the icon on this page to access the multiple sport modes option. Select a sport mode, click the icon to start, and slide right to pause or stop the sport.

1.No charging with water stains.
2.This product is an electronic monitoring product, not for medical use, and the measurement data is for reference only.
3.It is not recommended to wear in hot water baths and longtime swimming.
4.Please charge with the matching charging cable.



Weather: Display the local weather conditions. Connect the synchronization APP for normal use, and open the phone GPS to ensure that the APP gets the positioning permission function and network connection.



FAQ: Problems such as the watch cannot be searched in the APP, or the watch cannot synchronize with the time of the phone.



Answer: If the phone turns on the message notification and the corresponding notification permission according to the above tips, the Bluetooth is kept on, and the APP and the watch are kept connected, maybe the system authorized APP alert function is not working, and the user needs to re-check the message push function.



4. Android's phone Bluetooth often disconnects or has no message alert after a period of connection.



Answer: Android will from time to time clean up the phone's backstage applications or applications that consume more power for smooth system operation. If the APP is not set to allow backstage running, it will be easily cleaned by the system and the Bluetooth will drop out. Different Android phones have different methods for APP backstage running settings. As in the Huawei nova 8 SE: Settings - Battery - Power Consumption Ranking - APP - Application Launch Management - Manually manage to turn on backstage running.

◆ Schematic Diagram of Charging

Operate in strict accordance with the following figures:

1. Please use the product-specific magnetic charging cable to charge by aligning it with the charging contacts on the back of the watch.

2. Do not use a power adapter with a voltage exceeding 5V and an output current exceeding 1A for charging, as this may cause charging failure and damage to the magnetic charging cable or the device.

3. Please activate the watch when it runs out of power before charging: the watch screen will only light up after about 5 minutes of normal charging.

Main interface: Display the current time, date, steps and other information of the watch; press the main interface for a long time to switch the main dial left and right, and click to confirm.

Music: After connecting the APP, the watch can control the mobile phone player to play/pause/switch to the previous song and the next song. This function must be opened on the mobile phone player before it can be controlled on the watch. This function requires staying connected to your phone and turning on the notification push permission.

Call function: Click the call switch. Open the phone settings - Bluetooth - search connection Bluetooth T90 -xxxx to play mobile music or make/receive calls, etc.

Steps: Display current steps, distance and calories of the watch.

Stopwatch: Click on the icon to start the function, and click Start for timing, pause or reset. Slide right to leave.

Heart rate: Slide to this page and keep a while and automatically measure the current real-time dynamic heart rate. Connectable to APP to set real-time monitoring and view data records.

Search: Click this icon, your phone will beep to indicate the orientation of your phone, this function requires your phone to stay connected with the watch APP. No alert on the phone in silent mode.

Blood oxygen: Slide to this page and keep a while and automatically measure the current blood oxygen data and vibrate to indicate the result.

Connection succeeded

Service email:amazon.seller9966@gmail.com

◆ Precautions

3. The reminder switch is turned on, but there is no reminder on the watch, or the reminder is sporadic.

Answer:

If the phone turns on the message notification and the corresponding notification permission according to the above tips, the Bluetooth is kept on, and the APP and the watch are kept connected, maybe the system authorized APP alert function is not working, and the user needs to re-check the message push function.

FAQ: The watch can receive cell phone calls, SMS, QQ, WeChat and other notification alerts, which can be set according to the message alert and turn on the corresponding push switch on the APP. This page can store up to 15 message records. This function needs to stay connected with the phone and make sure the APP gets the corresponding permission.

Answer: A. Make sure your phone's Bluetooth and phone GPS positioning are on before using it for the first time.

B. Users need to open the APP to obtain positioning permission (Phone Settings - Applications).

C. If the watch has already been paired with a Bluetooth connection in the phone, please cancel the pairing first and then search for the connection in the APP.

"To pair with: T90", please select pairing.

The watch connection operates as follows:

Open the APP and make settings according to the prompt

▼


Select the name of the searched Bluetooth: T90

▼

Connection succeeded

Mode d'emploi de la montre de sport intelligente

A: Tout d'abord, assurez-vous de connecter notre montre intelligente via l'application "FitCloudPro".



Effectuez les étapes suivantes pour activer la fonction réponse/appel.



Si vous n'avez pas besoin d'utiliser la fonction d'appel, vous pouvez désactiver la fonction de réponse/appel afin que la batterie puisse durer plus longtemps.

◆ Présentation de l'apparence



◆ Schéma de principe de charge

Procédez exactement comme indiqué sur le schéma ci-dessous:

Effectuez les étapes suivantes pour activer la fonction réponse/appel.

1. Veuillez viser les contacts de charge à l'arrière de la montre pour charger avec le câble de charge magnétique spécifique au produit.

2. Ne pas charger à l'aide d'un adaptateur secteur avec une tension supérieure à 5V et un courant de sortie supérieur à 1A, sinon cela entraînera une panne de charge et endommagera le câble ou l'appareil de charge magnétique.

3. Si vous chargez la montre après qu'elle soit hors tension, vous devez d'abord l'activer : l'écran de la montre s'allume après une charge

4. Une fois connecté, vous pouvez utiliser la montre pour répondre/passer des appels à tout moment.

Si vous n'avez pas besoin d'utiliser la fonction d'appel, vous pouvez désactiver la fonction de réponse/appel afin que la batterie puisse durer plus longtemps.

◆ Présentation de la fonction de montre

Exercice: Appuyez sur l'icône pour accéder à l'option de mode multisport, sélectionnez un mode sportif, appuyez sur l'icône pour démarer et balayez vers la droite pour mettre en pause ou arrêter l'exercice.

