

# SOUNDCHARGE

Bluetooth® Speaker and Alarm Clock  
with Wireless Charger



### Package Includes:

- Soundcharge Alarm Clock
- USB power cable
- User manual

USER'S MANUAL FOR MI-WCR01

### Power Connection:

- Plug the alarm clock in using the included USB-C cable to a USB power source.  
**Note:** To use fast wireless charging, the product must be powered using a USB power adapter with Quick Charge 3.0 Technology.

### Wireless Charging:

- You can charge your smartphone with a protective case on it. (Works with most cases up to 4mm thick.)
- If your protective case has metallic studs, magnetic clasps, or a magnetic plate, you must remove the case before placing your phone on the pad.
- Also ensure the protective case does not create distance between the charging pad and the back of the phone that is greater than 4mm.

### Charging:

- Your smartphone will automatically begin to charge when placed on the Wireless Charger.
- For optimum charging, place your mobile phone in the center of the Wireless Charger.
- When it's charged, the red light will be on. When fully charged, the light will be off.

### LED Status Indicator:

- No Light: Standby.
- Breathing Light: Device is charging properly.
- Slow Flashing Light: Foreign object detected. Charging is disabled.


### Fast Charging:

- The wireless charger supports outputs of up to 15W (Fast Charging).
- To enable fast charging for your compatible device the wireless charger must be powered by a USB charger with Quick Charge 3.0 Technology (5V/3A, 9V/2A, 12V/1.5A).

### Ambient Light Settings:

- Press the Light button once to turn on the ambient light. Continue to press the Light Button to toggle through the various LED colors and lighting effects or to turn off the ambient light.
- Double Click the Light Button to select Medium LED Light Intensity.
- Double Click the Light Button again to select Low LED Light Intensity.
- Double Click the Light Button again to select High LED Light Intensity.

## DETAILED INSTRUCTIONS AND DIAGRAMS



### Control Button Panel:

- |                |               |                |
|----------------|---------------|----------------|
| ❶ Power Button | ❷ Mode Button | ❸ Clock Button |
| ❹ Down Arrow   | ❺ Up Arrow    | ❻ Light Button |

**Power Button:** Press and hold for 2 seconds to power the device on/off.

### Bluetooth® Mode:

To enter "Bluetooth® mode", press the Mode Button and you will see a Bluetooth® indicator light flashing on the front of the speaker, proceed to your Bluetooth® enabled device settings and search the pairing name: MERKURY WCR01 and connect it to your device.

### To control the speaker volume and track selections:

- Press the down arrow once to lower speaker volume; Press and hold the down arrow to advance to next track.
- Press the up arrow once to raise speaker volume; Press and hold the up arrow to return to previous track.

If you don't hear any audio, press the up arrow to increase the speaker volume.

### Time, Date, and Alarm Settings:

- Press the Clock button once to enter the clock settings mode.
- You will see the year flashing on the clock, press the up or down arrow to select the desired year.
- Press the clock button again to select the month and use the up or down arrow keys to select the desired month.

- Press the clock button again to select the hour and use the up or down arrow keys to select the desired hour.
- Press the clock button again to select the minutes and use the up or down arrow keys to select the desired minutes.
- Press the clock button again to select the alarm hour and use the up or down arrow keys to select the desired alarm hour.
- Press the clock button again to select the alarm minutes and use the up or down arrow keys to select the desired alarm minutes.
- Press the clock button again to select the alarm on or off function and use the up or down arrow keys to select if you want the alarm on or off.
- Press the clock button again to exit the clock settings mode.

When the alarm rings, simply press any button to turn off the alarm. If no button is pressed to turn off the alarm, the alarm will continue to ring for 1 minute and then shuts off automatically.

### Please note:

- In normal display mode you can turn the alarm function on or off by pressing and holding the clock button for 2 seconds.
- To switch between a 12H or 24H clock display: simply press the down arrow while in normal display mode to toggle between a 12H or 24H clock.
- To switch between Celsius or Fahrenheit Temperature display: simply press the up arrow while in normal display mode to toggle between Celsius or Fahrenheit temperature.

### FCC Warning Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### RF Exposure Statement (Bluetooth)

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### RF Exposure Statement (Wireless charger)

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body.

### Technical Support:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have.

For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkurs Innovations technical support:

Merkury Innovations  
45 Broadway, 3rd Fl  
New York, New York 10006  
www.merkuryinnovations.com  
E-mail: support@merkursinnovations.com

### Technical Specifications:

Input: 5V/3A, 9V/2A

Wireless Output: 5W, 7.5W, 10W, 15W

©2024 Merkurs Innovations, LLC.

To explore our full selection of products, visit us at: www.merkuryinnovations.com

iPhone is a trademark of Apple Inc., registered in the U.S. and other countries.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. All other trademarks and trade names are those of their respective owners.

Made in China.