

Product description

HV-BT018 is a Bluetooth adapter combining transmitter and receiver function. It can help transmitting music from your phone, music player, TV or computer to your Bluetooth receiver, stereo Bluetooth headset or Bluetooth speaker when it is used as Bluetooth transmitter. It can also be used as stereo Bluetooth headset when in Bluetooth receiver mode (only need to plug the audio cable into the 3.5mm port) or transmit wireless audio signal by connecting speakers.



- A, Micro USB charging port
- B, 3.5mm Aux-in
- C, Slide option _Receiver
- D, Slide option _Transmitter
- E, LED Indicator
- F, Multi-function button

Product specification

Product No.	HV-BT018
Bluetooth Version	V4.1
Chip	CSR8670
Frequency Range	2.402GHz-2.480GHz
Working Time for Receiver Mode	about 14 hours
Working Time for Transmitter Mode	about 14 hours
Charging Time	about 2 hours
Profile Supported	A2DP
Support dual stream (transmitter mode)	Support one transmitter connects two Bluetooth speakers or headsets (using the same CODEC)
Support multi-point connection (one for two receiver mode)	Support connecting two phones simultaneously
Password for Bluetooth headsets, Bluetooth receiver, Bluetooth speakers	0000, 1111, 1234, 8888
CODEC	Ordering: APT-X (first) ; SBC (second)
Notes for APTX	Support APTX 48kHz CODEC in priority when singly connected (headset or speaker should also support APTX). Automatically switch to SBC CODEC when doubly
Battery	280 mAh rechargeable lithium battery
Charging power	5VDC, 100-240V AC adapter, ≥300MAH
Working temperature	-10—55℃
net weight	about 21g
size	ø49X13MM

TX mode:

1. Charge it via the USB port till the red light turns off. After charging the unit, push to "TX", hold down the MFB button till it flashes blue. Turn on your Bluetooth device and after about three seconds the transmitter button light will turn a solid blue. This indicates the pairing is successful.
 2. Insert the 3.5mm audio cord into the 3.5mm audio port of the transmission devices.
 3. Long press for 3s to turn off.
- Note: 1) Once push to TX mode, all the paired device information of RX mode will be cleaned up. TX/RX mode switching cannot be conducted within 3s after powering off.
- 2) The password for pairing: "0000", "1234", "1111", "8888". (Generally, the password is not needed.)
4. Connect two Bluetooth devices simultaneously while working as a Bluetooth transmitter.
- 1) After paired the first Bluetooth device, please turn off the Bluetooth function of the first one. (If it don't automatically enter the Bluetooth pairing status, Double press the MFB button) then pair to the second Bluetooth device.
- 2) Power off HV-BT018 and turn on the Bluetooth function of the first device. Then power on HV-BT018, it will connect two devices automatically. Then connect it to the output devices.
5. Low battery:
Red LED light flashes quickly. If the voltage is below 3.1A, it will automatically turn off.

RX mode:

1. Charge it via the USB port till the red light turns off. After charging the unit, push to "RX", hold down the MFB button till it flashes blue and red alternately. Turn on your Bluetooth device and after about three seconds the transmitter button light will turn a solid blue. This indicates the pairing is successful.
 2. Insert the 3.5mm audio cord into the 3.5mm audio port of the receiving devices.
 3. Play/Pause: Short press the MFB button.
 4. If you want to play music from another device, you should stop the currently playing music. (For example, if connecting with two phones, control the music playing on the phones.)
 4. Long press for 3s to turn off.
- Multi-point connection when used as receiver:
- Turn on your first phone and get it into pairing mode.
 - Pair HV-BT018 with your first phone follow the steps mentioned above.
 - Deactivate Bluetooth function of your first phone after successful connection. Double click the MFB to get HV-BT018 into pairing mode.
 - Pair HV-BT018 with your second phone.
 - Turn off HV-BT018 when it successfully connected with your second phone. Reactive Bluetooth function of your first phone before you restart HV-BT018.
6. Low battery:
Red LED light flashes quickly. If the voltage is below 3.1A or lose connection for 6 min, it will automatically turn off.
- Note: If connection is not successful, pls retry according to the steps.



WWW.PROHAVIT.COM MADE IN P.R.C

OWNER'S MANUAL



Bluetooth receiver and emitter

Model: HV-BT018

FCC NOTE

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.