

Product Name:Bluetooth Speaker

Model name:M3

Brand Name:AOMAIS

If you have any question please contact with our support

Customer Service Email:Support@aomais.com

Tool Free:833-4AOMAIS(833-4266247)

AOMAIS


AOMAIS

LIFE

Quick Start Guide

Designed and Engineered By aomais

www.aomais.com



Support@aomais.com

12-month limited warranty

Lifetime technical support

Your Bluetooth device may be out of range, move closer within 66 unobstructed feet

Turn your AOMAIS LIFE off and back on.

No audio playing from the speaker when connected with the 3.5mm audio cable

Make sure the 3.5mm audio cable is fully inserted the AOMAIS LIFE and device.

Make sure your device is on and playing music.

Increase the volume level on the AOMAIS LIFE and device.

Poor sound quality when connected over Bluetooth

Your Bluetooth device may be out of range, move closer within 66 unobstructed feet.

Remove the AOMAIS LIFE from the Bluetooth device list on you source device, and then re-pair and connect to the speaker.

Turn your AOMAIS LIFE off and back on.

Some devices need to have their WIFI turned off to improve audio quality over Bluetooth.

Poor sound quality when connected within the 3.5mm audio cable

Reduce the volume level on the AUX source.

Remove the charging cable while playing.

Page25

The speaker can be paired with only one device at a time. Meaning if you would like to pair the speaker with a second different device, you must cut off the pairing between device and the speaker.

Check that your AOMAIS LIFE has a sufficient battery charge, the speaker may not connect when the battery has a low charge.

Connect the speaker to a charging source and try again pair and connect.







Your device may be out of range. Move it closer to within 66 unobstructed feet of your speaker.

Some older windows computers and operating systems may have difficulty pairing and connecting over Bluetooth. If this occurs it is recommended to connect using the 3.5mm audio cable.

No audio playing from the speaker when connected over Bluetooth

Remove the AOMAIS LIFE from the Bluetooth device list on you source device,and then re-pair and connect to the speaker.

In The Package



Page24Page1

Buttons and Connectors

1.Power button

2.TWS button/Play/Pause

3.Volume up/Next track

4.Volume down/Previous track

5.Transform button


6.Function button LED1

7.Battery charging LED2

8.Mobile power port

9.USB charging port

10.3.5mm port



Page2

Troubleshooting & Customer Support

For assistance with the questions or any issue with your AOMAIS LIFE that is not answered in the troubleshooting tips below,please contact us by visiting: AOMAIS.com/contact and sent the mail to our customer service.

Can not turn on

The battery may have become fully drained.Charge the AOMAIS LIFE use wall charge from a Smartphone/iphone,then press power button to turn the speaker on.Then continue charging the battery.

Can not pair or connect to Bluetooth

Check the Bluetooth LED light (Blue) to make sure it is quick flashing.If it is blue light the AOMAIS LIFE is already connected to another source device.

Page23

Safety and Precautions

Follow all instructions-All operating and use instructions should be followed.

If not use the device for long time,to protect the battery life, please full charge the Speaker and keep it always powered .

Protect the Micro USB charging cable from pinched particularly at the connectors.








Unplug the USB charging cable during storms or when unused for long periods of time.

Specifications:


Model: AOMAIS LIFE	Audio Output: 30W
Size: 11. 93*3. 74*2. 99 inch	Range: 20m/ 66ft
Weight: 3. 07 lb	Input: 5V/ 2A
Bluetooth Version: V4. 2	THD: 1% Volume max
Main Material: Bamboo	Charging Time: 3. 5 hours
Battery Capacity: 5000mAh lithium battery	Play Time: 10 hours (50% Volume)

Page22Page3

Button Function Description



Notice






For the first time, the volume of the speakers defaults to 60% of the volume.

After the first use the speaker will remember the volume used last time.

Page4Page21

Notice



LED Light is quick flashing (Red) when low battery.

LED Light is Red when charging.

LED Light is turn off when full battery.

Turn on the speaker and not connected with Bluetooth.

The speaker will NOT turn off automatically.

The speaker is connected with Bluetooth and not playing the music.



The speaker will NOT turn off automatically.

Number	Function	Instructions	Seconds	Current status
1	Power On	Power Button	2s	Power on
2	Power Off	Power Button	0. 5s	Power off
3	Volume +	Volume -	0. 5s	Music playing
4	Volume -	Volume +	0. 5s	Music playing
5	Bluetooth	Bluetooth Button	0. 5s	Music playing
6	Play / Pause	Volume -	2s	Connection Status
7	Previous Track	Volume +	2s	Connection Status
8	Next Track	Bluetooth + Vol-	2s	Bluetooth is connected
9	Into the Pairing State	Bluetooth + Vol-	10s	Pairing status
10	Clear Pairing List	Bluetooth Button	2s	connecting
11	TWS into the Pairing	Bluetooth Button	2s	TWS connection
12	Disconnect TWS	Vol+ and Vol-	2s	TWS connects and plays music

Switch Mono and Stereo

Page20Page5

Pairing&Bluetooth




1.Turn on the bluetooth of the speaker and the phone.

2.Search for Bluetooth Model "AOMAIS LIFE" from your device list then pair with your device.

3.The audible blue light will be on all the time when the pairing is successful.

Notice





Please pay attention to protect the speaker's horn.

If you accidentally press the horn into the speaker, you can use a transparent tape to restore it to the original state.


Page6Page19

Notice





Note: Please remember don't drop the speaker in the water.

Stereo Pairing&Connecting





turn on the two speakers and press the Bluetooth button for two speakers at the same time when Red and blue lights flash.






Turn on your device, pairing with the speaker





successful





Start your music party

Note: The LED flashes slowly (blue) is the main speaker. The LED is a blue light and does not flash speaker is slave speaker.


Note: Please turn off your bluetooth of your device before stereo pairing 2 speakers.

Page18Page7

Distance



Notice



LED1 LED2

LED1 is just a function indicator.

In the AUX mode LED1 is red.

LED2 is the power status indicator.






When the battery is low, LED2 is the red light flashing state.

LED2 is a red light during charging.

LED2 is turn off the red light when the full charge.

Page8Page17

Notice




WARNING: Please don't charging the speaker when it in wet condition, otherwise it will lead the battery burned

Plugged in for charging, please far away from water.

If you have any question please contact with our support Email:

Support@aomais.com


Mono/Stereo



Press the Volume "-" and Volume "+" you can change the Mono or Stereo mode.It is useful in a TWS (two speakers are paired) situation.


Page16Page9

EQ Button



3 EQ modes: With unparallelled three EQ modes , three modes (Classic, Party & Surround) enhance any music style and occasion.

Notice




Please use the USB date cable to charge the speaker.


Do not use USB date cable to charge the computer and other equipment.

Page10Page15

Use adapter charging just only 3 hours.



Bluetooth Connect




The speaker will automatically to connect with the last source device.

If you want to pair or connect to other source device you can press the Bluetooth and Volume - button for 4s to disconnect the current paired device.


Page14Page11

Audio Cable Mode



You can play with your Apple Mac,Laptop,Computer and non-Bluetooth devices with the 3.5mm audio cable.

Power Bank



The built-in 3.7V/5000mAh battery even turns the speaker into a cable power bank so you can charge smartphones, tablets, or other devices that need a boost.

Page12Page13

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.