





External antenna connection position
(3 places)

- EXT-ANT1
- EXT-ANT2
- EXT-ANT3



Label



External antenna

Controller