

Brand Name: ZEBRA / Model Name: TC83B0




Brand Name: ZEBRA / Model Name: TC83B0



Brand Name: ZEBRA / Model Name: TC83B0



Brand Name: ZEBRA / Model Name: TC83B0



2. Photograph of Accessory

Brand Name: ZEBRA / Model Name: TC83B0

Specification of Accessory		
Battery 1	Brand Name	Zebra
	Part Number	BT-000380
Battery 2	Brand Name	Zebra
	Part Number	82-176054-01
Headset 1	Brand Name	Zebra
	Part Number	HDST-35MM-PTVP-01
Audio adapter cable 1	Brand Name	Zebra
	Part Number	CBL-TC8X-AUDBJ-01
Headset 2	Brand Name	Zebra
	Part Number	HS2100-OTH
HS2100 to Quick Disconnect Cable	Brand Name	Zebra
	Part Number	CBL-HS2100-QDC1-01
Audio adapter cable 2	Brand Name	Zebra
	Part Number	CBL-TC8X-AUDQD-01
Hand Strap	Brand Name	Zebra
	Part Number	SG-TC8X-HDSTP-01
USB Cable	Brand Name	Zebra
	Part Number	CBL-TC8X-USBCHG-01
Holster 1	Brand Name	Zebra
	Part Number	SG-TC8X-QDHLST-01
Holster 2	Brand Name	Zebra
	Part Number	SG-TC8X-PMHLST-01
Adapter	Brand Name	Zebra
	Part Number	PWR-BUA5V16W0WW
DC Line Cord	Brand Name	Zebra
	Part Number	CBL-DC-383A1-01

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: ZEBRA / Model Name: TC83B0



Brand Name: ZEBRA / Model Name: TC83B0

Battery 1



Brand Name: ZEBRA / Model Name: TC83B0



Brand Name: ZEBRA / Model Name: TC83B0

Battery 2



Brand Name: ZEBRA / Model Name: TC83B0



Brand Name: ZEBRA / Model Name: TC83B0

Audio adapter cable 1



Brand Name: ZEBRA / Model Name: TC83B0

Audio adapter cable 2



Brand Name: ZEBRA / Model Name: TC83B0

USB Cable



Brand Name: ZEBRA / Model Name: TC83B0

Adapter

