

US UK

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.

2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

O.S. Support

Windows XP/ Vista/ Win 7/ Win 8/ Win 10/ Win 11 / Mac O.S.

How to connect the keyboard with multi-ple devices

Type C port


2.4G receiver storage slot

2.4G/OFF/BT mode switch

Wired Connection

1. 2.4G/OFF/BT switch on "OFF".  
2. Connect the keyboard to computer with USB cable.  
3. The computer will recognize and configure the keyboard automatically.


2.4G Wireless Connection

1. 2.4G/OFF/BT switch on "2.4G", plug 2.4G wireless USB receiver into computer USB port, the keyboard will connect with computer automatically.  
2. Re-connect: Press and hold [FN]+[4] for 3 seconds, the LED  flashes quickly in green, plug the USB receiver into USB port on your computer, after paired the LED will turn to green steady on.

Bluetooth Connection

1. 2.4G/OFF/BT switch on "BT".

1

2. Press and hold [FN]+[1/2/3] for 3 seconds,  flashes in Blue[1] or Cyan[2] or Purple[3] quickly.

3. Turn on Bluetooth function and searching for available devices, It will find "BT 3.0-1/ BT 5.0-1 or BT 3.0-2/ BT 5.0-2 or BT 3.0-3/ BT 5.0-3" devices. Select a Bluetooth device name to pair, after paired the LED will turn to steady on.

4. To switch the Bluetooth connections between BT1/BT2/BT3, press FN+[1/2/3].

Product Features

Backlight

1. The default 19 backlight patterns switch by press [FN] + [INS] to cycling switch the light patterns.

2. Press [FN] + [←/→] to adjust light rotating speed, total 5 levels.  
Press [FN] + [↑/↓] to adjust backlight brightness, total 5 levels.

3. Press [FN] + [Space bar] to turn on/off the backlight.

[WIN] lock

Press [FN] + [WIN] to lock [WIN] key, repeat to unlock.

Commands of key combinations with [FN] key

FN+F1: My computer	FN+F7: Play/Pause
FN+F2: Internet browser	FN+F8: Stop
FN+F3: Calculator	FN+F9: Mute
FN+F4: Media player	FN+F10: Volume -
FN+F5: Pre track	FN+F11: Volume +
FN+F6: Next track	FN+F12: E-mail

3


Restore factory settings

Press and hold [FN] + [ESC] for 3 seconds.

Auto sleep and power save function

The keyboard will enter sleep mode when it is out of operation in 3 minutes, backlight will turn off, press any key to wake it up, when the keyboard is out of operation in 10 minutes, the keyboard will enter power save mode, click any button to wake it up.

How to recharge the keyboard


When battery is low,  LED will blink in Red. Connect the keyboard with computer to charging, or use power bank, charger to charging.

Warning: Charging current: 5V==2A max

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.

2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.



4

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.  
DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.  
DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.  
DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.  
DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.  
DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

CAUTION:

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.


Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

5


FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help  
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

6



7



REDRAGON


KUMARA ELITE

WIRED/2.4G WIRELESS/BT 3 MODES  
CONNECTION MECHANICAL KEYBOARD

Mechanical Gaming Keyboard  
User manual

8

封底			封面					
型号	K552-KRS 8565		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷					
名称	说明书							
日期	2024-7-20							
页码	1 OF 1		文件编号					
绘图	雷国建	审核		核准				
				版本	A.1			



EasternTimes  
Tech

