

12 EUT PHOTOS

EUT PHOTOS (1/4)



EUT PHOTOS (2/4)

EUT PHOTOS (3/4)



EUT PHOTOS (4/4)

Earphone (Merry, P/N EMC147-008)



BATTERY



POWER ADAPTOR (Delta, model EADP-10BB)



POWER ADAPTOR (Hi Pro, model HP-AC010L63)



USB Cradle (HP, model HSTNH-F02X)



DC CONNECTOR



Y-CABLE

