

Setup Photo

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 4 test positions all with the distance =0mm between the EUT and the phantom bottom:

Front in body position	Tilt Side in body position
	
EUT Setup Configuration 1	EUT Setup Configuration 2
Left Side in body position	Top Side in body position
	
EUT Setup Configuration 3	EUT Setup Configuration 4