


IQ FOB-S QUICK INSTALL GUIDE



Convenience on a keychain


The IQ Fob is one of the easiest ways to use your system. Using our proprietary S-Line encryption technology, encrypts signals sent to the IQ Panel while still providing backwards compatibility for legacy 319.5 systems. Most people find themselves remembering they haven't armed their system as they get into the car, or are too busy carrying things to arm their system from the IQ Panel.

The IQ Fob allows you to activate your system within 100' of the IQ Panel, and has the hidden feature of being able to activate an intrusion or "police" panic by pressing "Lock" and "Unlock" together for 3 seconds.



FEATURES

- Encrypted S-Line sensor technology
- Lock button can arm in stay or away mode
- Unlock disarms system
- Up to 100' range
- Panic function



This is a quick guide for experienced installers only. Refer to <http://dealers.qolsys.com> (login required)

STEP 1

LEARN
INTO
PANEL



Place your panel in
“autolearn” mode



Press and hold arm and disarm
buttons to “tamper” the device

ADD


Customize name and settings
as desired and touch “ADD”



ASK
JENNI
Qolsys

STEP 2

ARMING
YOUR
SYSTEM




Press the arm
button down
once until the red
LED lights up for
stay mode.

Press a second
time to arm away.

STEP 3


DISARMING
YOUR
SYSTEM



Press the disarm
button down
once until the red
LED lights up to
disarm the
system.

STEP 4

SENDING A
PANIC
SIGNAL



Press and hold
the arm and
disarm buttons
down for three
seconds to send
an emergency
panic signal to
the panel.



Document#: IQDW-QG-1-17
Revision#: 1/4/17
Issue Date: JAN 2017
Qolsys Product #: QS1331-840

Qolsys Inc. proprietary.
Reproduction without permission is not permitted.
FCC ID: 2ABBZ-RF-KEYFOB
IC: 11817A-RFKEYFOB

GOT QUESTIONS?
CONTACT TECH SUPPORT
TechSupport@Qolsys.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.