




## 正面内容

<p><b>8级防水骨传导耳机</b> 5800-B RUNNER PRO</p> <p><b>耳机操作说明</b></p> <p>充电窗口：插上电源自动开机(U型模式)、可下垂作触控开关 功能键：长按2秒开机，长按2秒关机，单击暂停，单击播放，单击接听与挂断 <b>MP3模式/蓝牙模式切换</b>：长按2秒即可切换两种模式与蓝牙模式 <b>佩戴舒适性</b>：硅胶挂绳耳机上，戴上电源自动开启U型模式，下垂直接触控长按与单击开关</p> <p><b>产品功能</b></p> <p>音乐播放、音乐暂停、音乐暂停、内置32G内存、本机播放功能</p> <p><b>适用产品</b></p> <p>Android 5.0以上系统的手机、PSP、笔记本电脑等具备蓝牙功能的设备</p> <p><b>特点</b></p> <p>高通芯片驱动的扬声器，本公司运动蓝牙耳机设计独特的音质大，音质很好，公司真正体验无线打电话、听音乐的乐趣 <b>续航能力</b> 内置32G存储，可存储超过3000-5000首音乐、视频音乐、通话录音和语音音乐</p> <p><b>蓝牙适配/本地播放功能</b></p> <p>开关机：长按2秒开机，长按2秒关机；开机状态下长按2秒进入蓝牙模式； 切换模式：双击背部即可在“蓝牙模式”与“本地播放模式”之间切换。</p> 	<p><b>LED灯</b></p> <table border="1"><tr><td>开机</td><td>红蓝灯闪烁</td></tr><tr><td>关机</td><td>红灯灭</td></tr><tr><td>蓝牙配对</td><td>红蓝灯闪烁</td></tr><tr><td>蓝牙状态</td><td>灭灯</td></tr><tr><td>来电时</td><td>灭灯</td></tr><tr><td>拨打电话时</td><td>灭灯</td></tr><tr><td>播放音乐时</td><td>灭灯</td></tr><tr><td>充电显示</td><td>红灯常亮</td></tr><tr><td>充电完成</td><td>蓝灯常亮</td></tr><tr><td>电池低电压</td><td>语言提示+手机电量显示</td></tr></table> <p><b>温馨提示与安全信息</b></p> <p><b>充电方式</b></p> <ol style="list-style-type: none"><li>1. 插接电源线充电，在使用过程中请勿拆卸并遵守以下注意事项：<ol style="list-style-type: none"><li>1. 使用前请先充电，充电时间过长可能会导致产品损坏或火灾。</li><li>2. 请在温度10°C~45°C范围内使用产品。产品长时间充电，请在3个月内充电一次，以保证电池的性能完好。</li><li>3. 请将产品从电源插座处拔出后进行清洁，清洁请用干布，时间2小时；请将充电线干燥后再插机充电，防止充电过程中因进水引起的短路影响本产品使用寿命。</li><li>4. 本产品含有锂电池，请勿加热、挤压、摔落本产品或将其放入水中，防止漏水，本产品遇水容易损坏，遇水请停止使用并及时维修。</li><li>5. 长时间使用耳机可能会导致头部不适或听力损失，建议使用降噪功能或休息。</li><li>6. 挂个休眠按钮，如果真的想把耳机不连接耳朵来睡觉，建议停止佩戴耳机休息。</li><li>7. 如果您身上佩戴了起搏器或其它电子医疗装置，在使用本产品前应咨询医生。</li><li>8. 请勿将本产品用于儿童无法接触的场所，若本产品被小孩误食且吞咽或误吸请及时就医。</li><li>9. 请遵守所有国家及地区的关于无线电设备或射频干扰产品的标准和规定。</li><li>10. 使用本产品时请遵守交通安全及当地法律法规。</li></ol></li></ol> <p>This device complies with Innovation, Science and Economic Development Canada License exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including inter ference that may cause undesired operation of the device.</p> <p>Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'utilisation est autorisée à ces deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si ce brouillage est susceptible d'en compromettre le fonctionnement.</p>	开机	红蓝灯闪烁	关机	红灯灭	蓝牙配对	红蓝灯闪烁	蓝牙状态	灭灯	来电时	灭灯	拨打电话时	灭灯	播放音乐时	灭灯	充电显示	红灯常亮	充电完成	蓝灯常亮	电池低电压	语言提示+手机电量显示
开机	红蓝灯闪烁																				
关机	红灯灭																				
蓝牙配对	红蓝灯闪烁																				
蓝牙状态	灭灯																				
来电时	灭灯																				
拨打电话时	灭灯																				
播放音乐时	灭灯																				
充电显示	红灯常亮																				
充电完成	蓝灯常亮																				
电池低电压	语言提示+手机电量显示																				

## 反面内容

<p><b>EN</b></p> <p><b>Magnetic Charging Port</b></p>  <p><b>Button “+”</b></p> <p><b>Button “-”</b></p> <p><b>Multi-function Button</b></p> <p><b>Instructions</b></p> <table border="1"><tr><td>Multi-Function Button</td><td>Power On/Power Off-Pause/Play; Answer/End Call/Reject Calls</td></tr><tr><td>Magnetic Charging Port</td><td>Connect S800-B RUNNER PRO to your computer, download and transfer MP3 files</td></tr><tr><td>Power On/Off</td><td>Long press "Multi-Function Button" 2s to activate S800-B RUNNER PRO. Default by Bluetooth mode</td></tr><tr><td>MP3 or Bluetooth Player</td><td>Double click "Multi-Function Button" to switch MP3 or Bluetooth Player</td></tr><tr><td>Button “+”</td><td>One click "Increase volume"   Long press "next song"</td></tr><tr><td>Button “-”</td><td>One click "Decrease volume"   Long press "previous song"</td></tr></table> <p><b>Product Features</b></p> <p>Answer/Reject calls; Play/Pause music; built-in 32G memory card; MP3 or Bluetooth Player</p> <p><b>Wide Application</b></p> <p>Applicable to terminal devices with Bluetooth function, such as mobile phones with Android 5.0/6.0 or above, PSP, laptop, etc.</p>	Multi-Function Button	Power On/Power Off-Pause/Play; Answer/End Call/Reject Calls	Magnetic Charging Port	Connect S800-B RUNNER PRO to your computer, download and transfer MP3 files	Power On/Off	Long press "Multi-Function Button" 2s to activate S800-B RUNNER PRO. Default by Bluetooth mode	MP3 or Bluetooth Player	Double click "Multi-Function Button" to switch MP3 or Bluetooth Player	Button “+”	One click "Increase volume"   Long press "next song"	Button “-”	One click "Decrease volume"   Long press "previous song"	<p><b>Summary</b></p> <p>Thank you for choosing our product. Our company's sports Bluetooth headphones have a fashionable design and powerful features, with good compatibility, allowing you to truly experience the joy of wireless phone calls and music listening.</p> <p><b>MP3 Player</b></p> <p>MP3 Player is available, with a built-in 32GB storage that can hold up to 3000-5000 songs. You can enjoy listening to music anytime, anywhere without the need for a phone.</p> <p><b>LED Indicator</b></p> <table border="1"><tr><td>Power On</td><td>Flash red and blue light</td></tr><tr><td>Power Off</td><td>Red light off</td></tr><tr><td>Bluetooth Pairing</td><td>Flash red and blue light</td></tr><tr><td>Bluetooth Paired</td><td>LED OFF</td></tr><tr><td>Incoming Call</td><td>LED OFF</td></tr><tr><td>Making a Call</td><td>LED OFF</td></tr><tr><td>Play Music</td><td>LED OFF</td></tr><tr><td>Charging</td><td>Red</td></tr><tr><td>Fully Charged</td><td>Blue</td></tr><tr><td>Low Battery</td><td>Voice reminder - Phone battery reminder</td></tr></table>	Power On	Flash red and blue light	Power Off	Red light off	Bluetooth Pairing	Flash red and blue light	Bluetooth Paired	LED OFF	Incoming Call	LED OFF	Making a Call	LED OFF	Play Music	LED OFF	Charging	Red	Fully Charged	Blue	Low Battery	Voice reminder - Phone battery reminder	<p><b>How to charge S800-B RUNNER PRO headphones?</b></p> <ol style="list-style-type: none"><li>1. Charging with magnetic suction interface.</li><li>2. Please use a charger with a current of 1 amp or less to charge the headphones. After fully charged, please disconnect the power supply. It is not recommended to use a mobile power supply to charge the headphones.</li></ol> <p><b>Main Features</b></p> <ol style="list-style-type: none"><li>1. 15-day ultra-long standby time</li><li>2. Comfortable in-ear design</li><li>3. HiFi stereo sound</li><li>4. 5.5 Bluetooth high-speed transmission</li><li>5. Can be used independently without a phone</li><li>6. IPX8 waterproof and sweat proof, can be used for swimming up to 2 meters deep</li><li>7. Comes with 32GB internal memory, can store 3000-5000 songs</li></ol> <p><b>Friendly Reminder</b></p> <p>Care user, please keep the charging port dry while charging, and do not use heat source. The music will bring you more joy and a unique experience. We wish you a pleasant experience!</p> <p><b>RF warning statement:</b> The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>	<p><b>Warm tips and safety information</b></p> <p>Dear users, please carefully read and observe the following precautions before using and operating the device:</p> <ol style="list-style-type: none"><li>1. Please fully charge the device before using, and do not use a charger with output higher than 5V/2A when charging.</li><li>2. Please use this product in the temperature range of 0°C~45°C. If the product is not used for a long time, please charge it within 5 months to ensure good battery performance.</li><li>3. After using the product for exercise, it is recommended to clean the sweat and water stains on the surface of the product with a dry towel, and let it dry for 2 hours. Please make sure that the charging port is dry before charging the headphones, so as to prevent short circuit caused by sweat from affecting the service life of the product during charging.</li><li>4. This product contains batteries. Do not throw, press, disassemble or immerse the product in water. Keep it away from fire, water and high voltage equipment. Do not continue to use the product if it is overcharged, dropped or damaged, or falls into liquid.</li><li>5. Prolonged exposure to high volume may cause permanent hearing loss, and the minimum volume required is recommended.</li><li>6. Please stop wearing the product and consult your doctor if you have skin disorder or your ears one buzzing.</li><li>7. If you are fitted with a pacemaker or other electronic medical device, please consult your doctor before using this product.</li><li>8. Keep the product out of reach of children. Swallowing the product or the packaging bag and small parts may cause suffocation.</li><li>9. Please observe all legal and instructions that require you to turn off electronic devices or RF radio products in designated locations such as hospitals or airports.</li><li>10. Please observe the traffic safety and local laws when using this product.</li></ol> <p><b>FCC Warning</b></p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: — Reorient or relocate the receiving antenna. — Increase the separation between the equipment and receiver. — Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. — Consult the dealer or an experienced radio/TV technician for help.</p> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p><b>Model</b>: S800-B RUNNER PRO <b>Input</b>: 5.0V ± 150mA <b>Capacity</b>: 1800mAh/5.0Wh <b>Made in China</b></p> 
Multi-Function Button	Power On/Power Off-Pause/Play; Answer/End Call/Reject Calls																																		
Magnetic Charging Port	Connect S800-B RUNNER PRO to your computer, download and transfer MP3 files																																		
Power On/Off	Long press "Multi-Function Button" 2s to activate S800-B RUNNER PRO. Default by Bluetooth mode																																		
MP3 or Bluetooth Player	Double click "Multi-Function Button" to switch MP3 or Bluetooth Player																																		
Button “+”	One click "Increase volume"   Long press "next song"																																		
Button “-”	One click "Decrease volume"   Long press "previous song"																																		
Power On	Flash red and blue light																																		
Power Off	Red light off																																		
Bluetooth Pairing	Flash red and blue light																																		
Bluetooth Paired	LED OFF																																		
Incoming Call	LED OFF																																		
Making a Call	LED OFF																																		
Play Music	LED OFF																																		
Charging	Red																																		
Fully Charged	Blue																																		
Low Battery	Voice reminder - Phone battery reminder																																		