

HOW TO

Attach your Jiobit





INDEX	Choose the Best Fit	02
	Built In Loop	03
	Universal Clip	09
	Secure Loop	13
	Strap Clip	17
	Outer Sleeve	19
	Appendix	21

GET TO KNOW YOUR JIOBIT



Jiobit Device
w/ Built In Loop



Universal Clip



Secure Loop

ADDITIONAL ATTACHMENTS

Sold separately



Strap Clip



Outer Sleeve

Choose the best fit for your child

Every child will have a preferred way to wear Jiobit. That's why we've designed multiple attachments to accommodate as many wearing options as possible.

See our recommendations here or visit <http://jiobit.it/HowToAttach> for a video demonstration.

Built In Loop

Best for shoelaces,
drawstrings, and kept
in a pocket.




WEARABILITY



Shoelace



Drawstring




In Pocket

HOW TO ATTACH


We are using shoelaces as an example, but this loop also works with drawstrings.

1




Thread the lace through the loop.

2



Tie laces normally.

3



Pull laces around Jiobit to secure down.


ALTERNATIVE ATTACHMENTS

We understand that kids can be picky about what they wear. If the wearing options we've suggested are not available to you, let us help you get creative with the built in loop.




In Socks

Tuck Jibbitz into a tight fitting sock.



Hair Ties

Hair ties work well to attach Jibbitz to any kind of loop.



Safety Pins


Use a large safety pin to attach to just about anything.

Universal Clip


Best for waistbands, pockets, sleeves, and necklines.




WEARABILITY



Waistband




Neckline



Pocket


HOW TO ATTACH

1



Line up the prongs of the clip with the loop holes on each side of JioBit.

2



Push down hard to snap it in.


HOW TO REMOVE

1



Hold JioBit in one hand.

2




With the other hand, twist and pull up on the clip at the same time to remove.

Secure Loop


Best for belt loops, tag loops, and buttonholes.




WEARABILITY



Belt Loop




Tag Loop




Buttonhole

HOW TO ATTACH




Line up the prongs of the loop with the loop holes on each side of JioBit.




Push down hard to snap it in.

HOW TO REMOVE



Hold JioBit in one hand.



With the other hand, twist and pull up on the clip at the same time to remove.


Strap Clip

Best for backpack straps,
belts, and shoe straps.



Sold separately


WEARABILITY



Shoe Strap



Backpack Strap



Belt

The strap clip is sold separately.
Visit www.jiobit.com to purchase.

Outer Sleeve


To protect or personalize your JioBit.



Sold separately

ATTACHING THE SLEEVE TO JIOBIT

Insert JioBit top first into the sleeve as shown. Pull the bottom of the sleeve over the bottom of JioBit.



The sleeve is sold separately.
Visit www.jiobit.com to purchase.

Appendix

Visit jiobit.com to see Jio's Warranty & Return Policy, Privacy Policy, Terms of Use, and Terms of Service.

©2017 Jio Inc. All Rights Reserved

REGULATORY & SAFETY NOTICES

Model Name & Number: Jiobit 4188N8762W

USA: Federal Communications Commission (FCC) statement

This device complies with FCC part 15 FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation FCC warning. Changes or modifications not approved by JIO, Inc. could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- IC Notice to Users in accordance with RSS GEN Issue 3: 21. This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and 2. this device must accept any interference, including interference that may cause undesired operation of the device IC ID: 8542A-FB404

This device meets the FCC requirements for RF exposure in public or uncontrolled environments.

FCC ID: 2AKLI-080715

Canada: Industry Canada (IC) statement

This device meets the IC requirements for RF exposure in public or uncontrolled environments. IC Notice to Users in accordance with RSS GEN Issue 3:

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage;
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC ID: 22220-080715

QUESTIONS?

Visit Jiobit member care

SUPPORT.JIOBIT.COM

Give us a call

855-546-2848

Send us an email

SUPPORT@JIOBIT.COM