





Photograph of the depth in the Phantom (835MHz)




Photograph of the depth in the Head Phantom (1900MHz)




Photograph of the depth in the Phantom (2450MHz)



Right Head Tilt Setup Photo



Right Head Touch Setup Photo



Left Head Tilt Setup Photo



Left Head Touch Setup Photo



0mm Body-worn Rear Setup Photo





0mm Body-worn Left Side Setup Photo



0mm Body-worn Right Side Setup Photo



0mm Body-worn Top Side Setup Photo



0mm Body-worn Bottom Side Setup Photo