Glozata

Wireless Earphone

E30

User's Manual

# Contents

English

that you are satisfied with our product and services. If you have any problem with our product during the warranty period, please feel free to contact with our after-service dept for rapid repairing or replacement: sales@ec-tek.com.

Problem mit dem Produkt innerhalb der Gewahrleistungszeit auftreten.

konnen Sie unseren After Sales Service f ür eine Reparatur oder Ersatz

unter eu@ec-tek.com kontaktieren

Warranty

お客様に良い体験をしていただくことは、私たちの責任と使命であ 故障していました時には、万全たアフターサービス。 迅速な修理 良品との交換を実施しております。商品の保証期間中に問題が発生 した場合、購入履歴を弊社アフターサービスまでご連絡をいただけ れば、弊社で速やかに対応させていただけますので、ご安心くださ Vielen Dank, dass Sie sich für unser Produkt entschieden haben. Wir hoffen, dass Sie zufrieden mit Ihrem Einkauf sind. Sollte dennoch ein

Thanks very much for your purchase with our product, we sincerely hope

Signal indicator

Multi-function key Short press: Play/pause: answer the phone Press twice: Redial the last call

[Inhone Siri]: Press the Multi-function key for 3 senconds, the

release to acitivate Siri or Google Assistant.

Play and Pause Press the multi-function Key shortly increase volume Previous song/volume -

Long press to shift to previous song/short

Microphone

Pick up and Hang up the phone

Press multi-function key shortly while there is an incoming call.

Turn on the ON/OFF button, you will see the white and orange light flashing

Reject an incoming call

## Press and hold the multifunction key for 2 seconds

Redial the phone

# Press the multifunction key twice, then it will dial the last number

# you called.(The first connected phone)

Volume+/Next song

Press volume+ once to increase volume, press and hold the volume+

## button for 2 seconds to switchthe next song.

Volume-/Previous song

Turn off the ON/OFF button

Press volume- once for Volume-down. Press and hold the volume

for 2 seconds, then shift to the previous song.

Product name

Playing time

Standby time

•E30 Bluetooth headset

·Soft headset pouch

·User's Manual

then select it to pair.

→ Specification ←

1. Please switch the power button to On place, then the light flashing to enter pairing mode. (You can hear the voice of "Power on") 2. Click your computer's Bluetooth devices and select the add device button, enter the search mode. Search the "E30" then click it and connect. You can hear the Charging time voice of "Connected successfully", but you need to continue the 3 sten. 3. Click your computer's Bluetooth devices and select the display Bluetooth

Turn on the ON/OFF button, the white and orange LED indicator flashing,

the Bluetooth headset will automatically enter the pairing mode.

device, the "E30" model will display in the search devices list.

Turn on Bluetooth on your mobile phone and search for Bluetooth

a) If your computer doesn't include Bluetooth function, you need to add to a ·Charging cable external Bluetooth Receiver b) The different computer may have a difference, so if you can't pair, please

How to pair

steps after connect successfully, it will pairing automatically, Connecting to mobile phones and other Bluetooth devices:

o connect the E30 Bluetooth earniece with computer

devices to find the E30 Bluetooth headphone, then click twice to enter the paire

interface. You need to click the listen to music and the switch to handsfree

c) The E30 headphone has a memory function, so you don't need to repeat the

earpiece button, the light stop flashing when connecting successfully.

Disconnect

Connected

contact our after-service team

Disconnect

1. Pair with the first mobile phone, then turn off both This equipment has been tested and found to comply with the limits for a the Bluetooth headset and the Bluetooth function of the

first mobile phone. 2. Turn on the E30 headset again, pair with the second mo phone as normal.

CSR8615 smart chip

password is 0000

3. Turn on the Bluetooth function of your first phone. connect the first phone again. Then 2 mobiles connected

Charging method

There are three charging methods available: 1. USB interface charging;

Connect two-device at the same time

2. Connect vehicle charger for charging:

3. Connect charging plug for charging.

Please use an under 1A charger to charge the Bluetooth headset, and

the equipment off and on, the user is encouraged to try to correct the please don't to connect the charger before the device is fully charged interference by one or more of the following measures' Do not use a nower bank to charge the Bluetooth headset directly

- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver

Bluetooth 4.1 is well compatible with most smartphones and tablets.

Ontimized with 360° rotation for wearing convenience and comfortability

Note: For some devices with an old version of Bluetooth (i.e., Bluetooth 2.0)

or some niche smartphones, you may need to enter an access code. The initial

which the receiver is

**FCC Statement** 

Class B digital device.

equipment generates

accordance with

However, there is

determined by turning

- Connect the equipment into an outlet on a circuit different from that to

Consult the dealer or an experienced radio/TV technician for help.

pursuant to Part 15 of the FCC Rules. These limits are designed to provide

uses and can radiate radio frequency energy and, if not installed and used in

the instructions, may cause harmful interference to radio communications.

no guarantee that interference will not occur in a particular installation. If

cause harmful interference to radio or television reception, which can be

protection against harmful interference in a residential installation. This

FCC Statement

the following two

device must accept

This device complies with part 15 of the FCC Rules. Operation is subject to

conditions:(1) This device may not cause harmful interference, and (2) this

any interference received, including interference that may cause undesired

Changes or modifications not expressly approved by the party responsible for

could void the user's authority to operate the equipment.

Glazata

# FCC ID: 2AMLT-E30

# FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter