

A3119

Front: Keyboard, Numeric Keypad, Fingerprint Scanner



A3119

Back Side



A3119
Left side



A3119
Right Side



A3119

Top Edge - power on/off toggle, USB-C connector



A3119

Bottom Edge

