

Luggage Finder Tag

Quick start guide



The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, iPod touch, or the Find Items App on Apple Watch.

To use the Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, iPod touch, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark of Cisco and is used under license.

Quick Start Guide

EN

Please fully charge the Luggage Finder Tag to 100% before using it for the first time.

Setting Up Your iPhone

Compatibility

The Luggage Finder Tag is only compatible with iOS 14.5 or later with Two-Factor Authentication turned on. If your Apple ID does not use two-factor authentication, you can turn on this feature with the following instructions:

1. Turn on Two-Factor Authentication for your Apple ID

On your iPhone: Go to Settings your name > Sign-In & Security. Tap Turn On Two-Factor Authentication. Then tap Continue and follow the onscreen instructions.

On your MAC: choose Apple menu > System Settings, then click on your name (or Apple ID). Click Sign-In & Security. Next to Two-Factor Authentication, click Turn On and follow the onscreen instructions.

On the web: Go to apple.com and sign in using your Apple ID. Answer your security questions, then tap Continue, Tap Continue when you see a prompt to update account security. Then tap Update Account Security and follow the onscreen instructions.

2. Turn on Find My

A. Go to Settings.

B. Tap your name, then tap Find My

C. Tap Find My iPhone and turn on Find My iPhone.

3. Turn on Bluetooth

4. Connect to a stable Wi-Fi or cellular network.

5. Turn on Location Services

Go to Settings > Privacy & Security > Location Services > turn on Location Services.

Getting Started

Turn on

Short press the Luggage Finder Tag power button one time (⏻), and a beep sound will indicate that it has been turned on.

Turn off

To turn off the Luggage Finder Tag, short press the power button two times (⏻); then long press it until you hear a beep. This will indicate that your Luggage Finder Tag has been turned off. If your Luggage Finder Tag has not been paired within 10 minutes, you will hear a beep indicating that it has been turned off. Please turn it on again to continue with the pairing of your tag.

Factory reset

To factory reset the Luggage Finder Tag, short

press the power button 4 times (⏻), then long press until you hear a beep. This will indicate that the factory reset has been completed.

Pairing Your Luggage Finder Tag

1. Ensure your iPhone is set up (see "Setting Up Your iPhone" above) and your Luggage Finder Tag is turned on.

2. Open the Find My app (📍).

3. In the Items tab, tap Add New Item.

4. Tap Other Supported Item (your iPhone will search for your Luggage Finder Tag).

5. Once your Luggage Finder Tag is detected, tap Connect.

6. Follow the onscreen steps to name it and register it to your Apple ID.

7. Ensure your Luggage Finder Tag appears in Items. If not, forget the device, perform a factory reset on the Luggage Finder Tag (see "Getting Started > Factory reset" above), and then reconnect.

- Please do not leave the Find My app while pairing the Luggage Finder Tag.

Locating Your Luggage Finder Tag

Locate your Luggage Finder Tag via the Maps app

1. Open the Find My app.

2. Tap the Items tab.

3. Select your Luggage Finder Tag in the Items list.
4. Tap Directions to open the location of your Luggage Finder Tag and get directions in the Maps app.

Play sound alert

1. Open the Find My app.
 2. Tap the Items tab.
 3. Select your Luggage Finder Tag Tag in the Items list and tap Play Sound*.
- *The sound alert will only play if your iPhone is connected to a network, and your Luggage Finder Tag is in Bluetooth range of your iPhone (approx. 160f/50m)

Set up Notify When Left Behind

If your Luggage Finder Tag is not in Bluetooth range of your iPhone for a while, you will receive a notification that your Luggage Finder Tag has been lost (if you set up a name, the name will be displayed, otherwise it will show the Luggage Finder Tag)

1. Open the Find My app.
2. Tap the Items tab.
3. Select your Luggage Tag in the Items list and scroll down.
4. Under Notifications, tap Notify When Left Behind and turn it on.

Enable Notify When Found

1. Open the Find My app.
2. If the Luggage Finder Tag cannot be located: You will see "No location found" displayed below the device name. Under Notifications, turn on Notify When Found. You will receive a notification when the device is found.
[Important] Please make sure to allow notifications from the Find My app. Check the notification settings of your iPhone.

Mark your Luggage Finder Tag as lost

1. Open the Find My app.
2. Tap the Items tab.
3. Select your Luggage Finder Tag in the Items list and scroll down.
4. Ensure Notify When Left Behind is turned on.
5. Under Lost Mode, tap Enable, then tap Continue.
6. Enter your phone number/email address so that the finder of your Luggage Finder Tag can contact you, then tap Activate.

Changing the Name of Your Luggage Finder Tag

1. Open the Find My app and tap the Items tab.
2. Select your Luggage Finder Tag in the Items

list.

- 3.Scroll down and tap Rename Item.
- 4.Select a name from the list or select Custom Name.
- 5.For Custom Name, input a name and select an emoji.
- 6.Tap Done

Removing Your Luggage Finder Tag

Removing your Luggage Finder Tag from your Apple ID will allow it to be activated and used by another person.

- 1.Ensure that your Luggage Finder Tag is connected to your iPhone*.
- 2.Open the Find My app.
- 3.In the Items tab, tap the Luggage Finder Tag
- 4.Tap Remove item, tap Remove and confirm to remove.

*If not connected when removing your Luggage Finder Tag from your Apple ID, it will no longer be discoverable. You will need to perform a factory reset before creating a new connection (see “Getting Started Factory Reset” above).

Unwanted Tracking Notification

If your Luggage Finder Tag is separated from your iPhone and is detected moving with another person with an Apple device over time, that person will receive a tracking alert message.

Charging your Luggage Finder Tag

Charge the Luggage Finder Tag with a wireless charger. (Note: wireless charger not included). During Charging, the status light will be orange. When fully charged, the status will turn green. It is recommended to fully charge your Luggage Finder Tag once every 4 months.

Apple’ s Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, or Mac, or the Find Items app on your Apple Watch.

To use Apple’ s Find My app to locate the item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of the watchOS.

The use of Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple’ s Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My,

iPhone, iPad, iPadOS, Mac, macOS, and watchOS are trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

FCC Statement

Please take attention that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 18 of FCC Rules.

FCC Caution

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CE Statement

Herby, Aveoe Inc. declares that the radio equipment type Taita M 3 in 1 foldable wireless charging station is in compliance with Directive 2013/53/EU.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.