

Exhibit 4
Instruction Manual

MAXIMUM HEAT!

TYCO RC 6.0V JET TURBO

OWNER'S MANUAL
PLEASE READ THOROUGHLY BEFORE OPERATING YOUR VEHICLE

6.0V JET TURBO
PYTHON
RADIO CONTROL 6.0V JET TURBO®

TYCO RC SERVICE CENTER



WE CARE!

If you have questions or difficulty operating this vehicle,
DO NOT RETURN IT TO THE STORE!

Call Toll-Free 1-888-557-TYCO (1-888-557-8926) (US only)

Freephone: 0800 212751 (UK only)

for technical help, or **RAPID** parts and service assistance.

30648-1920



Model No. 32848 (Blue-27MHz) (U.S.A. only)



Model No. 30712 (Black-49MHz) (U.S.A. only)




Model No. 36510 (Blue-27MHz) (U.K. only)


FEATURES

- 8 functions
- Available in 2 frequencies:
27 MHz and 49 MHz
(27 MHz only in U.K.)
- Water-spitting,
transforming snake-head
- Range up to 65 feet (20 m)

CONTENTS



(1) Transmitter



(1) 6.0V Jet Turbo® PYTHON® Vehicle

BOTTOM VIEW

Steering Trim
Adjuster

Battery
Compartment
Latch

Water Tank

Front
Bumper

ON/OFF Switch

Battery
Compartment

Water Tank
Latch

Powerful
RC260
Mabuchi
Motor

TRANSMITTER


NOTE: Your transmitter is equipped with a special automatic "ON" battery-saving feature. Just turn your vehicle "ON." Then push either transmitter stick and you will be able to run and control your vehicle.

Left Stick
Controls
Forward
& Reverse

Whip
Antenna

Trigger Button
Controls Snake-Head
& Water-Spitting Action

Right Stick
Controls Right
& Left Turns



Automatic "ON" Power
Indicator Light

Refer to label on transmitter and vehicle for frequency. Do not race vehicles with the same frequency.


STEP 1

BATTERY CHARGING/CARE


(BATTERIES AND CHARGER NOT INCLUDED)

Your vehicle will not operate without the TYCO® R/C 6.0V Jet Turbo Battery Pack and 4-Hour Quick Charger. The 6.0 Jet Turbo battery pack is designed for use exclusively in TYCO R/C 6.0V Jet Turbo vehicles. It will not work in any 9.6V NiCd battery powered vehicles.

1. Plug wall pack charger into standard wall outlet.
2. Click the battery pack securely into the charger.
3. To disconnect, push the red button on the side of the charger. Hold the red button down while you slide out the battery pack.
4. New battery packs must be charged for 5½ hours the first two times charged. After that, subsequent charges will require only 4 hours.
5. After charging for 4 hours, the battery pack will feel warm. This is normal for fully charged batteries.
6. Charging the battery pack for more than 4 hours will not give you longer running time.
7. Unlike alkaline batteries, which lose power gradually, your 6.0V Jet Turbo battery will run for its normal running time, depending on your particular vehicle, and then lose most of its power at once. It is now time to recharge the battery pack.
8. After use, the battery pack will be hot! Wait at least 20 minutes until the battery pack cools down before recharging. Recharging a hot battery pack will greatly reduce the number of times your battery pack can be recharged.



6.0V Jet Turbo Battery Pack and Charger



Have additional Battery Packs charged ahead of time for longer non-stop racing action. Uses the 6.0V Jet Turbo 4-Hour Quick Charger.

BATTERY PACK CARE

Because of its unique design, most other battery chargers will be unable to charge your 6.0V Jet Turbo battery pack. To charge your battery pack, use only the Tyco R/C 6.0V Jet Turbo battery charger. Inferior quality battery packs will shorten your vehicle's running time and may void the warranty.

Caution:

- DO NOT RECHARGE BATTERY PACK IF IT'S HOT. ALLOW IT TO COOL BEFORE RECHARGING.
- DO NOT CHARGE A BATTERY PACK THAT SHOWS LEAKAGE OR CORROSION.
- DO NOT DISASSEMBLE THE BATTERY PACK. THE BATTERY PACK IS A SEALED NiCd (NICKEL-CADMIUM) BATTERY.
- DO NOT DISPOSE OF THE BATTERY PACK IN FIRE.
- EXERCISE CAUTION IN HANDLING A HOT BATTERY PACK.
- IF BATTERY PACK AND/OR CHARGER ARE WET, THOROUGHLY DRY BEFORE CHARGING.

SPECIAL NOTE TO ADULTS:



- The battery charger should not be operated without adult supervision.
- Regularly examine for damage to the plug, enclosure and other parts. In the event of any damage, the toy must not be used with the transformer until the damage has been repaired.
- This toy is not intended for children under 3 years old. The transformer is not a toy.



STEP 2

BATTERY INSTALLATION

(AND REMOVAL)




BATTERY MUST BE CHARGED FOR 4 HOURS.

1. Release battery compartment latch.
2. Insert battery pack into battery compartment as shown.
3. Make sure battery pack snaps securely in place, turn battery compartment latch and lock battery pack in place.
4. To remove battery pack, turn latch and lift battery pack out of vehicle.



Estimated run time for this vehicle: 15-20 min.

TRANSMITTER



1. Install one 9-volt battery with polarity as shown inside battery compartment.
2. The 9-volt transmitter battery will last much longer than the run time of the 6.0V Jet Turbo rechargeable battery pack.




This vehicle uses a "Nickel-Cadmium rechargeable battery pack. Must be recycled or disposed of properly." **Note:** If you have any questions about proper disposal of Nickel-Cadmium batteries, contact your local county office of solid waste management (or other appropriate local office) for information.


**STEP
3**

SPECIAL PYTHON® R/C VEHICLE ACTION FEATURES


FORWARD!




REVERSE!



LEFT TURN!




RIGHT TURN!




TRANSFORM!

Push trigger button on transmitter and the snake figure will rise up! Some water may be released – don't worry about that.





Note: The snake figure is permanently attached to the vehicle. Do not attempt to remove the snake figure from the vehicle.




WATER-SPITTING FEATURE

Push trigger button again to activate the snake figure's water-spitting feature. Hold down the red button for continuous spitting action!




RESETTING SNAKE FEATURE

To reset the snake figure, GENTLY press on the back of the snake-head until snake snaps into place.




FILLING THE WATER TANK

1. Turn vehicle upside down. Release water tank latch, as shown, and remove water tank.



2. Fill with cool or lukewarm tap water—USE ONLY CLEAR FRESH WATER!



3. Line up water tube with hole in bottom of water tank. Once the top of the water tube is inserted into the water tank, QUICKLY push the water tank COMPLETELY down – until the top of the tank is even with the water tank latch.



4. Rotate water tank latch to lock water tank in place.



IMPORTANT: After each use, shoot water tank dry to avoid damage caused by freezing or mildew. Don't store your vehicle in overly cold temperatures.

Quick Reference

This section is only a quick reference guide. Please read this entire manual thoroughly before operating your vehicle.

1. Give your 6.0V Jet Turbo battery pack a full 4-hour charge and then install in vehicle.
2. Turn vehicle and transmitter switches "ON." Press either joystick and you will be able to run and control your vehicle.
3. After approximately 15-20 minutes of running, your vehicle will lose most of its power at once. The 6.0V Jet Turbo battery pack is near total power loss and needs to be recharged.
4. Turn vehicle and transmitter switches "OFF."

Tips & Hints


1. The radio circuitry in your vehicle and transmitter is sensitive. Do not store vehicle or transmitter near heat or in direct sunlight. After each use, remove any water or moisture from vehicle using a clean dry cloth. Avoid operating in snow.
2. Turn vehicle switch to the "OFF" position and remove battery pack when not in use.
3. When your vehicle runs erratically, the problem is usually the result of interference caused by high tension wires, CB radios, or other R/C vehicles running nearby on the same frequency as yours. You may have to choose an alternative place to race.

Safety Precautions

Adults, this toy is recommended for children 5 years of age and older. To ensure that the child's play is both safe and fun, please review the operating instructions and these general safety rules with the child.

Caution

- DO NOT pick up vehicle while in motion.
- Keep fingers, hair and loose clothing away from the tires and the wheel hubs while the vehicle is switched "ON."
- If this toy is being operated in the presence of children under 5 years of age, adult supervision is recommended.
- To avoid accidental operation, remove battery pack when not in use.




1. Radio interference is caused by the presence of another radio controlled vehicle operating on the same frequency as your vehicle. Obviously, multiple vehicles should **NOT BE OPERATED ON THE SAME FREQUENCY** at the same time.

2. Radio interference can be caused by the operation of your vehicle near **HIGH VOLTAGE ELECTRICAL WIRES, LARGE STEEL REINFORCED CONCRETE BUILDINGS AND PASSING TRUCKS WITH CB RADIOS.** Avoid these if possible.


3. DO NOT operate your vehicle over wet surfaces. Water can damage the electronic assemblies.



4. DO NOT operate your vehicle on streets! They are for real cars.



5. For best results, hold antenna up, not pointed down toward R/C vehicle. If you drive your vehicle **TOD FAR AWAY FROM THE TRANSMITTER**, your signal strength will become weak and vehicle will not function properly. The maximum range for the vehicle should be between 30 feet (9 m) to 65 feet (20 m), when operating outdoors.



TROUBLESHOOTING

PROBLEM? - SOLUTIONS

THIS INFORMATION FOR U.S.A. CONSUMERS ONLY

Symptom	Probable Cause	Correction
Vehicle runs slowly or will not run.	<ul style="list-style-type: none"> • Loose battery connection or vehicle switch not ON. • Weak or uncharged rechargeable battery. • Weak 9-volt transmitter battery. 	<ul style="list-style-type: none"> • Check battery connector and vehicle switch. • Charge battery or replace. • Replace with fresh 9-volt alkaline battery.
Erratic operation or only short range possible.	<ul style="list-style-type: none"> • Radio interference likely. 	<ul style="list-style-type: none"> • Change location (see point 3 - Tips & Hints).
Short battery life.	<ul style="list-style-type: none"> • Battery not fully charged. 	<ul style="list-style-type: none"> • Recharge 6.0V Jet Turbo battery pack. For maximum running time, make sure you give your battery pack a full 4 hour charge. About 15-20 minutes of life is typical with this type of radio control vehicle.

©1998 Mattel, Inc., Mt. Laurel, NJ 08054 U.S.A. PRINTED IN CHINA. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

Retain this address for future reference. Mattel U.K., Ltd., Meridian West, Leicester LE3 2WT. Mattel Australia Pty., Ltd., Port Melbourne, Victoria 3207 - Consumer Advisory Service: 1800 800 812 (valid only in Australia). Mattel East Asia Limited, 930 Ocean Centre, Harbour City, HK. China In Britain 49 MHz is not available. 27 MHz can be raced against 40 MHz vehicles. The PYTHON trademark is used under license from Directed Electronics, Inc.



THIS INFORMATION FOR U.K. CONSUMERS ONLY
TYCO® R/C 90 DAY LIMITED WARRANTY

This product is thoroughly tested and inspected before shipment and is guaranteed to be free from factory defects in material and workmanship for a period of 90 days from the date of purchase. Mattel will repair or replace any defective part or unit free of charge during this period. This warranty is valid provided the product has been operated in accordance with the instructions and proof of purchase is furnished. This warranty does not apply to worn or defective batteries, or to items which have been damaged or abused by the consumer. This warranty gives you specific legal rights and is in addition to and does not diminish your statutory or other legal rights.

IMPORTANT: Please return your product in its original package and keep a record of what you return.



COMPLIANCE WITH FCC REGULATIONS (U.S.A. ONLY)

THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION OF THIS DEVICE IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE
 2. THIS DEVICE MUST ACCEPT ANY HARMFUL INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.
- This device generates and uses radio frequency energy and if not used properly may cause interference to radio and television reception. It has been tested and found to comply with the limits set by the FCC which are designed to provide reasonable protection against such interference.

CAUTION: FCC Regulations state that changes or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CONSUMER INFORMATION

PRODUCT: PYTHON® Radio Control Vehicle
WARRANTY: 90-Day Limited Warranty. Details inside. Valid only in U.S.A. For ages 5 and over.
AGE GRADE: No
ASSEMBLY REQUIRED: No
BATTERIES REQUIRED: 1 9-Volt (transmitter); 1 6.0V Jet Turbo® Rechargeable NiCd (vehicle).
CONTENTS: PYTHON® Radio Control Vehicle, transmitter.



YOU CAN TELL IT'S MATTEL! CALL us toll-free or write with comments or questions about our toys or service. Monday-Friday, 8:00 a.m.-5:00 p.m. EST. Outside U.S.A., see telephone directory for Mattel listing. Consumer Affairs Department, 636 Grand Avenue, East Aurora, NY 14052 USA

1 (888) 557-TYCO



CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

We are dedicated to quality products.