

100g双胶纸彩色印刷,风琴折页,折叠SIZE:80x90mm


Charging

indicator light is white. It flashes blue when charging is complete.

It takes 2 hours to fully charge headphones. While charging, the battery

Note: The lifetime of the battery will be significantly reduced if your headphones are left uncharged for a long period of time. We recommend

that you recharge your headphone at least once a month.



Product Specifications

Lithium Ion Batteries: Model: 652035, 3.7V, 420mAh Battery Factory: SHENZHEN MEI NI INDUSTRIAL CO., LTD. Battery Factory Address: F4, NO. 28, Jinfeng Road, Yangnei Gang Village, Longgang District, Shenzhen

Use this product in an environment with a temperature between 0 $\rm C$ and 45 $\rm C$; otherwise, it may become damaged.

KOSS Corporation Model: KOSS CS340BT QZ Hereby declares that Bluetooth Headset, Model: KOSS CS340BT QZ is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.

KOSS Corporation Model: KOSS CS340BT QZ Bluetooth Version: 5.0 DC input: 5V=250mA Case Battery Capacity: 420mAh 1.6Wh Made in China

WARNING

Using earbuds at high volumes for extended periods of time may result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety. Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds.

Earbuds may not work properly under high temperature or high humidity conditions. Do not use any corrosive cleaner/oil to clean the earbuds. If the earbuds come in contact with liquids, quickly wipe away. If submerged in water, do not turn the earbuds on until completely dried.

Liquid submersion voids the warranty. Keep the earbuds and packaging out of reach of children.

Battery warning!

Do not disassemble, strike, crush or put the battery into fire.
 Do not expose the battery to conductive materials, liquids, fire, or high temperatures.

Do not allow metal objects to touch the two poles of the battery.
Do not continue to use the battery if it has bulges, leaks, discoloration, odors.
Do not use the battery after it has been submerged in water.
If the battery is used improperly, it may explode or leak, causing burns and other personal injuries.

* If the battery leaks, it should be carefully disposed of according to the local laws and regulations concerning battery disposal.

The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on 14/02/2014, resulted in a major change in the treatment of electrical equipment at end-of-life. The purpose of the Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce disposal. The WEEE logo on the product or on its box indication collection for electrical and electronic equipment consist of the crossed-out wheeled bin, as shown below.

X

FCC WARNING

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

Reorient the receiving antenna.
 Increase the separation between the equipment and receiver

Increase the separation between the equipment and receiver.
 Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

IC STATEMENT

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles succetibles de provoquer un fonctionnement indésirable de l'appareil.