



QUICK SETUP GUIDE

Wireless Stereo Earbuds

NS-CAHBTAP


PACKAGE CONTENTS

- Wireless Stereo Earbuds
- Charging case
- Two additional pairs of ear tips in small and large sizes
- USB charging cable
- Quick Setup Guide

FEATURES

- Control phone calls and and music playback using a touchpad
- Has a waterproof rating of IPX4
- Listen to music or talk on the phone wirelessly
- Provides five hours of music playback
- Includes echo cancellation and noise suppression in the calling mode
- Includes voice prompts and easy pairing
- Provides high-quality sound
- Charges the batteries in two hours

Final flat size: 23.62 × 4.72 in. (600 × 120 mm)
Final fold size: 5.90 × 4.72 in. (150 × 120 mm)



#	DESCRIPTION	FUNCTION
1	Ear hooks	Place the ear hooks over your ears.
2	Sensor touchpad	Tap to control phone calls and music playback and activate siri.
3	Microphone	Speak into the microphone when on a phone call.
4	Earbud LED	Indicates the power, pairing status, low battery, and reset states. See CONTROLLING YOUR EARBUDS.
5	Charging contact area	When charging the battery, make sure that this contact is face down in the charging case.
6	Ear tips	Insert the ear tips into your ears.
7	MFB button	Press to turn your earbuds on or off or to enter paring mode. With your earbuds turned off, press and hold for more than five seconds to reset your earbuds and clear all pairing information.
8	Charging case LED	White LED light turns on for five seconds to indicate battery charge level. Indicates the battery charge level. When your earbuds are in the charging case, the LED lights red while charging and turns off when charging is complete.
9	Charging case button	Press to check the battery charge level. The charging case LED lights turn on. One light indicates the battery charge level is low. Four lights indicate that the batteries are fully charged.
10	Micro USB port	Connect the USB cable to this port and to a USB port on a computer to charge the batteries.
11	Slave Earbuds	L is Slave Earbuds
12	Master Earbuds	R is Master Earbuds

CONTROLLING YOUR EARBUDS

ACTION	OPERATION	LED	SOUND
Turn on	When your master and slave earbuds are turned off, press and hold the MFB button for more than two seconds to turn them on.	The red LED lights for 1.5 seconds.	power on
Turn off	When your master and slave earbuds are turned on, press and hold MFB button for more than three seconds to turn them off.	The red LED lights for 1.5 seconds.	power off
Pairing mode	When your master earbuds are turned off, press and hold the MFB button for more than four seconds to enter pairing mode. When your slave earbuds are turned off, press and hold the MFB button for more than two seconds to turn them on, then it will connect with master earbuds automatically.	The LED blinks blue and red alternately when master earbuds pairing. The blue LED blink for every 6 seconds once it is connected. The blue LED slow blink(2 times/s) when slave earbuds connecting. The blue LED blink for every 6 seconds once it is connected.	Your device is connected
Automatic connect after power on	The master earbuds automatic connect to last device after turn on if have paired when can't connect to last device after 10S will enter pairing mode.	Blue LED slow blink(2 times/s) until connected.	Your device is connected
Volume control	Use your MP3 player, phone, or computer to control the volume.		
Incoming call		Blue LED blinks three times every six seconds.	Ring tone
Answer or end a call	Tap the master or slave sensor touchpad on either earbud once.		Two long beeps
Reject call	Tap the master or slave touchpad on either earbud twice.		Two long beeps
Reset	When your master earbuds are turned off, press and hold the MFB button for more than eight seconds. Your master earbuds remove existing pairing information.	The LED blinks blue and red alternately for 1.5 seconds.	
Playing audio	Tap the master or slave sensor touchpad once to start or pause playback. Tap the sensor touchpad twice to go to the next track.	Blue ramping LED flashes for six seconds	

CHARGING THE BATTERIES

When the red LED blinks three times a minute and you hear“battery low,”you need to charge the batteries.

- 1 Connect the USB cable to the charging case and to a USB port on a computer.
- 2 Place both earbuds into the charging case. Make sure that the charging contract areas are face down and closed charging case door. The LED lights red while charging and turns off when charging is complete.

PAIRING YOUR EARBUDS

Notes:

- Range is 33 feet (10 meters)
- Supports easy pairing
- Prompts you by saying “Your device is connected,”when connected
- Supports a battery indicator icon on an iOS device

Connect with a cell phone or MP3 player

- 1 With your master earbuds turned off, press and hold the MFB button for four seconds. The LED blinks blue and red alternately.
- 2 On your phone or MP3 player, select INSIGNIA NS-CAHBTAP from the list of discovered devices, then enter the password 0000 (four zeros) (if required) to pair your master earbuds. For more information on pairing Bluetooth devices to your cell phone or MP3 player, see the device's documentation. Note: After you successfully pair your master earbuds to a phone or MP3 player, you master earbuds automatically reconnect to the phone or MP3 player.
- 3 With your slave earbuds turned off, press and hold the MFB button for more than two seconds to turn them on, The blue LED slow blink(2 times/s), then it will connect with master earbuds automatically.

Connect with a computer running Windows

Note : Before you pair your master earbuds with the computer, make sure that the computer is equipped with Bluetooth. Refer to the computer’s documentation or contact the computer manufacturer for more information. If your computer is not Bluetooth-compatible, install a Bluetooth USB adapter (dongle).

- 1 Turn on Bluetooth on the computer. For instructions, see the computer's documentation or contact the computer manufacturer.
- 2 Double-click the Bluetooth icon in the system tray, then click Add a device
- 3 With your master earbuds turned off, press and hold the MFB button for four seconds. The LED blinks blue and red alternately. Pairing mode is activated.
- 4 Double-click the INSIGNIA NS-CAHBTAP icon on the computer or highlight the icon, then click Next Note: If you are unable to locate the INSIGNIA NS-CAHBTAP icon, click the Search Again button.
- 5 If required, enter 0000 (four zeros) in the Bluetooth security code field, then click Next
- 6 After your master earbuds have been paired, click Close Note: To make your master earbuds the default playback device, see the computer's documentation or contact the computer manufacturer.
- 7 With your slave earbuds turned off, press and hold the MFB button for more than two seconds to turn them on, The blue LED slow blink(2 times/s), then it will connect with master earbuds automatically.

Connect with a Mac computer

Note: Before you pair your master earbuds with the computer, make sure that the computer is equipped with Bluetooth. Refer to the computer’s documentation or contact the computer manufacturer for more information. If your computer is not Bluetooth-compatible, install a Bluetooth USB adapter (dongle).

- 1 Turn on Bluetooth on the computer. For instructions, see the computer's documentation or contact the computer manufacturer.
- 2 Click the Bluetooth status menu.
- 3 Click Set up Bluetooth Device. The Bluetooth Setup Assistant opens.

Before using your new product, please read these instructions to prevent any damage.

- 4 Click **Continue**.
- 5 Select **Headset** as the device type, then click **Continue**.
- 6 With your **master** earbuds turned off, press and hold the **MFB** button for four seconds. The LED blinks blue and red alternately. Pairing mode is activated.
- 7 Select **INSIGNIA NS-CAHBTAP**, then click **Continue**. The computer gathers information.
- 8 Click **Continue**.
- 9 Enter **0000** (four zeros) into the **Passkey** field, then click **Continue**.
- 10 Click **Quit** to finish.
- Note:** To use your **master** earbuds, they must be selected as the default input and output device on the computer.
- 11 Click **System Preferences**, then click **Sound**.
- 12 Under **Input**, select **INSIGNIA NS-CAHBTAP**, then under **Output**, select **INSIGNIA NS-CAHBTAP**.
- 13 With your slave earbuds turned off, press and hold the MFB button for more than two seconds to turn them on, The blue LED slow blink(2 times/s) , then it will connect with master earbuds automatically.

RESETTING YOUR EARBUDS

- With your**master** earbuds turned off, press and hold the **MFB** button for **eight** seconds. The LED blinks blue and red alternately for 1.5 seconds when entering pairing mode .
- [REVIEWERS: Can these earbuds pair with multiple devices at the same time? If yes, how?][NO.]

SPECIFICATIONS

Bluetooth version:	Bluetooth 4.1
Wireless between ears:	NFMI (10.579 MHz)
Microphone noise cancellation:	Yes
Earphone channel:	Stereo
A2DP:	SBC, MP3, and AAC
Time delay (master to slave):	<=300ms
RF distance (IP6S)(master to device):	> 33 ft. (10 m)
Connection distance(slave to master):	>= 0.72 ft.(22cm)

Earbuds size:	.9 × .8 × .7 in. (23.5 × 19.8 × 16.7 mm)
Earbuds weight:	0.63 oz (18 g)
Playing time:	5 hours
Battery size:	Master: 3.7V/115mAh Slave: 3.7V/55mAh
Phone call:	Click Touch Pad
Charging time:	2 hours
Docking Cycle Charging with earbuds	3 times

TROUBLESHOOTING

PROBLEM	SOLUTION
No power	• Make sure that the master and slave earbuds' batteries are charged. • Make sure that your master and slave earbuds are turned on.
No sound or low volume	• Shorten the distance between your master earbuds and your Bluetooth device. • Make sure that your Bluetooth device is turned on, Bluetooth is turned on, and NS-CAHBTAP is selected. • Turn up the volume on your Bluetooth device. Make sure that your Bluetooth device is not muted. • Make sure that your master earbuds are not paired to another Bluetooth device. • Make sure that your Bluetooth device is not paired to another Bluetooth device.
Cannot establish Bluetooth connection	• Make sure that your master earbuds are in pairing mode. Press and hold the MFB button for four seconds to re-enter pairing mode. • Shorten the distance between your master earbuds and your Bluetooth device. • Turn your devices off, then on. Re-pair yourmaster earbuds and your Bluetooth device. • Make sure that yourmaster earbuds are not paired to another Bluetooth device. • Make sure that your master earbuds and Bluetooth device are both in pairing mode. • Make sure that your Bluetooth device supports Bluetooth v4.0. • Make sure that your Bluetooth device is not connected to any other device. • Make sure that you have selected NS-CAHBTAP on your Bluetooth device.
My Bluetooth device keeps unpairing	• Shorten the distance between your master earbuds and your Bluetooth device. • If the battery on your Bluetooth device is low, recharge the battery. • If the batteries on your master and slave earbuds are low, recharge the batteries.
NS-CAHBTAP does not appear on my Bluetooth device	• Shorten the distance between your master earbuds and your Bluetooth device. • Put yourmaster earbuds into pairing mode, then refresh your list of Bluetooth devices. For more information, see the documentation that came with your Bluetooth device.
Poor sound quality	• Shorten the distance between your master earbuds and your Bluetooth device. • Try a different music source. • Pair your master earbuds to a different device. • Try changing the volume on your Bluetooth device.

LEGAL NOTICES

FCC statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RSS-Gen & RSS-247 Statement:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RSS-102 Statement

This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme à l'exposition aux rayonnements Industrie Canada limites établies pour un environnement non contrôlé.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2018 Best Buy. All rights reserved.
Made in China