

1. External Photograph of EUT

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100





Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100



**2. Photograph of Accessory****Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100**

Specification of Accessory		
Battery	Brand Name	Zebra
	Model Name	BT000296A01
USB Cable	Brand Name	Zebra
	Model Name	HS3100-CHUC1-01

Remark: For accessories equipped with this EUT, please refer to the following photos.



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100






Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100

