

ATTEN 20dB

RL 55.0dBm

10dB/


MKR 50.83dBm

869.45MHz

EDGE 120W
PWR OUTPUT LOW

MKR
869.45 MHz
50.83 dBm

R



CENTER 869.45MHz

*RBW 1.0MHz

*VBW 1.0MHz

SPAN 10.00MHz

SWP 50.0ms

ATTEN 20dB

RL 55.0dBm

10dB/


MKR 50.83dBm

881.50MHz

EDGE 120W
PWR OUTPUT MID

MKR
881.50 MHz
50.83 dBm

R



CENTER 881.50MHz

*RBW 1.0MHz

*VBW 1.0MHz

SPAN 10.00MHz

SWP 50.0ms

ATTEN 20dB

RL 55.0dBm

10dB/


MKR 50.83dBm

893.55MHz

EDGE 120W
PWR OUTPUT HIGH

MKR
893.55 MHz
50.83 dBm

R



CENTER 893.55MHz

*RBW 1.0MHz

*VBW 1.0MHz


SPAN 10.00MHz

SWP 50.0ms

ATTEN 10dB
RL 50.6dBm


10dB/

Δ MKR -.34dB
300kHz



CENTER 869.450MHz SPAN 1.000MHz
*RBW 3.0kHz *VBW 3.0kHz SWP 280ms

ATTEN 10dB
RL 50.6dBm 10dB/ ΔMKR .16dB
300kHz




CENTER 881.500MHz SPAN 1.000MHz
*RBW 3.0kHz *VBW 3.0kHz SWP 280ms

ATTEN 10dB
RL 50.6dBm


10dB/

ΔMKR 0dB
300kHz




CENTER 893.550MHz
*RBW 3.0kHz *VBW 3.0kHz SPAN 1.000MHz
SWP 280ms

ATTEN 10dB ΔMKR -.66dB
RL -1.6dBm 10dB/ 300kHz




CENTER 869.450MHz SPAN 1.000MHz
*RBW 3.0kHz *VBW 3.0kHz SWP 280ms

ATTEN 10dB ΔMKR -1.16dB
RL -1.6dBm 10dB/ 300kHz



CENTER 881.500MHz SPAN 1.000MHz
*RBW 3.0kHz *VBW 3.0kHz SWP 280ms

ATTEN 10dB ΔMKR -.83dB
RL -1.6dBm 10dB/ 300kHz



CENTER 893.550MHz SPAN 1.000MHz
*RBW 3.0kHz *VBW 3.0kHz SWP 280ms


ATTEN 10dB

RL 0dBm

10dB/

MKR -80.00dBm

846.0MHz



CENTER 881.5MHz

*RBW 30kHz

*VBW 30kHz

SPAN 100.0MHz

SWP 280ms

ATTEN 10dB
RL 52.2dBm


10dB/

MKR -22.47dBm
846.0MHz

EDGE 120W IMD
OUT OF BAND

DISPLAY LINE
-13.0 dBm

R



CENTER 881.5MHz
*RBW 30kHz *VBW 30kHz SPAN 100.0MHz
SWP 280ms

*ATTEN 10dB

RL 52.2dBm

10dB/


MKR -22.80dBm

844.8MHz

EDGE 120W IMD
OUT OF BAND

DISPLAY LINE
-13.0 dBm

R



START 30.0MHz

STOP 1.0000GHz

*RBW 30kHz

*VBW 30kHz

SWP 2.70sec

