FRONT

for use with

8 Bluetooth

enabled devices

iJOľ

Quest USA CORP

Made in China

•BATTERY CAUTION

•BATTERY DISPOSAL

495 Flatbush Ave Brooklyn, NY 11225

our website www.goijoy.com & register this product

Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic sub-

stances. Always confirm the temperature is 41° Fahrenheit before you

change the battery. Never expose the battery to any liquid. Never ex-

pose the battery to excessive heat such as direct light or fire. Always keep the battery out of the reach of infants and small children

Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing

batteries/electronics. If there are no local regulations concerning bat-

tery/electronics disposal, please dispose of the device in a waste bin for

electronic devices. Many electronics retailers now recycle batteries and

community regulations that apply to the disposal of

other electronic components at no charge

DEPENDING TRUE WIRELESS EARBUDS

Thank you for purchasing and using the "IJOY BUDZ" wireless bluetooth®

earbuds with case. This product can provide a high quality listening expe-

rience for your mobile phone, computer and other media devices. Before using this product, carefully read this manual to correctly operate this

device. Please ask your local dealer if you have any questions

USER

MANUAL

•YOUR IJOY PRODUCT

Mini Bluetooth Earbuds X 2

Model: IJFTW01
Chipset: JL 6963
Bluetooth Version: V 5.1

Play time: 2-3 hoursBluetooth Distance :10 M


Charging port: LightningCharging time: 1.5 hours

Driver Size: 10mm

• Earbuds battery: 300mah + 35mah*2

Charging Case X 1 USB Charging Cable X 1 User Manual X 1

•SPEC



To avoid danger of choking, please keep cables away from babies and children. This product is not a toy. Do not treat this product as household waste. Dispose of this device properly by handing it over to local collection services for recycling of electronic equipment. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item X

•LIMITED LIFETIME WARRANTY

Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 24 months does not apply to decreases in the effective capacity caused by its use or age. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit, www.goijoy.com,

PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE SIDED. DO NOT PRINT GREEN LINES

BACK

INSTRUCTIONS	
 POWERING ON/OFF Press the button on the back. Blue lights should lit from the case Take the earbuds out. Blue and red lights should be flashing from the earbuds. If this does not work, try charging the case with the earbuds inside. Connect the USB charger to the port on the bottom of the case and a power source. The earbuds will turn off automatically after being disconnected from the Bluetooth device for 5 minutes SKIPPING TRACKS To play the last song: tap • twice To play the next song: tap • twice ANSWERING/ENDING PHONE CALLS To answer or hang up the phone: tap either • or • once CHARGING The earbuds will automatically charge when inside the case Place the earbuds inside the case and close the case. Use the USB charging cable provided and connect it to the port on the bottom of the case and a power source to charge both the case and the earbuds 	
FCC STATEMENT : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party respon- sible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruc- tions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television recep- tion, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.	on- - re is
RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction	

-