
## **APPENDIX C - EUT PHOTOGRAPHS**

## Base – Top View (Model: GH3150)



Base - Bottom View (Model: GH3150)



Base – Side View (Model: GH3150)



Base – Top View (Model: GH3110 & GH3100)





Base - Bottom View (Model: GH3110 & GH3100)

**Power Adapter – Top View** 

