



Tune-up Procedure

TRACGMT100UM004

Revision: 1.02





http://www.queclink.com

sales@queclink.com



Document Title	GMT100_Tune-up Procedure					
Version	1.02					
Date	2013-10-18					
Status	Release					
Document Control ID	TRACGMT100UM004					

General Notes

Queclink offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Queclink. The information provided is based upon requirements specifically provided to Queclink by the customers. Queclink has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Q ueclink within a larger electronic system remains the responsibility of the customer or the customer's system in tegrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Queclink Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai Queclink Wireless Solutions Co., Ltd. 2011

TRACGMT100UM004 -2-



Revision History

Revision	Date	Date Author Description of change									
1.01	2011-10-18	Owen Feng	Initial								
1.02	2013-10-20	Niu	Add RF table								

ante chink confinite confi

TRACGMT100UM004 -3-



Tune-up Procedure of GMT100

During manufacturing each phone will be individually calibrated.

The measurement is done in a fully calibrated setup, which is based on Agilent 8960 or RS CMU200 (TX power, AFC, DRP, LNA Gain.....).

Furthermore, the highest power level is verified afterwards in a call measurement on three channels (low, mid and high).

Procedure:

- 1. Set the module to ope rational voltage and on one certain channel in a special service mode by means of company proprietary software.
- 2. The actual power is measured at several power levels.
- 3. The gain factors of each individual phone are adjusted via the Board-test SW using automatic adjustment arithmetic until the target value is met.

The appropriate gain control settings are stored in RF table (a special section in Nor Flash marked with Read only and untouchable for end user) each phone individually (for each power level).

The user has no possibility to change these settings later on.

AT factory calibration , the target output power , low power limit and high power limit is As following table:

Table 1. GMT100 RF power table

Table 1. Civil 100 Pa power lable																
EGSM900																
PCL	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
Normal out power	32.5	31	29	27	25	23	21	19	17	15	13	11	9	7	5	
Low limit(dBm)	31.5	30	27	25	23	21	19	17	15	13	11	9	7	5	3	
High limit(dBm)	33.5	33	31	29	27	25	23	21	19	17	15	13	11	9	7	
GSM850																
PCL	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
Normal out power	32.5	31	29	27	25	23	21	19	17	15	13	11	9	7	5	
Low limit(dBm)	31.5	29	27	25	23	21	19	17	15	13	11	9	7	5	3	
High limit(dBm)	33.5	33	31	29	27	25	23	21	19	17	15	13	11	9	7	
DCS																
PCL	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

TRACGMT100UM004 - 4 -



GMT100_Tune-up Procedure

Normal out power	29.5	28	26	24	22	20	18	16	14	12	10	8	6	4	2
Low limit(dBm)	28	26	24	22	20	18	16	14	12	10	8	6	4	2	0
High limit(dBm)	30.5	30	28	26	24	22	20	18	16	14	12	10	8	6	4
PCS															
PCL	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14
Normal out power	29.5	28	26	24	22	20	18	16	14	12	10	8	6	4	2
Low limit(dBm)	28	26	24	22	20	18	16	14	12	10	8	6	4	2	0
High limit(dBm)	30.5	30	28	26	24	22	20	18	16	14	12	10	8	6	4

TRACGMT100UM004 - 5 -