

PRINT ARTWORK ON DIRECTLY ON PAPER.  
DO NOT PRINT RED FOLD AND CUT LINES. OPEN USER MANUAL DIMENSIONS: 6.46”W x 5.5” H



FOLD LINE




CUT LINE

ijoy

WIRELESS EARBUDS  
VELOCITY

FCC ID: 2AJG7VELOCITY  
ModelIJ10069-AMZN  
IJ10069-AMZN



USER  
MANUAL

for use with  
Bluetooth  
enabled devices

ijoy

QUEST USA CORP.  
495 Flatbush Ave Brooklyn, NY 11225

© GOIJOY & IJOY are registered trademarks of QUEST USA CORP.  
All other trademarks and trade names are property of their  
respective owners.  
Designed by GOIJOY & IJOY in New York. All rights reserved QUEST USA  
CORP.

One (1) year limited warranty. To activate your product warranty go to our  
website [www.goijoy.com](http://www.goijoy.com) & register this product.

Made in China.

•YOUR IJOY PRODUCT

Thank you for purchasing and using the “IJOY VELOCITY” Wireless  
Earbuds. This product can provide a high quality listening experience  
through phones, computers, and multimedia. Before using this product,  
carefully read this manual to in order to operate at maximum benefit.  
Please ask your local dealer or call us if you have any questions.

WIRELESS EARBUDS x1  
Charging Cable x1  
User Manual x1

•PRODUCT SPECIFICATIONS

- PLAYTIME: 100% VOLUME ~3-4HRS; 50%-4-5HRS
- CHARGE TIME: 1.5 HRS
- BATTERY CAPACITY: 180 MAH
- FEATURES: BT/LED
- BLUETOOTH VERSION: 5.0
- CHIPSET JIELI
- MATERIAL ABS

•BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion  
or chemical burn if used incorrectly. Never use or charge the  
battery if it appears to be leaking, discolored, deformed or in any  
way abnormal. Never disassemble the unit or attempt to remove  
the battery as that could cause leakage of alkaline solution or  
other electrolytic substances. Never expose the battery to any  
liquid. Never expose the battery to excessive heat such as direct  
light or fire. Always keep the battery out of the reach of infants  
and small children.

•BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery  
has died, you should follow the disposal instructions listed here.  
Never dispose of used batteries/electronics with ordinary solid  
wastes. Always dispose of used batteries/electronics in accordance  
with the prevailing community regulations that apply to the disposal  
of batteries/electronics. If there are no local regulations concerning  
battery/electronics disposal, please dispose of the device in a waste  
bin for electronic devices. Many electronics retailers now recycle  
batteries and other electronic components at no charge.

•PAIRING YOUR PRODUCT

Using the controls on your Bluetooth device, select **IJOY VELOCITY**  
in the Bluetooth Settings to pair. A beep sound will be heard when  
the bluetooth device is connected successfully.

•PLAYING AUDIO

- 1.Play / Pause Music: Short press the button once/finger touch
- 2.Previous/Next Track: Double press the left/right button
- 3.Volume – / Volume + : Short press three times the left/right button
- 4.Answer / Hang Up a Call: Short press Button during calling
- 5.Siri or Voice assistant: Long press 3 seconds the left/right button

•FCC ID STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the  
following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference  
that may cause undesired operation.  
Warning: Changes or modifications not expressly approved by the party  
responsible for compliance could void the user’s authority to operate the  
equipment.

NOTE: This equipment has been tested and found to comply with the limits for  
a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are  
designed to provide reasonable protection against harmful interference in a  
residential installation. This equipment generates uses and can radiate radio  
frequency energy and, if not installed and used in accordance with the  
instructions, may cause harmful interference to radio communications. However,  
there is no guarantee that interference will not occur in a particular installation.  
If this equipment does cause harmful interference to radio or television  
reception, which can be determined by turning the equipment off and on, the  
user is encouraged to try to correct the interference by one or more of the  
following measures:

Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver. Connect the  
equipment into an outlet on a circuit different from that to which the receiver is  
connected.  
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:  
The device has been evaluated to meet general RF exposure requirement. The  
device can be used in portable exposure condition without restriction.

•OTHER IMPORTANT SAFETY INFORMATION

Disposal of old electronic & electronic equipment (Applicable in the  
European Union and other European Counties with separate collection  
systems) The trash can symbol (seen on the bottom) on the  
production indicates that this product shall not be treated as  
household waste. Instead it shall be handed over to the applicable  
collection point for recycling of electronic equipment. By ensuring this  
product is disposed of correctly, you will help prevent potential  
negative consequences for the environment and human health, which  
could otherwise be caused by inappropriate waste handling. For more  
detailed information about this product, please contact your local  
household waste disposal service or the shop where you purchased  
this item.



IMPORTANT REMINDERS

This device can ONLY be charged by 5V adapters/  
USB ports only. Quick charging devices over 5V  
may cause heat and fire.



•ONE (1) YEAR LIMITED WARRANTY

Our product is warranted for a One (1) year limited warranty from  
the date of purchase. The warranty is provided on all material defects  
and workmanship. Guarantee of 12 months does not apply to decrease  
in the accumulator’s effective capacity caused by its use or age.  
Effective capacity gradually decreases depending on the method of  
use of the accumulator. **WE RESERVE THE RIGHT TO CHANGE  
TECHNICAL SPECIFICATIONS.** For more information please visit,  
[www.goijoy.com](http://www.goijoy.com)

TIP: Must use a formal manufactured certified charger. If the power  
bank has not been used for a significant amount of time, please make  
sure to charge before using the product.

•WARNING

At full volume, prolonged listening may lead to a ruptured eardrum (temporary or  
permanent deafness, hearing drone, tinnitus, hyperacusis). Please listen at a  
medium-low volume and no more than one hour a day

Please insert the proper battery needed correctly to prevent explosion.