



802.11be-EHT80 - Ant 0

Channel 103 (6465MHz)

The Reference Level




The Mask Data




Channel 119 (6545MHz)

The Reference Level




The Mask Data




Channel 135 (6625MHz)

The Reference Level




The Mask Data




802.11be-EHT80 - Ant 0

Channel 151 (6705MHz)

The Reference Level




The Mask Data




Channel 167 (6785MHz)

The Reference Level




The Mask Data




Channel 183 (6865MHz)

The Reference Level




The Mask Data




802.11be-EHT80 - Ant 0

Channel 199 (6945MHz)

The Reference Level



The Mask Data




Channel 215 (7025MHz)

The Reference Level




The Mask Data




802.11be-EHT160 - Ant 0

Channel 15 (6025MHz)

The Reference Level




The Mask Data




Channel 47 (6185MHz)

The Reference Level



The Mask Data




Channel 79 (6345MHz)

The Reference Level




The Mask Data




802.11be-EHT160 - Ant 0

Channel 111 (6505MHz)

The Reference Level




The Mask Data




Channel 143 (6665MHz)

The Reference Level



The Mask Data




Channel 175 (6825MHz)

The Reference Level




The Mask Data




802.11be-EHT160 - Ant 0

Channel 207 (6985MHz)

The Reference Level



The Mask Data



802.11be-EHT320-1 - Ant 0

Channel 31 (6105MHz)

The Reference Level




The Mask Data



Channel 95 (6425MHz)

The Reference Level



The Mask Data



Channel 159 (6745MHz)

The Reference Level




The Mask Data



802.11be-EHT320-2 - Ant 0

Channel 63 (6265MHz)

The Reference Level




The Mask Data



Channel 127 (6585MHz)

The Reference Level




The Mask Data



Channel 191 (6905MHz)

The Reference Level




The Mask Data




802.11a - Ant 1

Channel 1 (5955MHz)

The Reference Level




The Mask Data




Channel 49 (6195MHz)

The Reference Level



The Mask Data




Channel 93 (6415MHz)

The Reference Level




The Mask Data




802.11a - Ant 1

Channel 97 (6435MHz)

The Reference Level




The Mask Data




Channel 105 (6475MHz)

The Reference Level




The Mask Data




Channel 113 (6515MHz)

The Reference Level




The Mask Data




802.11a - Ant 1

Channel 117 (6535MHz)

The Reference Level




The Mask Data




Channel 149 (6695MHz)

The Reference Level



The Mask Data




Channel 181 (6855MHz)

The Reference Level




The Mask Data




802.11a - Ant 1

Channel 185 (6875MHz)

The Reference Level




The Mask Data




Channel 189 (6895MHz)

The Reference Level




The Mask Data




Channel 209 (6995MHz)

The Reference Level




The Mask Data




802.11a - Ant 1

Channel 229 (7095MHz)

The Reference Level




The Mask Data




802.11ax-HE20 - Ant 1

Channel 1 (5955MHz)

The Reference Level




The Mask Data




Channel 49 (6195MHz)

The Reference Level




The Mask Data



Channel 93 (6415MHz)

The Reference Level




The Mask Data




802.11ax-HE20 - Ant 1

Channel 97 (6435MHz)

The Reference Level




The Mask Data




Channel 105 (6475MHz)

The Reference Level



The Mask Data



Channel 113 (6515MHz)

The Reference Level



The Mask Data

