

Model:WF86 wolki WWW.WOLKMOBILE.COM Start Here	Thanks For Choosing WOLKI Mobile Model WF86. MENU SMS Messages: Write Message/Edit the content/Outbox/Draft You have created SMS and MMS, when the message is finished you can send it to SMS or MMS. Read and modify the messages stored in the Outbox of SMS and MMS then modify sent or delete the messages. Call Settings: Setup the current SIM card (Select SIM2 Settings). Call transfer and call waiting and other functions can be setup the menu. Phone Book: Add a new contact record. Copy contacts: Provide two ways displaying from SIM1/SIM2 card to mobile and from mobile to SIM1/SIM2 card. Transfer: Choose all of the records in the SIM1/SIM2 card, or delete items one by one. User Profiles: Select silent, vibrate, loud, normal. Audio Player: Play audio and music files. 1	Multimedia Image Viewer: View or modify photos saved in the album. Video Recorder: Enter options menu to extend save these settings. Press the OK key to save settings and press again when you want to save the video. Video Player: Press this key can send out video file via BT. Storage: Select to play the video files in the phone or memory. FM Radio: This phone support the wireless FM radio function, choose and receive the programs and you also can listen the wireless. Press the left/right direction key to search the channel at the FM radio player. File Manager: Mobile You can manage by saving several folders in this menu and transfer, copy and move files/folders between. Memory: Provides the T-flash card support. 2	Organization Calendar: To access the Calendar, The first row displays year and month, the second row displays week, the middle part displays dates for a specific month, and the last row displays the time left time. Alarm: You can set 5 alarm times with this mobile. For each of them, you can set the alarm clock to be open or not, set the alarm time and alarm frequency (once, daily or for repeat) and optional tones. Calculator: This phone supports four arithmetic operations. The operation of calculator is simple, practical and convenient. Network Settings: STC The full name is SIM card application tool kit (SIM Application Toolkit) it is a new function, which provides flexible information for you, such as stock information, traffic information, weather forecast and so on. The function of STC is determined by network operator. This function needs the support of SIM card and network. 3	Setting Dual SIM card settings: Set SIM1/SIM2 choose to open the both SIM card phone settings. Language: Display language for your mobile, language can be changed using the touch screen setting. Phone lock: Activate or deactivate the keypad lock and lock duration. Key lock: Choose whether to activate the keypad and select the time to restrict the same key lock function. Press the left key and then press "F" key within 2 seconds. Change the Pin Number: Setup the new password in this phone. Default settings: Restore the default setting of the phone. You need to enter the phone password, the default password "0000" or "1234" or "1232". 4	FCC Warning: Any Changes or modifications not expressly approved by the party responsible for compliance should void the user's warranty. To operate the equipment this device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Notes: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 5	Recycle or recycle the unwanted antenna. ---Increase the separation between the equipment and receiver. ---Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. ---Consult the dealer or an experienced radio/TV technician for help. Specific Absorption Rate (SAR) Information: SAR tests are conducted using standard operating procedures accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Before a new mobile phone is available for sale to the public, it must be tested and certified by the FCC. SAR data and related test procedures are maintained by the FCC. Tests for each phone are performed in positions and locations: On top of the ear and next to the body as required by the FCC for body worn operation. With recent phone has been tested and meets the FCC RF exposure guidelines when used with an antenna designed for the product or when used with an antenna that complies with FCC and that provides the handset a minimum of 1.0 cm from the body. Noncompliance with the above restrictions may result in violation of FCC exposure guidelines. 6
Gracias por elegir el modelo WOLKI WF86. MENU SMS Messages: Escribir mensaje / Editar el contenido / Borradores Tanto los mensajes de SMS y MMS. Cuando termine el mensaje, puede enviarlo por SMS o MMS. Lea y modifique los mensajes almacenados en la bandeja de salida de SMS y MMS (los mensajes se envían o eliminan los mensajes). Ajuste de llamadas: Configure la tarjeta SIM actual (seleccione SIM1 / SIM2) transferencia de llamadas y transferir de respuesta y otras funciones pueden configurarse en el menú. Copiar contactos: Agregar un nuevo registro de contacto. Transferir: Seleccione una forma de copiar desde la tarjeta SIM1 / SIM2 a móvil y desde el móvil a la tarjeta SIM1 / SIM2. Borrar: Elimine todos los datos en SIM1 / SIM2 o elimine elementos uno por uno. Tono: Seleccione Silencio, vibrar, alto, normal. Reproductor de audio: Reproducir archivos de audio y música. 7	Multimedia Visual de imágenes: Ver o modificar las fotos guardadas en el álbum. Grabación de vídeo: Tipos de vídeo de cámara para configurar y guardar una configuración. Flujo de vídeo: Para comenzar a grabar y presionar nuevamente cuando desea pausar o video. Reproductor de vídeo: Reproducir: Reproducir los archivos de vídeo. Eliminar: Puede eliminar el archivo de vídeo a través de BT. Almacenamiento: Información para reproducir los archivos de vídeo en el teléfono. Radio FM: Este teléfono es compatible con la función de radio FM independiente, sintoniza y recibe estaciones de radio y también puede transferir o descargar. Presione la tecla de dirección izquierda / derecha para buscar o cancelar el reproductor de radio FM. Administrador de archivos: Múltiple puede administrar agregando varios carpetas en este menú transferir, copiar y eliminar archivos. Eliminar: proporcione soporte para tarjetas de memoria. 8	Organización Calendario: Para acceder al calendario, la primera fila muestra el año y el mes, la segunda fila muestra la semana, la parte central muestra la fecha para un mes específico y la última fila muestra los días festivos programados. Alarmas: Puede configurar 5 horas de alarma con este móvil. Para cada una de ellas, puede configurar el método de la alarma para que esté abierto o no, configure la hora y la frecuencia de la alarma (una vez, diariamente o para varias fechas automáticas). Calculadora: Este teléfono admite cuatro operaciones aritméticas. El funcionamiento de la calculadora es simple, práctico y conveniente. Servicio de STC: El número completo es KIT de herramientas de la aplicación SIM. Este servicio necesita el soporte de la tarjeta SIM y la red. 9	Ajustes Ajustes de Dual SIM: Elige entre las dos tarjetas del teléfono de la tarjeta SIM. Modo de espera: Restablece el estado de espera. El sistema se puede cambiar usando la configuración de idioma. Revisión de batería: Elige si desea activar el bloqueo y seleccionar el tiempo para bloquear. Presione la tecla extra Media y luego presione la tecla de destino de 2 segundos. Cambio de contraseña: Configure la nueva contraseña en el teléfono. Restaurar la fábrica: Restaurar la configuración predeterminada del teléfono. Cuando ingrese la contraseña del teléfono, la contraseña predeterminada es 0000 o 1234 o 1122. 10	Advertencia de la FCC: Cualquier cambio o modificación no aprobada expresamente por la parte responsable del cumplimiento, podría anular la garantía del usuario para equipar. Este dispositivo cumple con la parte 15 de la normativa de la FCC. El funcionamiento está sujeto a las dos condiciones siguientes: (1) Este dispositivo no puede causar interferencias perjudiciales, y (2) este dispositivo debe aceptar cualquier interferencia no intencional, incluyendo la interferencia que pueda provocar el funcionamiento no deseado. Nota: Este equipo ha sido probado y cumple con los límites para los dispositivos digitales de Clase B, según la parte 15 de las normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable frente a la mayoría de las interferencias perjudiciales en un entorno residencial. Este equipo genera, utiliza y puede recibir energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias dañinas a la radio comunicaciones. Sin embargo, no hay garantía de que no se produzcan interferencias con un instalador particular. Si este equipo causa interferencias perjudiciales en la recepción de radio o televisión, el usuario puede intentar algunas medidas y procedimientos, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas: 11	Recomiendo a reducir la antena receptora. Aumentar la separación entre el equipo y el receptor. Conectar el equipo a una línea de corriente en un circuito distinto al que el otro está conectado al receptor. Consultar al distribuidor por un servicio de servicio para obtener ayuda. Nota de declaración específica (SAR): Las pruebas de SAR se realizan en condiciones de funcionamiento estándar aceptadas por la FCC con el teléfono. Seleccionar la posición de la cabeza de la persona ubicada en la base de la cabeza de la frecuencia prohibida. Antes de que un nuevo modelo de teléfono esté disponible para la venta al público, debe ser probado y certificado ante la FCC que no excede el nivel de exposición establecido por la FCC, pruebas para cada teléfono en posición de portabilidad y ubicación de uso típico, en un estado de uso o en un estado de espera por la FCC. Para cumplir con el SAR, este modelo de teléfono ha sido probado y cumple con los límites con un aumento de SAR de 1.0 cm desde la cabeza, una distancia mínima de 1.0 cm desde la cabeza. El cumplimiento de las restricciones anteriores puede resultar en violación de las restricciones de exposición RF. 12	

2019 All rights reserved©WOLKI MOBILE. Tel: +91-9620321324-15 Printed in China