

封底背面

3 1MORE MUSIC APP

中国内地用户可扫描二维码,下载 1MORE MUSIC APP

进行产品升级,体验更完整的功能。





语音助手,

语音助手

自动暂停/播放功能 播放时取下耳机,播放自动暂停; 再次戴上, 自动续播。

三击

\* 上述功能适用于单、双模式使用时的任一耳机。 \* 以上功能定义因设备不同可能略有差异。







# 公子与300万层的300年; 不符合《产品性能故障表》所列性能故障的情况; 因人为原因导致本产品及其配件产生《产品性能故障表》所列性能故障; 产品附送的任何配件或赠品。 更多服务可登录 1MORE 官方网站 www.1more.com 点击"服务"项或咨询服务热线: 400-992-0909

环保支持 产品中有害物质的名称和含量

有害物质

六价铬

多溴联苯

多溴二苯醚

(PBDE)

0 0

未经授权的维修、误用、碰撞、疏忽、滥用、进液、事故、改动、不正确的使用非本产品配件,或期段、涂改标贴、防伪标记;
 已超过一年保修期;
 因不可抗力造成的损坏;

		(PD)	(Hg)	(Ca)	(Crvi)	(PBB)
	耳机外壳	0	0	0	0	0
	电路板及组件	×	0	0	0	0
	电池	×	0	0	0	0
	耳套	0	0	0	0	0
	配件	0	0	0	0	0

表 镉

# 充电线

●请避免产品与液体接触;

- ●请勿以任何理由拆开、维修或改装耳机,否则可能会导致起火甚至彻底损坏本产品; ●请勿将设备置于温度过低或过高(0℃以下或者45℃以上)的环境下; ●请勿在雷暴天气下使用本产品,雷暴可导致设备工作异常,并增加触电的危险;

●请勿用酒精及其它挥发性液体擦拭本产品;

●请勿试图拆卸、修理或修改本产品,否则可能导致火灾甚至完全损坏本产品; ●在使用本产品时,请将本产品的指示灯远离儿童和动物的眼睛; ●请勿在雷雨天气使用本产品。雷雨天气可能会导致产品故障,增加被电击的风险; ●请勿拆卸、刺穿、压碎本产品或将其暴露于火中;

●遵守所在地区或国家的相关规定,驾车时请勿使用本设备;

- ●如果皮肤接触部位出现红肿迹象,请立即停止使用并寻求医疗救助; 为了防止可能出现的听力损伤,请勿长时间用高音量使用本产品;
   为了防止可能出现的听力损伤,请勿长时间用高音量使用本产品;
- ●本设备并非玩具,可能包含部分小零件,请将设备及其配件放置儿童接触不到的地方; ●将电池放入火中或热烤箱中,或机械地粉碎或切割电池,可能导致爆炸;●将电池放在极高温的环境中,可能导致爆炸或易燃液体或气体泄漏; ●极低气压下的电池,可能导致爆炸或可燃液体或气体泄漏;
- ●产品信息和认证标志位于充电盒内; ●不要将电池放入垃圾填埋场处理的垃圾中。处理电池时,应遵守当地法律法规; ●更换型号不正确的电池,会破坏防护措施(如着火、爆炸、泄漏腐蚀性电解液等); ● ===符号表示直流电压;
- ●只使用由合格制造商提供的合格充电器;

●该设备内置电池,不能拆卸或更换。请勿自行拆卸或改装电池;

- FAQ 1. 耳机无法开机,该如何解决? 请确认耳机有电, 若耳机没有电, 请充电 30 分钟以上再开机。
- 2. 耳机与手机蓝牙无法正常连接,连接时间长,该如何解决?1) 如左、右耳机无法配对、仅一个耳机可与手机连接时,可将左、右耳机放入盒中,快速3击配对按钮,左、右耳机即可与手机连接。 2) 如需与新设备连接,开机且非通话状态下,将左、右耳机放回盒内,长按配对按钮 8 秒,选择 新设备名,耳机将与新设备进行蓝牙配对。

3. 安卓系统手机连接耳机成功后,无法听到音乐,该如何解决?

- 在耳机与手机连接成功后,点击所连接设备名称右边的图标,进入后确保"媒体音频"选项已被开启。 4. 在安卓系统手机连接耳机成功后,无法通话,该如何解决? 在耳机与手机连接成功后,点击所连接设备名称右边的图标,进入后确保"手机音频"选项已被开启。
- 5. 蓝牙连接不稳定, 出现断续情况, 该如何解决? 1)请尽量缩短设备与耳机之间的距离,避开实体障碍物; 2)请远离强干扰源环境(Wi-Fi/GPRS等); 3)请确保手机天线不被遮挡。
- 6. 使用第三方音乐播放软件时,为什么部分操控功能与说明书定义不一致? 1) 手机软件与第三方软件因定义不同而导致耳机操控功能有差异; 2) 建议使用品牌手机系统自带音乐播放器。 7. 调节耳机音量到最大后,声音仍偏小,该如何解决? 在不同的手机操作系统内(如安卓),耳机音量加减功能与手机音量加减功能是独立操作状态,
- 请根据您的具体需求,分别调节手机及耳机的音量。 8. 初次使用 1MORE MUSIC APP,无法正常连接对应的耳机,该如何解决? 安卓手机用户进入 1MORE MUSIC APP 界面时,请选择"始终允许"获取设备的定位信息。

\* 更多更细节的产品实际使用问题解析,请登录 1MORE 官方网站"技术支持"项进行查询。










耳机置于盒中,开盖即左、右自动配对。



耳机与蓝牙设备配对连接

- \*上述功能适用于单、双模式使用时的任一耳机。

电量提示







# 1.7日无理由的退货(电商渠道),由用户承担物流费用; 2.免费维修或以换代修的产品的保修期仍然技原始产品的购买日期计算一年免费保修期。 3.本产品出现《产品性能故障表》所列性能故障的情况,经检测确定后,可以免费享受如下 服务类型

修理、换货、退货应当凭相关订单号或发票办理。

服务政策 退货 自签收次日起 7 天内产品质量原因退货 自签收次日起 15 天内产品质量原因换货 换货 自签收次日起 1 年内产品质量原因维修 维修

产品性能故障表 性能故障



本表格依据 SJ/T 11364 的规定编制。 〇:表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。 ×:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。 **(11)** 本标识内的数字表示产品(除电池外)在正常使用状态下,环保使用期限为 10 年。 本标识内的数字表示电池在正常使用状态下,环保使用期限为5年。 部件上的环保使用年限标识优先于产品上任何与之相冲突或不同的环保使用期限标识。本产品 所有环保使用期限是指在产品说明书规定的使用条件下使用本产品不发生有毒有害物质泄露的 安全年限。

提示 1. 使用产品前请仔细阅读本使用说明书并请妥善保管; 2. 首次使用,请先将本产品充满电; 3. 如果产品长期(超过3个月)不使用,请对其充电; 4. 必须选择正规厂家生产的经过第三方权威机构认证的充电线和电源适配器;

5. 在干燥环境佩戴,静电可能会触到耳朵产生瞬间发麻的感觉,这与产品质量性能无关。

- ●若使用电源适配器充电时,应使用满足相应安全标准要求的电源适配器或 者使用获得 CCC 认

# 证的电源适配器; ●产品内含不可拆卸的锂电池,请勿自行更换电池,以免损坏电池或设备。 电池只能由授权服务中心更换且必须更换相同型号的电池。 错误型号电池 更换会有爆炸危险。请不要将旧电池扔进

方可继续使用。

- 生活垃圾中,并按当地要求处理 本设备及废旧电池。
- 微功率短距离设备声明 (-) 符合 "微功率短距离无线电发射设备目录和技术要求"中通用微功率设备 A 类设备技术要求, 用于无线充电。具体使用请参考使用说明书。 (二)不得擅自改变使用场景或使用条件、扩大发射频率范围、加大发射功率(包括额外加装射频
- 功率放大器),不得擅自更改发射天线。 (三) 不得对其他合法的无线电台(站)产生有害干扰,也不得提出免受有害干扰保护。 (四) 应当承受辐射射频能量的工业,科学以及医疗(ISM)应用设备的干扰或其他合法的无线电 (五) 如对其他合法的无线电台(站)产生有害干扰时,应立即停止使用,并采取措施消除干扰后

(六) 在航空器内和依据法律法规、国家有关规定、标准划设的射电天文台、气象雷达站、卫星地

- 球站(含测控、测距、接受、导航站)等军民用无线电台(站)、机场等的电磁环境保护区域内使用微功率设备,应当遵守电磁环境保护及相关行业主管部门的规定。 (七)禁止在以机场跑道中心为圆心,半径 5000 米的区域内使用各类模型遥控器。 (八) 微功率设备使用时温度和电压与耳机相同。

# 扫描、关注 1MORE 官方微信公众号 欢迎访问 1MORE 社区: bbs.1more.com


登录 www.1more.com,注册成为 1MORE 会员,更多精彩在等你。



名称: 1 MORE PistonBuds Pro 活塞耳机降噪版 播放时长\*(降噪关)。

名称: 1 MORE PistonBuds Pr 型号: EC302 克电盒重量: 30 g 整机重量: 39 g 耳机尺寸: 17×18×21.4 mm 充电盒尺寸: 58×23×37.7 mm 耳机电池容量: (单个): 38 mAh 充电盒电池容量: 410 mAh 耳机充电时间: 1 小时 充电盒充电时间: 2 小时 播放时长: (降噪开): 单耳满电: 4 小时 描放时长\*(降噪美): 申耳満电: 6.5 小时 搭配充电盒满电: 26 小时 喇叭阻抗: 16 Ω 頭叭距离: 10 米 (在空旷环境下) 遮牙規范: Bluetooth\* 5.2 遮牙协议: HFP / AZDP / AVRCP 輸入: 5V=0.5A 工作温度: 0°C ~ 45°C 頻率波段: 2.400 GHz ~ 2.4835 GHz 单耳满电: 4 小时 搭配充电盒满电: 16 小时

规格参数为实验室测试数据。 \* 播放时长为 AAC 格式、50% 音量条件下的实验室测算数据,依设备设置、环境、使用情况及诸多 其他因素可能有所差异。 制造商: 万魔声学股份有限公司 地址:深圳市南山区留仙大道 3333 号塘朗城 A 座 35楼 执行标准: GB8898



\* Above functions are available for either earbud in individual or Stereo mode.

# **Charging Methods**



With the Type-C cable, a full charge will take around 2 hours. A green light on the charging case indicates full battery.



With the charging case, a full

charge will take around 1 hour. The red lights on the headphones will turn off indicating charging is complete.

# Battery Status Display in 1MORE MUSIC APP

Battery status of headphones and charging case will be displayed in 1MORE MUSIC APP.





Above functions are available for either earbud ir Above functions may vary with different devices.

# Auto Pause/Play:

Playback will auto pause when it detects the earbuds are removed from the ears, it will auto play when it detects they are on again  $\,$ 





# **Extra Functions**

- If the earbuds cannot pair normally when powered on, open the case and quickly click the pairing button 3 times to reset the Left & Right pairing process. 2. Unpair the Connected Device: Put the earbuds into the case, press and hold the pairing button for 8 seconds.
- 3. OTA Firmware Update: It can be synchronously upgraded via 1MORE MUSIC app when the earbuds are connected.
- \* Functions of 1MORE MUSIC APP may vary with different cellphones or operating systems. For more details, please contact our customer service.

# 4

We Appreciate Your Business

We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction. If you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to www.Imore.com and sign up for VIP, and 1MQRE will treat you like one.

# Tips

- 1. Please read this instruction manual carefully and retain for future reference. 2. Please fully charge the battery before first use. 3. If the headphones have been unused for more than 3 months, we recommend that you charge
- them. This will improve battery capacity. 4. Only use charging cables and adapters that are FCC (Federal Communications Commission) approved.
- $5.\ \text{ln}$  dry environments, static electricity may numb your ear. This is not related to the quality of the product. Safety Information

- 1. Never disassemble the headphones. There are no user-serviceable parts inside 2. Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 3. Do not use the headphones in a thunderstorm storm. This could prevent the headphones from
- working properly, and also increase your chance of being electrically shocked. 4. Do not use oil or any volatile liquid to clean this product. 5. Do not listen at high volumes for extended periods of time 6. Do not use the headphones in traffic. Do not use the headphones any time it would be
- dangerous to be unaware of noises around you. 7. Adult supervision is required for children of age 6 and under

### **WEEE** Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household wastage, it must be collected and disposed of separately

Your 1MORE retailer will advise you of the correct way of disposal in your country. Safety Caution

## Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like. CE

Declaration for EU Compliance

authority to operate the equipment.

Operation Frequency/Max. EIRP: 2402-2480MHz, 10 dBm

to protect the environment.

Declaration of Conformity Hereby, Tiinlab Acoustic Technology Limited declares that the radio equipment type 1MORE PistonBuds Pro Wireless Headphones of EC302 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet



Hereby. Tiinlab Corporation declares that the radio equipment type Wireless Hereby, Tiniab Corporation declares that the ratio equipment type virinessy the Headphones is in compliance with UK Radio Equipment Regulations (SI 2017/1206). The full text of the UK declaration of conformity is available at the following internet address: www.1more.com

RF exposure information: The EIRP power of the device at maximal case is below the exempt condition, 20mW specified in EN62479: 2010. RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation(1999/519/EC).

### (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized

**FCC** This device complies with part 15 of the FCC rules. Operation is subject to the following two

modifications or changesto this equipment. Such modifications or changes could void the use

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is -Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity Trade Name: 1MORE

Responsible Party - U.S. Contact Information ss: 10225 Barnes Canyon Road, Suite A202, San Diego, California, 92121 F-Mail: support@1moreusa.com

Tel: 1-855-551-6673

Model No.: EC302

Model: EC302 Headphone Weight: 4.5 g

₩. Headphones & Case Fully Charged: 16h Wireless Headphones

Headphone Fully Charged: 6.5h

Impedance: 16 Ω

Headphones & Case Fully Charged: 26h

Case Weight: 30 g Product Weight: 39 g Headphone Size: 17×18×21.4 mm Case Size: 58×23×37.7 mm Case Battery Capacity: 410 mAh

Wireless Range: 10 m Bluetooth: Bluetooth® 5.2 Headphone Battery Capacity: 38 mAh Bluetooth Protocol: HFP / A2DP / AVRCP

Headphone Charging Time: 1h Case Charging Time: 2h Playtime\* (ANC On): Headphone Fully Charged: 4h

setting, environments, usage and other factors

Input: 5V == 0.5A Working Temperature: 0  $^{\circ}\text{C}\,\sim45\,^{\circ}\text{C}$ Frequency Band: 2.400 GHz ~ 2.4835 GHz

Manufacturer: Tiinlab Corporation Address: No. 3333, Liuxian Avenue, Tower A. 35th Floor, Tanglang City,

Nanshan District, Shenzhen, China Product information can be found at www.1more.com Made in China

# Inside The Box



Type-C Charging Cable x 1






Silicone Ear Tips × 3 Pairs (XS / S / L)

# **Product Overview**

Headphones × 1 Pair Charging Case × 1



# **Headphones Pairing**



The headphones will automatically pair to each other after the lid is open while they are in the case

# Bluetooth Pairing To The Device

- To connect to your device during first use, turn the headphones on to enter pairing mode. The headpho will enter sleep mode if not paired to a device within 3 minutes.
- 3 minutes.
   2. After the first successful pairing, headphones will automatically connect to your device when the case lid is opened.
   3. To pair with a new device: put headphones back into the case, click the pairing button for 3 times when powered on (no music or phone calls) to re-enter pairing mode.





## **Battery Notification**




Low Battery Alert: When there is 25-30 minutes of use time left, you will hear a voice prompt.



Tap the touch control area of the headphones to control phone calls and music playback.

### **Touch Controls** Tap the touch control area of the headphones to control phone calls and music playback.

Phone Call Playback



ic playback or volume adjustment, please set it up on 1MORE MUSIC APP or operate on the connected mobile phone or device

# ANC / Pass-through Modes

① ANC Mode: suitable for aviation, highspeed train, metro etc.
② Pass-through Mode: Lets in environmental sounds so you don't need to take out the earbuds to hear what is going on around you.

The default setting of the earbuds are "ANC Off"



Switch Listening Modes: Long press the touch control area on either earbud

Set up personal listening mode in 1MORE MUSIC APP.



Q.

9

# 1MORE (1) Year Limited Warranty

IMORE warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in either material or workmanship. IMORE, at its option, will (a) repair the product with new or refurbished parts, or (b) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, IMORE as tit is sole option may replace the unit with a current model of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. IMORE assumes no responsibility or liability for such modification. TO OBTAIN A REPAIR OR REPLACEMENT UNDER THE TERMS OF THIS WARRANTY, PLEASE RETURN TO THE ORIGINAL DEALER FIRST AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PRODUCT.

You will be required to submit a proof of purchasing details, including but not limited to a receipt or sales invoice.

This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration.

This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product.

This limited warranty is pull and void for products not used to accordance with the DEC. This limited warranty is null and void for products not used in accordance with 1MORE's Instructions.

This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer.

This limited warranty terminates if you sell or otherwise transfer this product to another

# party.

# **FAQ**

Why the headphones cannot be turned on?
 Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes.

2. Why the headphones cannot connect to my cellphone, or take a long time to connect?

1) If the earbuds cannot pair to one another, and only one earbud will pair with your cellphone, then put both buds back into the charging case and quickly press the pairing button 3 times, click the device name, they should now pair correctly to the phone.

2) To pair the earbuds to a new cellphone, simply place them into the charging case and depress the pairing button for 3 seconds. Then click the new device name and pair with the new cellphone.

3. Why the headphones cannot naw music after successfully connecting to my Angroid device?

3. Why the headphones cannot play music after successfully connecting to my Android device?

After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on.

4. Why there is no sound from the headphones while making phone calls after successfully connecting

to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on.

5. Why the Bluetooth connection is not stable and causes some interruptions?

Thy shortening the distance between your headphones and device. Avoid solid barriers in between.
 Please keep away from strong interference sources, such as Wi-Fi and GPRS.
 Please make sure the Bluetooth antenna of your device is not blocked.
 Why some control functions do not match those in the manual while using third party music/video

player Apps? Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions. We recommend that you use the music/video player apps that your device has originally provided. 7. I turned the headphoens up to the maximum volume, but why the actual volume still sounds low?

In different operating systems, especially some Android systems, the headphones and your device have separate volume control systems. Please adjust the volume controls on both the device and the headphones according to your preference. 8. Why are my headphones not able to connect to 1MORE MUSIC APP for the primary use?

For Android users, please click "Allow all the time" to access to the location information of your device when entering 1MORE MUSIC APP. Or adjust this option in your settings for this app.

\* For more detailed product FAQs, please visit the product support section under www.1more.com

### Warning Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc);

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and A battery subjected to extremely low air

pressure that may result in an explosion or the leakage of flammable liquid or gas. === The symbol indicates DC voltage. RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2014/53/EU in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment. To prevent possible hearing damage, do not listen at high volume levels for long periods.

The SAR limit of USA (FCC) is 1.6 W/kg for head averaged over one gram of tissue. Device types

EC302 (FCC ID: 2ASDIEC302 ) has also been tested with 0mm against this SAR limit.

Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference

fonctionnement est soumis aux deux conditions suivantes:

This device complies with CAN ICES-003 (B)/NMB-003(B).

(2) This device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil est conforme à la norme CAN ICES-003 (B)/NMB-003 (B).

(1) Cet appareil ne doit pas provoquer d'interférences. (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil

The SAR limit of Canada (ICES) is 1.6 W/kg for head averaged over one gram of tissue. Device

(IC:24662-EC302) has also been tested with 0mm against this SAR limit.


(V

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation,

Cet appareil contient des émetteurs / récepteurs exempt (s) de licence qui sont conformes aux RSS exemptes de licence d'Innovation, Sciences et Développement économique Canada. Son

# 耳機佩戴 開、關機 開機: 打開盒蓋,耳機即開機。 關機: 將耳機放入盒中, \*上述功能適用於單、雙模式使用時的任一耳機。

### 充電







使用充電盒給耳機充電,一次充 滿需約1小時。當充滿電時, 耳機 LED 燈熄滅。

## 1MORE MUSIC APP 電量顯示

耳機與充電盒的電量狀態將在 1MORE MUSIC APP 中顯示。





功能適用於單、雙模式使用時的任 \*以上功能定義因設備不同可能略有差異。

## 自動暫停/播放:

播放時取下耳機,播放自動暫停;再次戴上,自動續播。





## 其它功能

- 1. 如開機時,左、右耳機無法正常配對,打開盒蓋,3 連擊充電盒配對按鈕,進入强制配對。 2. 浦除手機連接記錄: 將左、右耳機放入充電盒中,長按充電盒配對按鈕 8 秒,强制清除手機連接記錄。 3. OTA 韌體升級: 左、右耳機藍牙連接時,可直接在 1MORE Assistant APP 上同步升級。
- \* 1MORE MUSIC APP 的所有功能,在不同手機及操作系統上或有不同,請聯繫客服了解更多詳情。

1MORE保證消費者自初次購買之日起一年內,對1MORE產品在正常使用途中材料和工藝上的缺陷進行保修。在保固範圍內,1MORE會直接受理您的申訴(包括從1MORE授權的經銷商處購買的1MORE產品)。在保固期內,1MORE將自行決定修理或更換有缺陷產品或按照購買價格進行退款。本保固不適用於天災意外或使用,保養,維修不當,或是其他不是由材料,工藝上的缺陷引起的情況。完整的保固細節請登錄www.1more.com 查看。

感謝您的購買

我們知道您會享受並喜愛1MORE耳機。在1MORE 我們格外重視您的滿意度,如果您想要了解更多產品的訊息請掃描背面的二維條碼,進入www.1more.com 登錄成為VIP,1MORE將提供您尊榮的服務。

- 取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功
- 率或變更原設計之特性及功能。 低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用, 並改善至無干擾時方得繼續使用。
- 前述合法通信,指依電信管理法規定作業之無線電通信。 低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

### 包装内容



耳機 × 1 副 + 充電盒 × 1








Type-C 充電綫 × 1

硅膠耳套 × 3 副 (XS/S/L)

### 產品概覽



### 左、右耳機配對



耳機置於盒中,開蓋即左、右自動配對。

### 耳機與藍牙設備配對連接

- 首次連接,開機後即進入搜索配對。如3分鐘後無法 正常連接,耳機將進入休眠模式。
- 2. 已連接過設備的耳機,將自動與該設備進行藍牙連接。
- 3. 耳機與新設備連接:將耳機置於盒中,非通話狀態下, 三擊配對按鈕,即可與新設備進行配對連接。
- \* 上述功能適用於單、雙模式使用時的任一耳機。



### 電量提示



低電量提示:當耳機還能使用約 25 ~ 30 分鐘時,耳機將播放提示音。



當充電盒的電量不足以給耳機供電時,充電盒的 LED 將閃紅燈。

## 觸控功能

觸摸耳機感應區域可操控通話和播放功能。









\* 拒接電話:長觸 2S。 \* 選曲及音量調節,可通過 1MORE MUSIC APP 進行設置或在手機等設備端進行操作。

## 降噪、 通透模式

- ① 强檔降噪. 適用于航空、高鐵、地鐵等場景。
- ② 通透模式: 戴著耳機, 也不錯過外界聲音信息。 左、右耳機的出廠設置均為: ANC Off



降噪模式切換: 觸左/右耳機觸控區域

在 1MORE MUSIC APP 中可快捷設定聆聽模式。



型號: EC302 耳機重量(單個): 4.5 g 充電盒重量: 30 g 整機重量: 39 g 耳機尺寸: 17×18×21.4 mm 充電盒尺寸: 58×23×37.7 mm 耳機電池容量(單個): 38 mAh 充電盒電池容量: 410 mAh 耳機充電時間: 1 小時 充電盒充電時間: 2 小時 播放時長\*(降噪開). 單耳滿電: 4 小時

播放時長\*(降噪關): 單耳滿電, 6.5小時 搭配充電盒滿電: 26 小時 喇叭阻抗: 32 Ω 通訊距離: 10米(在空購環境下) 藍牙規範: Bluetooth® 5.2 藍牙協議: HFP / A2DP / AVRCP 輸入: 5V-0.5A 工作温度: 0℃~45℃ 頻率波段: 2.400 GHz~2.4835 GHz

搭配充電盒滿電: 16 小時 規格參數為實驗室測試數據。 · 插放時長為 AAC 格式、50% 音量條件下的實驗室測算數據,依設備設置、環境、使用情况及諸多其他因素可能有所差異。

製造商: 萬魔聲學股份有限公司 地址:深圳市南山區留仙大道 3333 號塘朗城 A 座 35 樓

