

User Manual

Intelligent voice Recorder




EN



<https://recolx.ai/>

Download the Recolx App to activate Recolx device upon first time.



- ①Microphone (mic) *2
- ②Indicator light
- ③Function buttons
- ④Data interface (charging port).

EN

Product Overview

Product Name: RECOLX AI VOICE RECORDER
Product Model: JYDH 100
Bluetooth Version: V5.0
Battery Capacity: 400 mAh
Charging Voltage: DC5V=1A

Indicator Light Status

Status	Button Operation	Light Color	Vibration Feedback
Charging	None	Green slow flash	None
Fully Charged	None	Green solid	None
Data Transfer	None	Blue fast flash	None
Power On	Press 0.5s	Blue slow flash	Short  x1
Bluetooth Standby	Auto on power	Blue slow flash	None
Bluetooth Connected	Auto on connect	Blue solid	None
Start Recording	Hold 0.5s	Red solid	Short  x2
Stop Recording	Hold 0.5s	Red off	Short  x1
Pause Recording	App controlled	Red flash	None
Standby	None	No light	None
Power Off	Hold 6s	No light	Long  x1

User Instructions

Power On and Off

Power On: Press the function button for 0.5 seconds.
The device will default to Bluetooth pairing mode
(the blue indicator light flashes slowly).

Once connected, the blue light will remain on.

Power Off: Press and hold the function button for ten seconds. The device will vibrate briefly before shutting down, and the indicator light will turn off.

EN

Connecting Devices

1. Search for [Recolx] in the App Store or Google Play to find the app. Create your Recolx account.



2. Briefly press the function button for 0.5 seconds to turn on the device. The blue indicator light will blink. Once the device is powered on, it can be connected to the app via Bluetooth.



3. Enable location services and Bluetooth on your phone. Open the RECOLX app and click the top left corner of the home screen to follow the on-screen instructions to complete the pairing process.



Once connected, the device status and related information will be displayed in the app.

EN


How to Record Audio:

Select Recording Mode

Choose the recording mode based on your environment: Conference Recording, Call Recording, Long-Distance Recording, or Short-Distance Recording. You can change the recording mode in the app

Recording Steps:

- **Turn On:** Briefly press the function button for 0.5 seconds to switch on the device.
- **Start Recording:** Press and hold the function button for 0.5 seconds to begin recording. You will feel two short vibrations, and the red indicator light will remain on, indicating that recording has started.



- **End Recording:** Press and hold the function button for 0.5 seconds to stop recording. You will feel one short vibration, and the red indicator light will turn off, indicating that recording has ended.




EN

KR



<https://recolx.ai/>

사용 전 RECOLX 앱을 다운로드하여 장치를 활성화해 주시기 바랍니다.



- ① 마이크 (mic) *2
- ② 표시등
- ③ 기능 버튼
- ④ 데이터 인터페이스 (충전 포트)

KR

제품 개요

상품명: RECOLX 지능형 음성 녹음기
모델 번호: JYDH 100
블루투스 버전: V5.0
배터리 용량: 400 mAh
충전 전압: DC5V=1A

상태 표시등 설명

상태	조작 방식	조명 색상	진동 피드백
충전 중	없음	녹색 LED 느리게 깜박임	없음
완전 충전	없음	녹색 LED 상시 점등	없음
데이터 전송	없음	파란색 LED 빠르게 깜박임	없음
전원 켜기	전원 버튼을 0.5초 길게 눌러서 켜기	파란색 LED 느리게 깜박임	짧은 진동 한 번
블루투스 대기	전원 켜면 자동으로 진입	파란색 LED 느리게 깜박임	없음
블루투스 연결됨	블루투스 연결 성공	파란색 LED 상시 점등	없음
녹음 시작	녹음 시작을 위해 0.5초 길게 눌러야 함	빨간색 LED 상시 점등	짧은 진동 두 번
녹음 중지	녹음 중지를 위해 0.5초 길게 눌러야 함	빨간색 LED 꺼짐	짧은 진동 한 번
녹음 일시 정지 대기 모드	없음 (앱 제어)	빨간색 LED 깜박임	없음
전원 끄기	6초 길게 눌러야 함	불빛 없음 (짧게 눌러 현재 상태 표시)	없음
		없음	긴 진동 한 번

사용 설명서

전원 켜기 및 끄기

전원 켜기: 기능 버튼을 0.5초 동안 눌러 전원을 켭니다.
기본적으로 블루투스 대기 연결 상태로 진입하며 (파란 불빛이 느리게 깜박임), 블루투스 연결이 완료되면 파란 불빛이 지속적으로 켜집니다.
전원 끄기: 기능 버튼을 10초 동안 길게 눌러 장치를 끕니다.
장치가 긴 진동을 한 후 전원이 꺼지며, 불빛이 꺼집니다


KR

연결 방법

1. 앱 스토어 또는 구글 플레이에서 [Recolx]를 검색하여 앱을 다운로드합니다. RECOLX 계정을 생성하세요.



2. 먼저, 기능 버튼을 0.5초 동안 짧게 눌러 전원을 켭니다. 파란색 표시등이 깜박이면, 장치가 켜진 것입니다. 이후 Bluetooth를 통해 앱에 연결할 수 있습니다.



3. 휴대폰의 위치 서비스와 Bluetooth 기능을 활성화한 후, RECOLX 앱을 열고, 화면 왼쪽 상단을 클릭하여 안내에 따라 연결 과정을 완료합니다.



연결이 완료되면 장치 상태 및 관련 정보가 앱에 표시됩니다.

KR


녹음 방법

1. 녹음 모드 선택

녹음 환경에 따라 회의 녹음, 통화 녹음, 장거리 녹음 또는 단거리 녹음을 선택합니다. 앱 내에서 녹음 모드를 변경할 수 있습니다.

2. 녹음 조작 단계

- **전원 켜기:** 기능 버튼을 0.5초간 눌러 전원을 켭니다.
- **녹음 시작:** 기능 버튼을 0.5초간 눌러 녹음을 시작합니다. 두 번의 짧은 진동 후, 빨간색 표시등이 지속적으로 켜지면 녹음이 시작된 것입니다.



- **녹음 종료:** 기능 버튼을 0.5초간 눌러 녹음을 종료합니다. 한 번의 짧은 진동 후, 빨간색 표시등이 꺼지면 녹음이 종료된 것입니다.




TC

TC



<https://recolx.ai/>

首次使用前，請下載RECOLX應用程式以啟動設備。



- ①麥克風（mic）*2
- ②指示燈
- ③功能按鍵
- ④數據接口（充電口）

產品概述

商品名稱：RECOLX AI智慧錄音卡
商品型號：JYDH 100
藍牙版本：V5.0
電池容量：400 mAh
充電電壓：DC5V=1A

指示燈狀態說明：

狀態	按鍵操作	燈光顏色	震動反饋
充電中	無	綠燈慢閃爍	無
滿電	無	綠燈常亮	無
數據傳輸	無	藍燈快閃爍	無
開機	按住開機鍵0.5秒開機，預設進入藍牙待連接狀態	藍燈慢閃爍	震動短促一次
藍牙待連接	開機後自動進入	藍燈慢閃爍	無
藍牙已連接	藍牙成功連接時自動切換	藍燈常亮	無
開始錄音	長按0.5秒開始錄音	紅燈常亮	震動短促兩次
停止錄音	長按0.5秒停止錄音	紅燈熄滅	震動短促一次
暫停錄音	無（應用程式控制）	紅燈閃爍	無
待機	無	無燈光（短按顯示當前設備狀態）	無
關機	長按6秒	無	震動長一下

使用說明

開機與關機

開機：按下功能鍵 0.5 秒即可開機，默認進入藍牙待連接狀態（指示燈藍色緩慢閃爍）。藍牙連接完成後，藍色指示燈將常亮。

關機：長按功能鍵十秒，設備會長時間震動後自動關機，指示燈熄滅。


TC

如何連接設備

1.在 App Store 或 Google Play 中搜索 [Recolx]，找到該應用程式，並創建您的 RECOLX 帳號。



2.首先，短按功能鍵 0.5 秒以開機，藍色指示燈會閃爍。設備開機後，可通過藍牙連接到應用程式。



3.開啟手機的定位和藍牙功能，然後打開 RECOLX 應用程式，點擊首頁左上角，按照螢幕指引完成綁定過程。



連接後，設備狀態和相關信息將顯示在應用程式中

TC


如何錄音

1.選擇錄音模式

根據錄音環境選擇會議錄音、通話錄音、長距離錄音或短距離錄音。
在應用程式中更改錄音模式。

2.錄音操作步驟

- 開機：**按住功能鍵0.5秒開機。
- 錄音開始：**按住功能鍵0.5秒開始錄音，感受到兩次短促振動，紅色指示燈常亮。



- 錄音結束：**按住功能鍵0.5秒結束錄音，感受到一次短促振動，紅色指示燈熄滅。




TC

JP



<https://recolx.ai/>

ご使用になる前に、RECOLXアプリをダウンロードし、デバイスを起動してください。



- ① マイク（mic）*2
- ② インジケータランプ
- ③ 機能ボタン
- ④ データインターフェース（充電ポート）

JP

製品概要

商品名：RECOLX AIボイスレコーダー
商品型番：JYDH 100
Bluetoothバージョン：V5.0
バッテリー容量：400 mAh
充電電圧：DC5V=1A

インジケータライトの状態説明

状態	操作	ライトの色	バイブレーション
充電中	なし	緑色点滅	なし
満電	なし	緑色点灯	なし
データ転送	なし	青色点滅	なし
起動	0.5秒長押し	青色点滅	短い [🔊] x1
Bluetooth待機中	自動的に接続待機	青色点滅	なし
Bluetooth接続済	自動的に接続完了	青色点灯	なし
録音開始	0.5秒長押し	赤色点灯	短い [🔊] x2
録音停止	0.5秒長押し	赤色消灯	短い [🔊] x1
録音一時停止	なし（アプリ操作）	赤色点滅	なし
スタンバイ	なし	ライトなし（短押しで状態表示）	なし
シャットダウン	6秒長押し	なし	長い [🔊] x1

使用ガイド

電源のオン/オフ

電源オン：機能ボタンを0.5秒押すと電源が入り、デフォルトでBluetooth接続待機状態になります（青色のランプがゆっくり点滅します）。Bluetooth接続が完了すると、青色のランプが常時点灯します。

電源オフ：機能ボタンを長押し（10秒間）すると、デバイスが長く振動し、その後電源がオフになります。ランプは消灯します。

JP

デバイスの接続方法

1.アプリのインストール

App StoreまたはGoogle Playで「Recolx」と検索し、アプリを見つけてインストールします。RECOLXアカウントを作成します。



2.デバイスの電源を入れる

機能ボタンを0.5秒間短く押して電源を入れます。青色のインジケータライトが点滅します。デバイスが起動したら、Bluetoothを使ってアプリに接続できます。



3.Bluetoothと位置情報の設定

スマートフォンのBluetoothと位置情報を有効にし、RECOLXアプリを開きます。ホームページの左上のボタンをタップし、画面の指示に従ってペアリングプロセスを完了させてください。



接続後、デバイスの状態と関連情報がアプリに表示されます。

JP


録音方法

1. 録音モードの選択

録音環境に応じて、会議録音、通話録音、長距離録音、または短距離録音のいずれかを選択してください。アプリ内で録音モードを変更できます。

2. 録音手順

- 電源オン：**機能ボタンを0.5秒押しして電源を入れます。
- 録音開始：**機能ボタンを0.5秒押し続けると、2回の短い振動を感じることがあります。赤い指示灯が常時点灯し、録音が始まったことを示します。



- 録音終了：**機能ボタンを0.5秒押し続けると、1回の短い振動を感じ、赤い指示灯が消灯します。これで録音が終了したことを示します。



JP



<https://recolx.ai/>

EN:
Please scan to learn more detailed instructions about RECOLX AI VOICE RECORDER.

KR :
RECOLX 지능형 음성 녹음기에 대한 자세한 지침을 보시려면 스캔하세요.

TC:
請掃描以獲取有關RECOLX AI智慧錄音卡的詳細說明。

JP:
RECOLX AIボイスレコーダーに関する詳細な指示を知るには、スキャンしてください。



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.