

ITEM	REV.	DESCRIPTION	DATE
REV.	1	INITIAL DESIGN	05/05/2024
REV.	2	UPDATES TO CASE	06/05/2024
REV.	3	UPDATES TO CASE AND FUNCTIONALITY	07/05/2024
REV.	4	UPDATES TO CASE AND FUNCTIONALITY	08/05/2024
REV.	5	UPDATES TO CASE AND FUNCTIONALITY	09/05/2024

NO.	DESCRIPTION	REVISION	DATE
1	DESIGN	1.0	05/05/2024

INSTRUCTIONS



Light Functions



Menu Functions



Light Functions

Bright Press to turn light on or off.
Dimming Press up or down to increase or decrease light intensity.
On/Off Press to turn light on or off.
Battery Indicator Press to view battery level.

Menu Functions

Setup Time Press to set the time.
Proximity Sensor Press to turn on or off the proximity sensor.
Proximity Sensor Press to turn on or off the proximity sensor.

Fonctions d'Éclairage

Éclairage Appuyez pour allumer ou éteindre la lumière.
Dimmer Appuyez sur les touches de haut ou de bas pour augmenter ou diminuer l'intensité lumineuse.
On/Off Appuyez pour allumer ou éteindre la lumière.

Fonctions du Menu

Setup Time Press to set the time.
Proximity Sensor Press to turn on or off the proximity sensor.
Proximity Sensor Press to turn on or off the proximity sensor.

Fonctions de List

Setup Time Press to set the time.
Proximity Sensor Press to turn on or off the proximity sensor.
Proximity Sensor Press to turn on or off the proximity sensor.

Fonctions del Menu

Setup Time Press to set the time.
Proximity Sensor Press to turn on or off the proximity sensor.
Proximity Sensor Press to turn on or off the proximity sensor.



ITEM	REV.	DESCRIPTION	DATE
REV.	1	INITIAL DESIGN	05/05/2024
REV.	2	UPDATES TO CASE	06/05/2024
REV.	3	UPDATES TO CASE AND FUNCTIONALITY	07/05/2024
REV.	4	UPDATES TO CASE AND FUNCTIONALITY	08/05/2024
REV.	5	UPDATES TO CASE AND FUNCTIONALITY	09/05/2024

ITEM	REV.	DESCRIPTION	DATE
REV.	1	INITIAL DESIGN	05/05/2024
REV.	2	UPDATES TO CASE	06/05/2024
REV.	3	UPDATES TO CASE AND FUNCTIONALITY	07/05/2024
REV.	4	UPDATES TO CASE AND FUNCTIONALITY	08/05/2024
REV.	5	UPDATES TO CASE AND FUNCTIONALITY	09/05/2024