



FreeRein

USER MANUAL

FCC ID:QTGIFFSBE

Warranty Registration

Your iFrogz FreeRein Bluetooth® earbuds come with a one-year manufacturer's warranty. Please keep your purchase receipt and register your FreeRein earbuds on our website www.ifrogz.com (purchases made on our website are automatically registered). Replacement products must be mailed back as soon as your new product arrives; you may incur postage fees as a result. See our website FAQs for further details. iFrogz is a ZAGG Inc brand.

Getting Started



The iFrogz FreeRein earbuds are the perfect solution for hands-free, premium quality music everywhere you go. They connect to your favorite devices wirelessly via Bluetooth® and deliver crystal clear music and calls.

The FreeRein earbuds are ready to go right out of the box, with about 80% battery life.

Getting started is as simple as 1, 2, 3.

1. Press and hold the Play button for five seconds to turn the earbuds on and pair them.
2. Turn on your favorite, Bluetooth-enabled audio device and access its Bluetooth settings.
3. Pair the FreeRein earbuds with your device (the earbuds will show up as iFrogz FreeRein), and enjoy over three hours of amazing sound, without bothersome cords (charge to 100% capacity for longer play time).

Continue reading these instructions for information on controlling your music, taking calls, and pairing. Keep these instructions for future reference.




Functionality

Volume Down

- Turn volume down - Press once and repeat until desired volume is reached. A tone will sound for each change in volume level until a final, lower pitched tone indicates you have reached the minimum volume.
- Track back - Press and hold for two seconds to re-start a song, press and hold for two seconds again at the beginning of a song to track back on your playlist.

Volume Up/Track Forward


- Turn volume up - Press once and repeat until desired volume is reached. A tone will sound for each change in volume level until a final, higher pitched tone indicates you have reached the maximum volume.
- Track forward - Press and hold for two seconds to move forward in your playlist.



Functionality

Play/Pause

- Turn on and pair - Press and hold for five seconds.
- Turn on - Press and hold for two seconds.
- Turn off - Press and hold for three seconds.
- Pause/resume music - Press once while playing to pause or while paused to resume your music.
- Take a call - Press once while ringing.
- End a call - Press once while talking.
- Ignore a call - Press and hold for two seconds while ringing.



Functionality

LED Indicator

- Charging - Solid red.
- Fully charged - Blue.
- Pairing - Flashing red and blue.
- Need to charge - Flashing red every 20 seconds (indicates battery is below 15%).

Pairing Your FreeRein Earbuds

With them charged and ready to go, pairing your FreeRein earbuds is quick and easy. Once paired with a device, you shouldn't need to pair them again. If the connection between the FreeRein earbuds and your device is ever broken or forgotten, simply repeat these steps.

1. Make sure your device's Bluetooth® connection is enabled. You can do this on many devices by accessing the SETTINGS menu, and then choosing GENERAL > BLUETOOTH > ON.
2. Press and hold the Play/Pause button for five seconds, or until the LED in the right earbud flashes red and blue.
3. Your device will show iFrogz FreeRein as an available device. Select this option to begin pairing. Once paired, the LED will stop flashing.

Charging Your FreeRein Earbuds

Your FreeRein earbuds come ready to go about 80% charged. That's enough to deliver over three hours of play. When you are ready to recharge your FreeRein earbuds:

1. Connect the included micro USB cord to the corresponding port.
2. Plug the USB end of the cord into your preferred charging device (an iFrogz® GoLite, your computer, a wall outlet converter, etc.).
3. The LED will light red and stay lit until your FreeRein earbuds are charged. It typically takes one and a half hours to charge fully.
4. When charged, the 65mAh lithium polymer battery in your FreeRein earbuds provides three to four hours of continuous play per charge.

Troubleshooting

If your music device does not respond to your FreeRein earbuds there may be a simple explanation such as a dead battery or an unsuccessful pairing. Please use the following to help troubleshoot your situation. If none of the following solve your issue, then please contact iFrogz Customer Service and one of our trained professionals will be happy to assist you.

1. There is popping or static when listening to music.
 - Turn down the volume on the FreeRein earbuds and turn it up on your music device.
2. The earbuds are not pairing.
 - If you have used your FreeRein earbuds with another device, have that device forget them and try pairing again. Additionally, try charging your earbuds to make sure they have adequate power.
3. You receive an error message when pairing your FreeRein earbuds.
 - Ensure you are following the proper steps to pair the earbuds and try pairing again. If they still do not pair, contact iFrogz Customer Service.

For more help please see: www.ifrogz.com

To reach a trained customer service representative, please use one of the following:

ifrogz.com/support/contact.php

questions@ifrogz.com

1-800-700-ZAGG [9244]

00-1-801-839-3906 for international customers

©2005 - 2014 ZAGG Inc | All Rights Reserved.

NASDAQ: ZAGG | MADE IN CHINA | iFrogz is a ZAGG brand

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1: This device may not cause harmful interference, and

2: This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.