


Clip Mini Bluetooth® Speaker

Instruction Manual XO-9401



- Power Button
- Micro-USB Charging Port
- LED Indicator
- Mic (speaker base)

What's included:

- 1 x Mini Speaker
- 1 x USB to Micro-USB charging cable
- 1 x Carrying Strap
- 1 x Instruction Manual

Tech Specifications

- Input: DC 5V/500mA
- Product Dimensions: 35*35 *35 mm
- Paring name : mini SPEAKER
- Bluetooth version: 4.2
- output power: 5.5dBm
- Frequency response:2.4-2.48G
- Battery type: Li-Polymer
- Battery Capacity:200MAH

Instructions:

1. **Charging the speaker:**
 - a. *Using a regulated USB adapter.* Connect a USB cable to a USB adapter. Using the Micro-USB connector, connect the other end of the USB cable to the charging port on the speaker. Plug the USB adapter into the outlet to begin charging.

Instructions (continued):

- b. *Using your computer.* Connect a USB cable to a USB outlet on your computer. Using the Micro-USB connector, connect the other end of the USB cable to an charging port on the speaker. Make sure the computer is on to begin charging the speaker.

2. Connecting a Media Device:

- a. Press and hold the Power Button for approx. 2 seconds to turn speaker ON/OFF.
- b. The Blue LED Indicator will flash to indicate pairing mode.
- c. Select "Mini Speaker" on your media device.

3. Power Button Function:

- a. Audio volume and track selection can be made by using the media source device.
- b. Single, short press the power button to play/pause audio.

4. When receiving an incoming call:

- a. Single, short press the power button to answer an incoming call.
- b. Single press again to hang up.
- c. Use the mic located on the speaker base during a call.

SAFETY PRECAUTIONS:

- **WARNING**-When using this product, basic precautions should always be followed, including the following:
 1. Read all the instructions before using the product.
 2. Charge the speaker completely before initial use to ensure longevity.
 3. If the device does not respond once it is powered on, the battery capacity may be low.
 4. Do not over charge the internal battery.

SAFETY PRECAUTIONS (continued):

5. Do not immerse in water or expose to moisture or damp weather conditions.
6. Do not drop, knock, or shake. Rough handling can damage the internal precision component and its boards.
7. Do not insert any objects into the speaker/mic.
8. Keep away from children. Device is not a toy.
9. Keep away from fire or other sources of heat. Exposure to high temperatures may cause it to explode.
10. Do not short-circuit as this may cause damage to the unit.
11. Do not pull the charging cable or over-extend it's reach.
12. Unauthorized changes or modifications may void your right to use this product.
13. While using, always comply with any special regulations that may apply to the area you are in and always turn off your mobile device when its use is prohibited.

FCC Statement:

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- ★ Warning:
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . The device has been evaluated to meet general RF exposure requirement.



MADE IN CHINA